

TM-L500A

Technical Reference Guide

Product Overview

Describes features and general specifications for the product.

Setup

Describes setup and installation of the product and peripherals.

Application Development Information


Describes how to control the printer and necessary information when you develop applications.

Handling

Describes how to handle the product.

Appendix

Describes interfaces, connectors, and character code tables.



Cautions

- No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation.
- The contents of this document are subject to change without notice. Please contact us for the latest information.
- While every precaution has been taken in the preparation of this document, Seiko Epson Corporation assumes no responsibility for errors or omissions.
- Neither is any liability assumed for damages resulting from the use of the information contained herein.
- Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third
 parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of:
 accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this
 product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating
 and maintenance instructions.
- Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by Seiko Epson Corporation.

Trademarks

EPSON and ESC/POS are registered trademarks of Seiko Epson Corporation in Japan and other countries/regions.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

ESC/POS® Command System

EPSON ESC/POS is a proprietary POS printer command system that includes patented or patent-pending commands. ESC/POS is compatible with most EPSON POS printers and displays.

ESC/POS is designed to reduce the processing load on the host computer in POS environments. It comprises a set of highly functional and efficient commands and also offers the flexibility to easily make future upgrades.

For Safety

Key to Symbols

The symbols in this manual are identified by their level of importance, as defined below. Read the following carefully before handling the product.



You must follow warnings carefully to avoid serious bodily injury.



Provides information that must be observed to prevent damage to the equipment or loss of data.

- Possibility of sustaining physical injuries.
- Possibility of causing physical damage.
- · Possibility of causing information loss.



Provides information that must be observed to avoid damage to your equipment or a malfunction.



Provides important information and useful tips.

Warnings



- To avoid risk of electric shock, do not set up this product or handle cables during a thunderstorm
- · Never insert or disconnect the power plug with wet hands.

Doing so may result in severe shock.

• Handle the power cable with care.

Improper handling may lead to fire or electric shock.

- * Do not modify or attempt to repair the cable.
- * Do not place any heavy object on top of the cable.
- * Avoid excessive bending, twisting, and pulling.
- * Do not place the cable near heating equipment.
- * Check that the plug is clean before plugging it in.
- * Be sure to push the plug all the way in.
- · Be sure to use the specified power source.

Connection to an improper power source may cause fire or shock.

• Do not place multiple loads on the power outlet.

Overloading the outlet may lead to fire.

 Shut down your equipment immediately if it produces smoke, a strange odor, or unusual noise.

Continued use may lead to fire. Immediately unplug the equipment and contact your dealer or a Seiko Epson service center for advice.

Never attempt to repair this product yourself.

Improper repair work can be dangerous.

. Never disassemble or modify this product.

Tampering with this product may result in injury or fire.

• Do not allow foreign matter to fall into the equipment.

Penetration by foreign objects may lead to fire.

• If water or other liquid spills into this equipment, do not continue to use it.

Continued use may lead to fire. Unplug the power cord immediately and contact your dealer or a Seiko Epson service center for advice.

• If you open the DIP switch cover, be sure to close the cover and tighten the screw after adjusting the DIP switch.

Using this product with the cover open may cause fire or electric shock.

 Do not use aerosol sprayers containing flammable gas inside or around this product.

Doing so may cause fire.

Cautions



- Do not connect cables in ways other than those mentioned in this manual.

 Different connections may cause equipment damage or fire.
- Be sure to set this equipment on a firm, stable, horizontal surface.

 The product may break or cause injury if it falls.
- Do not use this product in locations subject to high humidity or dust levels. Excessive humidity and dust may cause equipment damage or fire.
- Do not place heavy objects on top of this product. Never stand or lean on this product.

Equipment may fall or collapse, causing breakage and possible injury.

- Take care not to injure your fingers on the manual cutter:
 - * When you remove printed paper.
 - * When you perform other operations, such as loading/replacing roll paper.
- Do not open the roll paper cover without taking the necessary precautions, as this
 can result in injury from the autocutter fixed blade.
- To ensure safety, unplug this product before leaving it unused for an extended period.

Restriction of Use

When this product is used for applications requiring high reliability/safety, such as transportation devices related to aviation, rail, marine, automotive, etc.; disaster prevention devices; various safety devices; or functional/precision devices, you should use this product only after giving consideration to including fail-safes and redundancies into your design to maintain safety and total system reliability. Because this product was not intended for use in applications requiring extremely high reliability/safety, such as aerospace equipment, main communication equipment, nuclear power control equipment, or medical equipment related to direct medical care, etc., please make your own judgement on this product's suitability after a full evaluation.

About this Manual

Aim of the Manual

This manual was created to provide information on development, design, and installation of systems and development and design of printer applications for developers.

Manual Content

The manual is made up of the following sections:

Chapter 1 Product Overview

Chapter 2 Setup

Chapter 3 Application Development Information

Chapter 4 Handling

Appendix Specifications of Interfaces and Connectors

Character Code Tables

Contents

■ For Safety	3
Key to Symbols	
Warnings	
Cautions	5
■ Restriction of Use	5
■ About this Manual	6
Aim of the Manual	6
Manual Content	6
Product Overview	
■ Features	11
■ Product Configurations	12
LCD (Liquid Crystal Display)	12
BP (Boarding Pass)-Tray	12
Corner R (Round) Detection	
Interfaces	
Accessories	
Part Names and Functions	
Power Switch	
Control Panel	
Connectors	
Offline	17
■ Error Status	19
Printer Errors	19
Unrecoverable Errors	
Data Receive Error (Only with the Serial Interface Models)	21
■ Power-Saving Mode	22
Sleep 1 & Sleep 2	22
Sleep 3	
■ NV Memory (Non-Volatile Memory)	24
Memory Switches	24
Maintenance Counter	24
■ Product Specifications	25
Printing Specifications	26
Paper Specifications	27
Specified Original Paper Types	
Printable AreaPrinting and Cutting Positions	
Printing and Cutting Positions	
=	

Corner R Detection (Only for Models with Corner R Detection)	
Electrical Characteristics	
Reliability	
Environmental Conditions External Dimensions and Mass	
Power Supply Unit (PS-180)	
Tower supply of in (1 o 100)	
Setup	43
■ Flow of Setup	43
■ Installing the Printer	43
Important Notes	43
■ Changing the Paper Width	44
Setting the Paper Width to 82.5 mm	
Setting the Paper Width to 79.5 mm	
Setting the Paper Width to 50.8 mm (Only for ESC/POS mode)	47
■ Setting the DIP Switches	48
Setting Procedure	48
For Serial Interface	
For USB InterfaceFor Ethernet Interface	
■ Connecting the Printer to the Host Computer	
For Serial Interface	
For USB Interface	
For Ethernet Interface	54
■ Connecting the Power Supply Unit (PS-180)	55
Connecting the Power Supply Unit	55
Setting the Memory Switches	57
Functions	58
Setting Menu on the LCD	64
Application Development Information	65
■ How to Control the Printer	
EPSON Advanced Printer Driver (APD) AEA Commands	
ESC/POS Commands	
Software and Manuals	
How to Get Drivers, Manuals, and the Utility	
Printer Driver	
Utilities	67

## Brandling ## Belf-Test ## Appendix ##	■ Self-Test Mode	68
Usage Precautions	Starting the Self-Test	68
■ Installing and Replacing Paper 70 Installing Paper 70 Replacing Paper 71 ■ Removing Jammed Paper 73 ■ Cleaning the Printer 75 Cleaning the Printer Case 75 Cleaning the Thermal Head 75 ■ Preparing for Transport 77 Appendix 79 ■ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 10BASE-T/100BASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 1 (Katakana) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 2 (PC865: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 1 (PC851: Greek) 93 Page 1 (PC851: Greek) 93 Page 1 (PC857: Greek) 96 Page 1 (PC855: Turkish) 96 Page 1 (PC855: Turkish) 96 Page		
Installing Paper	■ Usage Precautions	69
Installing Paper	■ Installing and Replacing Paper	70
Replacing Paper. 71 ■ Removing Jammed Paper. 73 ■ Cleaning the Printer. 75 Cleaning the Printer Case. 75 Cleaning the Thermal Head. 75 ■ Preparing for Transport. 77 Appendix. 79 ■ Specifications of Interfaces and Connectors. 79 R8-232 Serial Interface. 79 10BASE-T/100BASE-TX Ethernet Interface. 83 USB (Universal Serial Bus) Interface. 85 ■ Character Code Tables. 86 Common to All Pages. 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana). 88 Page 2 (PC860: Mutillilingual) 89 Page 3 (PC860: Portuguese). 90 Page 4 (PC863: Canacian-Fench) 91 Page 5 (PC865: Nordic). 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (RO857: Turkish) 94 Page 16 (WPC1252). 98 Page 17 (PC866: Cyrillic #2) 98 Page 18 (PC852: Latin2). 100 Page 20 (KIU42: Thai). 102 <td></td> <td></td>		
■ Removing Jammed Paper 73 ■ Cleaning the Printer 75 Cleaning the Printer Case 75 Cleaning the Thermal Head 75 ■ Preparing for Transport 77 ■ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 10BASE-T/100BASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multillingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 12 (PC851: Turkish) 94 Page 13 (PC851: Turkish) 94 Page 15 (S008859-7: Greek) 96 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin/2) 100 Page 20 (Klu42: Thai) 101 Page 20 (Klu42: Thai) </td <td></td> <td></td>		
■ Cleaning the Printer 75 Cleaning the Printer Case 75 Cleaning the Thermal Head 75 ■ Preparing for Transport 77 ▲ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 10BASE-T/100BASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Karlakana) 88 Page 2 (PC850: Multillingual) 89 Page 3 (PC860: Portruguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC857: Turkish) 94 Page 15 (S008859-7: Greek) 96 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 29 (Kul42: Thai) 101 Page 20 (KUl42: Thai) 101 Page 20 (KUl42: Thai) 102 Page 20 (KUl43: Thai) 1		
Cleaning the Printer Case 75 Cleaning the Thermal Head 75 ▶ Preparing for Transport 77 ♣ Preparing for Transport 77 ♣ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 10BASE-T/100BASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multillingual) 88 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (IS08859-7: Greek) 96 Page 17 (PC866: Cyrillic #2) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latinz) 101 Page 20 (KU42: Thai) 102 Page 21 (IS11: Thai)		
Cleaning the Thermal Head .75 ▶ Preparing for Transport .77 Appendix .79 ■ Specifications of Interfaces and Connectors .79 RS-232 Serial Interface .79 10BASE-T/100BASE-TX Ethernet Interface .83 USB (Universal Serial Bus) Interface .85 ■ Character Code Tables .86 Common to All Pages .86 Page 0 (PC437: USA, Standard Europe) .87 Page 1 (Katokana) .88 Page 2 (PC850: Multillingual) .89 Page 3 (PC860: Portuguese) .90 Page 4 (PC863: Canadian-French) .91 Page 5 (PC866: Nordic) .92 Page 11 (PC851: Greek) .93 Page 12 (PC853: Turkish) .94 Page 13 (PC857: Turkish) .94 Page 15 (ISO8859-7: Greek) .96 Page 16 (WPC1252) .98 Page 17 (PC866: Cyrillic #2) .99 Page 18 (PC852: Latinz) .10 Page 20 (KU42: Thai) .10 Page 20 (KU42: Thai) .10 Page 20 (ISI18: Thai) .10 Page 30 (TCVN-3: Vietnamese)	-	
■ Preparing for Transport 77 Appendix 79 ■ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 108ASE-T/1008ASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Kafakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (IS08859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 20 (KU42: Thai) 102 Page 20 (KU42: Thai) 103 Page 20 (TS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105		
Appendix 79 RS-232 Serial Interfaces and Connectors 79 RS-232 Serial Interface 79 108ASE-T/1008ASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portruguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (IS08859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 20 (KU42: Thai) 102 Page 21 (IS11: Thai) 103 Page 20 (ICVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 105		
Appendix 79 ■ Specifications of Interfaces and Connectors 79 RS-232 Serial Interface 79 10BASE-T/100BASE-TX Ethernet Interface 83 USB (Universal Serial Bus) Interface 85 ■ Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multillingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (IS08859-7: Greek) 96 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS1: Thai) 102 Page 20 (KIS18: Thai) 103 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106 <	Preparing for Transport	77
■ Specifications of Interfaces and Connectors		
RS-232 Serial Interface	Appendix	79
10BASE-T/100BASE-TX Ethernet Interface. 83 USB (Universal Serial Bus) Interface. 85 ■ Character Code Tables. 86 Common to All Pages. 86 Page 0 (PC437: USA, Standard Europe). 87 Page 1 (Katakana). 88 Page 2 (PC850: Multillingual). 89 Page 3 (PC860: Portuguese). 90 Page 4 (PC863: Canadian-French). 91 Page 5 (PC865: Nordic). 92 Page 11 (PC851: Greek). 93 Page 12 (PC853: Turkish). 94 Page 13 (PC857: Turkish). 95 Page 14 (PC737: Greek). 96 Page 15 (IS08859-7: Greek). 97 Page 16 (WPC1252). 98 Page 17 (PC866: Cyrillic #2). 98 Page 18 (PC852: Latin2). 100 Page 20 (KU42: Thai). 102 Page 20 (KU42: Thai). 102 Page 21 (TIS11: Thai). 103 Page 26 (TIS18: Thai). 104 Page 30 (TCVN-3: Vietnamese). 105 Page 31 (TCVN-3: Vietnamese). 106	Specifications of Interfaces and Connectors	79
10BASE-T/100BASE-TX Ethernet Interface. 83 USB (Universal Serial Bus) Interface. 85 ■ Character Code Tables. 86 Common to All Pages. 86 Page 0 (PC437: USA, Standard Europe). 87 Page 1 (Katakana). 88 Page 2 (PC850: Multillingual). 89 Page 3 (PC860: Portuguese). 90 Page 4 (PC863: Canadian-French). 91 Page 5 (PC865: Nordic). 92 Page 11 (PC851: Greek). 93 Page 12 (PC853: Turkish). 94 Page 13 (PC857: Turkish). 95 Page 14 (PC737: Greek). 96 Page 15 (IS08859-7: Greek). 97 Page 16 (WPC1252). 98 Page 17 (PC866: Cyrillic #2). 98 Page 18 (PC852: Latin2). 100 Page 20 (KU42: Thai). 102 Page 20 (KU42: Thai). 102 Page 21 (TIS11: Thai). 103 Page 26 (TIS18: Thai). 104 Page 30 (TCVN-3: Vietnamese). 105 Page 31 (TCVN-3: Vietnamese). 106	RS-232 Serial Interface	
Character Code Tables 86 Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (IS08859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 20 (KU42: Thai) 102 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Common to All Pages 86 Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	USB (Universal Serial Bus) Interface	85
Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	■ Character Code Tables	86
Page 0 (PC437: USA, Standard Europe) 87 Page 1 (Katakana) 88 Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	Common to All Pages	86
Page 2 (PC850: Multilingual) 89 Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 3 (PC860: Portuguese) 90 Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	Page 1 (Katakana)	88
Page 4 (PC863: Canadian-French) 91 Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	Page 2 (PC850: Multilingual)	89
Page 5 (PC865: Nordic) 92 Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 11 (PC851: Greek) 93 Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 12 (PC853: Turkish) 94 Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 13 (PC857: Turkish) 95 Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 14 (PC737: Greek) 96 Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 15 (ISO8859-7: Greek) 97 Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 16 (WPC1252) 98 Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 17 (PC866: Cyrillic #2) 99 Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	· · · · · · · · · · · · · · · · · · ·	
Page 18 (PC852: Latin2) 100 Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106	g ,	
Page 19 (PC858: Euro) 101 Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 20 (KU42: Thai) 102 Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 21 (TIS11: Thai) 103 Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 26 (TIS18: Thai) 104 Page 30 (TCVN-3: Vietnamese) 105 Page 31 (TCVN-3: Vietnamese) 106		
Page 30 (TCVN-3: Vietnamese)		
Page 31 (TCVN-3: Vietnamese)		
- · · · · · · · · · · · · · · · · · · ·		

Page 33 (WPC775: Baltic Rim)	108
Page 33 (WPC775: Baltic Rim)	109
Page 35 (PC861: Icelandic)	
Page 36 (PC862: Hebrew)	
Page 37 (PC864: Arabic)	
Page 38 (PC869: Greek)	
Page 39 (ISO8859-2: Latin2)	
Page 40 (ISO8859-15: Latin9)	
Page 41 (PC1098: Farsi)	
Page 42 (PC1118: Lithuanian)	
Page 43 (PC1119: Lithuanian)	
Page 44 (PC1125: Ukrainian)	
Page 45 (WPC1250: Latin 2)	
Page 46 (WPC1251: Cyrillic)	
Page 47 (WPC1253: Greek)	
Page 48 (WPC1254: Turkish)	
Page 49 (WPC1255: Hebrew)	124
Page 50 (WPC1256: Arabic)	125
Page 51 (WPC1257: Baltic Rim)	126
Page 52 (WPC1258: Vietnamese)	127
Page 53 (KZ1048: Kazakhstan)	128
Page 255 (User-Defined Page)	129
International Character Sets	130

Product Overview

This chapter describes features and specifications of the product.

Features

The TM-L500A is a high-speed compact printer suited for issuing boarding passes and baggage tags.

The features are as follows:

Printing

- High speed printing: Max. 250 mm/s {9.84"/s}
- Selection of 3 paper widths 54.0 mm {2.13"}, 79.5 mm {3.13"}, and 82.5 mm {3.24"}. 50.8 mm {2.00"} is also available for the ESC/POS mode.
- Auto printing position adjustment

Handling

- Compact body for flexible installation locations
- High-speed autocutter
- Optional paper supply devices
- BP (Boarding Pass) tray is supplied as a factory option.

Software

- Command protocol based on the AEA2009 and ESC/POS Proprietary Command System
- Windows printer driver
- Bar code and two-dimensional symbol printing is possible.
- Maintenance counter

Environment

ENERGY STAR qualified.

Product Configurations

LCD (Liquid Crystal Display)

- Model with LCD
- Model without LCD

NOTE

The ESC/POS mode is available for the models without LCD only.

BP (Boarding Pass)-Tray

- Model with BP-Tray
- Model without BP-Tray

NOTE

Up to 20 autocut boarding passes can be stored in the BP tray.

Corner R (Round) Detection

- Model with the corner R detection
- Model without the corner R detection

NOTE

- The corner R detection is available only in the AEA mode.
- The corner R detection sensor can detect corner R of only 82.5 mm wide paper.

Interfaces

- Serial (9 Pin D-Sub) UB + USB interface model
- Serial (25 Pin D-Sub) interface model
- Ethernet interface model

Colors

EDG (Epson Dark Gray)

Accessories

Included

- AC adapter (Model: PS-180)
- Cable hook
- User's manual


Options

- Paper supply device (Model: SU-RPL500/RPL500B)
- USB/RS-232C D-sub9 interface board (Model: UB-U500)
- RS-232C D-sub25 interface board (Model: UB-S500)
- Ethernet interface board (Model: UB-E500)



These optional interface boards are only for the TM-L500A. Never use them with other Epson printers. Also, never use other interface boards with the TM-L500A.

Part Names and Functions



Power Switch


Turns the printer on or off. The marks on the switch: ($\ (\): OFF/\ |: ON)$



- Before turning on the printer soon after turning it off, make sure the LEDs on the control
 panel are off.
- Before turning the printer off, it is recommended to send a power-off command to the printer. If you use the power-off sequence, the latest maintenance counter values are saved. (Maintenance counter values are usually saved every two minutes.)
 For detailed information about ESC/POS commands, see the ESC/POS Application Programming Guide.

Control Panel

For a model with LCD



For a model without LCD



Power LED (Green)

- Lights when the power supply is on.
- Goes out when the power supply is turned off, or the printer is in the power-saving mode (sleep 3).

On Line LED (Green)

- Lights when the printer is online.
- Goes out when the printer is offline (For details about offline, see "Offline" on page 17.) or in the power-saving mode (sleep 3).

Error LED (Orange)

- Lights when the paper loading cover or the platen frame is open.
- Flashes when an error occurs. (For details about the flash codes, see "Error Status" on page 19.)
- Goes out during regular operation or the power-saving mode (sleep 3).

Paper LED (Orange)

- Lights when paper is out.
- Goes out when paper is loaded, or the printer is in the power-saving mode (sleep 3).
- Flashes in self-test printing standby state or autoloading standby state.

Unload (1) button

Holding down this button for 1 second or more feeds paper backward until the paper can be removed from the back of the printer.

In the menu mode with a model with LCD, this button switches the menu items and options.

Feed (\downarrow) button (only for the model with LCD)

If you use the label paper or paper with black marks,

- This button feeds paper to the print start position except during a printer error or the power-saving mode.
- This button ejects the paper when the status of the paper out sensor is paper not present and a paper out error has not occurred.

If you use the continuous paper, this button feeds paper continuously except during a printer error or the power-saving mode.

In the menu mode, this button switches the menu items and options.

On/Off Line (Back) button (only for the model with LCD)

This button switches between online and offline.

In the menu mode, this button returns to an upper menu item, or exits the menu mode.

Menu (OK) button (only for the model with LCD)

This button enters the menu mode when the printer is offline.

In the menu mode, this button sets the displayed setting option.



- For the setting items in the menu mode and setting procedures, see "Setting Menu on the LCD" on page 64.
- For information about the power-saving mode, see "Power-Saving Mode" on page 22.

Items displayed on the LCD (only for the model with LCD)


Printer status	Printer sub status	Line 1 of LCD	Line 2 of LCD
Normal condition	Online	(Device mode)	(User ID): On Line
	Offline	(Device mode)	(User ID): Off Line
	Online	Prt Ready	(User ID): On Line
During printer error	Online	(Device mode)	(User ID): On Line
		Error	(Displays causes of printer errors.)
During unrecoverable error	Offline	Unrecoverable error	(Displays causes of unrecoverable errors.)
In menu mode	First layer	(Setting menu)	(Menu name)
	Second layer	((Menu name))	(Options)

NOTE

During a printer error, the causes of the error are displayed in turn every other 2 seconds.

Connectors

All cables are connected to the connector panel on the lower rear of the printer.



• Interface connector: Connects the printer with the host computer interface.

The interface type differs depending on the model. (See

"Interfaces" on page 12.)

• Power supply connector: Connects the power supply unit.



For details on how to connect the interface connector and the power supply connector, see "Connecting the Printer to the Host Computer" on page 52 and "Connecting the Power Supply Unit (PS-180)" on page 55.

Offline

The printer automatically goes offline under the following conditions:

ESC/POS mode

- Between the power is turned on (including the printer reset through the interface) and when the printer is ready to receive data.
- During a self-test
- When the paper loading cover is open.
- When the platen frame is open.
- When the printer stops printing due to a paper-end.
- When the printer stops printing due to a paper jam.
- When an error has occurred.

AEA mode

- Between the power is turned on (including the printer reset through the interface) and when the printer is ready to receive data.
- During a self-test.
- During offline with the On/Off Line button.
- When in menu mode.
- When an unrecoverable error has occurred.

Error Status

When an error occurs, the printer stops operating, the Error LED or Paper LED lights or flashes, and the buzzer beeps (only when the buzzer function is enabled). If the error is a fatal one, the printer goes offline.

Printer Errors

Printing is no longer possible when printer errors occur. They can be recovered easily, as described below.

LCD indication	Error description	Error LED flash code Approx. 320 ms	Recovery measure
High temperature	The temperature of the print head is extremely high.		Recovers automatically when the print head cools.
Autocutter	Autocutting failed.		Open the platen frame, remove the foreign object, and then load the appropriate paper. Or send an error recovery command.
Check paper	No black mark/hole was found.	Approx. 5120 ms Approx. 3200 ms	Remove the paper in the paper path, and then load the appropriate paper.
Check paper	Paper out sensor is in the status of paper not present.	The Error LED goes out. The Paper LED lights.	Remove the paper in the paper path, and then load the appropriate paper.
Cover opened	Platen frame is open. (including while printing)	The Error LED lights.	Remove the paper in the paper path, close the platen frame, and then load the appropriate paper.
Cover opened	Paper loading cover is open.		Close the paper loading cover.

LCD indication	Error description	Error LED flash code Approx. 320 ms	Recovery measure
Paper JAM	Paper jam sensor has detected a paper jam.		Remove the paper wrapped around the platen, and then load the appropriate paper.

CAUTION

- When an Autocutter error occurs, do not turn the printer power off. If the printer power is turned off, in case of autocutter error, the print starting position of the first sheet immediately after the printer power is turned on is placed on the wrong position.
- The models with the corner R detection do not detect a paper jam.

Unrecoverable Errors

Printing is no longer possible when fatal errors occur. The printer must be repaired.



Turn off the power immediately when a fatal error occurs.

LCD indication	Error description	Error LED flash code Approx. 4800 ms Approx. 320 ms
R/W error in memory	After R/W checking, the printer does not work correctly.	
High voltage error	The power supply voltage is extremely high.	
Low voltage error	The power supply voltage is extremely low.	
CPU execution error	The CPU executes an incorrect address.	
Internal circuit connection error	The connection of internal circuit is not correct.	

Data Receive Error (Only with the Serial Interface Models)

If any of the following errors occurs during serial interface communication, the printer prints "?" or ignores the data.

- Parity error
- Framing error
- Overrun error

Power-Saving Mode

The TM-L500A has the power-saving mode function to reduce the power consumption. There are 3 statuses, sleeps 1, 2, and 3 in the power-saving mode.

NOTE

For the power consumption during standby in each sleep mode, see "Electrical Characteristics" on page 35.

Sleep 1 & Sleep 2

You can set the statuses, Sleeps 1 & 2 to any of the 3 patterns in the table below with the memory switch.

- Sleep 1: The printer enters this mode 10 seconds after entering standby status.
- Sleep 2: The printer enters this mode 5 minutes after entering standby status.

In the default setting (Pattern 1) of the model with LCD, if the printer does not operate for 10 seconds, the LEDs and the backlight of the LCD become dim, and for 5 minutes, the backlight of the LCD is turned off. They come back on when the printer operates.

Patterns for sleep 1 and sleep2	Status	LEDs brightness	LCD backlight brightness (only for the model with LCD)
No power saving	_	Bright	Bright (initial setting*1)
Pattern 1 (initial setting)	Normal	Bright	Bright (initial setting*1)
	Sleep 1	Dim	Dim* ²
	Sleep 2	Dim	Off
Pattern 2	Normal	Bright	Bright (initial setting*1)
	Sleep 1	Dim	Dim* ²
Pattern 3	Normal	Bright	Bright (initial setting*1)
	Sleep 1	Bright	Dim* ²
	Sleep 2	Bright	Dim* ²

^{*1:} Selectable from Bright, Dim, and Off with the control panel or the memory switch.

*2: If the LCD brightness during the normal status is set to Off, the LCD does not become dim.



- Standby status is a status when no processing is being performed for printing or communication, and the cover is closed.
- · When printing data is received, it is printed immediately.
- For details on how to set the memory switch, see "Setting the Memory Switches" on page 57.

Sleep 3

When Sleep 3 is enabled with the memory switch, the printer enters this mode 4 hours after entering standby status.

During Sleep 3, the LEDs and the backlight of the LCD are off, and no operation is available.

The printer recovers to the normal status when you perform any of the following;

- Push one of the panel buttons.
- Open the paper loading cover.
- Turn the printer power off, and turn it back on. (Turn the printer power on after 3 seconds or more have passed.)

NV Memory (Non-Volatile Memory)

The printer's NV memory stores data even after the printer power is turned off. NV memory contains the following memory areas for the user:

- · Memory switches
- Maintenance counter



As a guide when you program applications, NV memory should be rewritten 10 or fewer times a day.

Memory Switches

With the memory switches, which are software switches for the printer, you can configure various settings of the printer.

For information about the memory switches see "Setting the Memory Switches" on page 57.

Maintenance Counter

With this function, printer information, such as the number of lines printed, the number of MICR readings, the number of autocuts, and printer operation time after the printer starts working, is automatically stored in NV memory. You can read or reset the information with the TM-L500A Utility, the Status API of the APD, or OPOS ADK to use it for periodical checks or part replacement.

Product Specifications

Printing method		Thermal line printing
Dot density		203 dpi × 203 dpi
Printing direction		Unidirectional with friction feed
Paper width		50.8 mm {2.00"} (only for ESC/POS mode), 54.0 mm {2.13"}(default), 79.5 mm {3.13"}, 82.5 mm {3.24"}
Number of characters	ESC/POS mode	Alphanumeric characters: 95 Extended graphics: 128 × 43 pages International characters: 18 character sets
	AEA mode	Alphanumeric characters: 95 Extended graphics: 128 × 30 pages International characters: 16 character sets
Character structure	ESC/POS mode	Font A: 12 × 24 (including horizontal 2-dot spacing) Font B: 9 × 17 (including horizontal 2-dot spacing)
	AEA mode	PECTAB: 5 cpi, 10 cpi, 17 cpi TEMPLATE: Arbitrary width (cpi)
Cutting type		Full cut
Interfaces		Serial (RS-232), USB (2.0 Full-speed), Ethernet (10BASE-T/100BASE-TX)
Receive buffer		4 KB
Bar code/ two-dimensional symbol printing	ESC/POS mode	 Two-dimensional symbols (PDF417, QR code, MaxiCode, GS1-DataBar) Bar codes (UPC-A, UPC-E, EAN 13, EAN 8, Code 39, Inter-leaved 2 of 5, CODABAR, Code 128, GS1-128, GS1-DataBar) CompositSymbology
	AEA mode	 Two-dimensional symbols (PDF417, QR code, Aztec, Data-matrix) Bar codes (Interleaved 2 of 5, Industrial 2 of 5, Code 39, Code 128, EAN 13)
Power supply		Epson PS-180 (Model: M159B)
Overall dimensions (H × W × D)	Model without LCD	Model w/o BP-Tray: 122 × 156 × 230 mm {4.80 × 6.14 × 9.06"}
		Model with BP-Tray: 147 × 156 × 328 mm {5.79 × 6.14 × 12.91"}
	Model with LCD	Model w/o BP-Tray: 148 × 156 × 236 mm {5.83 × 6.14 × 9.29"} Model with BP-Tray: 148 × 156 × 328 mm {5.83 × 6.14 × 12.91"}
Weight (mass)		Approx. 2.8 kg {6.17 lb}
vvoigi ii (iiiuss)		7,46107, 2.0 kg (0.17 lb)

dpi: dots per inch cpi: characters per inch

Printing Specifications

Printing method	d	Thermal line printing
Dot density		203 dpi × 203 dpi
Printing direction	on	Unidirectional with friction feed
Paper width	ESC/POS mode	50.8 mm {2.00"}, 54.0 mm {2.13"}(default), 79.5 mm {3.13"}, 82.5 mm {3.24"}
	AEA mode	54.0 mm {2.13"}(default), 79.5 mm {3.13"}, 82.5 mm {3.24"}
Printing width	50.8 mm printing (only for ESC/POS mode)	48.0 mm {1.89"}, 384 dots
	54.0 mm printing	ESC/POS mode: 51.0 mm (2.01"), 408 dots AEA mode: 50.8 mm (2.00"), 407 dots
	79.5 mm printing	77.0 mm (3.03"), 616 dots
	82.5 mm printing	80.0 mm (3.15"), 640 dots

Maximum printing speed

Text printing	Media type 1, 2, 3 (Roll or fanfold paper)	153 mm/s {6.02"/s}
(boarding pass)	Media type 4 (Roll paper diameter: 184.0 mm or less)	200 mm/s {7.87"/s}
	Media type 4 (Roll paper diameter: 152.4 mm or less)	250 mm/s {9.84"/s}
Text printing (baggage tag)	Roll paper	200 mm/s {7.87"/s}
Bar code/2-dimension	al symbol printing	126 mm/s {4.96"/s}

Note: The printing speeds listed above are the values when the printer prints with the standard print density level at 24V and 25° C $\{77^{\circ}F\}$.



- When changing the paper width, you need to remove or move the paper guides. To change the paper width, see "Changing the Paper Width" on page 44.
- Because some parts of the print head contact the platen and they may become worn out in narrower paper width printing, once you use the printer in narrower paper width printing, you cannot change it back to wider one.



- Printing speed can be changed with the memory switch. (See "Setting the Memory Switches" on page 57.)
- Printing speed may be slower, depending on such items as the data transmission speed.

Paper Specifications



- Paper must not be pasted to the roll paper spool.
- If preprinted thermal paper is used, sticking (a problem of the thermal head sticking to the surface of the thermal paper during printing) may occur, causing faulty printing and other problems. Preprinting may also cause drop in the print density.

Boarding pass

Complies with IATA RESOLUTION722c, 722e

Туре	Thermal paper
Form	Fanfold paper, Roll paper (The chromogenic side must face outside.)
Width	79.5 mm \pm 0.5 mm $\{3.13" \pm 0.02"\}$, 82.5 mm \pm 0.5 mm $\{3.25" \pm 0.02"\}$
Length	203.2 mm {8.00"}, 187.3 mm {7.37"}
Length detection	Optical-sensing hole detection, Black mark detection (Roll paper without holes or black marks is also supported.) Corner round detection*
Thickness	75 to 200 µm
Roll paper diameter	184.2 mm {7.25"} maximum
Roll paper inside core	76.2 mm {3.00"}, 25.4 mm {1.00"}

^{*:} Only for the models with the corner R detection.



- Reflection rate of black marks must be 10% or less, and that of the areas without black marks must be 75% or more.
- Carefully design the print layout so that the print area is away from the perforated line.
- The corner R detection sensor can detect corner R of only 82.5 mm wide paper.

Baggage tag

Complies with IATA RESOLUTION740

Туре	Thermal paper			
Form	Roll paper (The chromogenic side must face outside.)			
Width	54.0 mm ± 0.5 mm {2.13" ± 0.02"}			
Length	400 to 600 mm {15.75" to 23.62"}			
Length detection	Optical-sensing (hole detection/backing paper (liner) detection)			
Thickness	220 µm or less (including backing paper)			
Roll paper diameter	184.2 mm {7.25"} maximum			
Roll paper inside core	76.2 mm {3.00"}			

CAUTION

- Take careful consideration in the print layout so that no printing is done on the backing paper or outer edge.
- Do not preprint (black marks or the equivalent print) in the joint between two backing papers.
- The transmission rate must be 57% or more for the backing paper, and 18% or less for the backing paper + label paper.
- The joint within a baggage tag must be 1 mm {0.039"} or less.
- The hole size must be 1.6 to 6 mm {0.06 to 0.24"}.
- The gap between labels must be 3.2 to 6 mm {0.13 to 0.24"}.

2" paper (only for ESC/POS mode)

Туре	Thermal paper
Form	Fanfold paper, Roll paper (The chromogenic side must face outside.)
Width	50.8 mm ± 0.5 mm {2.00" ± 0.02"}
Length	Fanfold paper: Minimum 40 mm {1.57"} Roll paper: Minimum 30 mm {1.18"}
Length detection	Optical-sensing hole detection, Black mark detection
Thickness	75 to 220 µm
Roll paper diameter	184.2 mm {7.25"} maximum
Roll paper inside core	76.2 mm {3.00"}, 25.4 mm {1.00"}



- Carefully design the print layout so that the print area is within paper and away from the outer edges and perforated lines.
- The hole size must be 1.6 to 6 mm {0.063 to 0.24"}

Specified Original Paper Types

For good print quality, set the media type, print density, and print speed, depending on the original paper number, as shown in the tables below. They can be changed with the memory switch. For information about the memory switches see "Setting the Memory Switches" on page 57.

Boarding pass and 2" paper


	Manufacturer		Recommended			
		Media type	Print	Print speed (mm/s)		
Specified origi- nal paper types			density	Fanfold	Roll paper	
					Diameter: 152.4 mm or less	Diameter: 184.0 mm or less
Resiste 400-7.0	Appleton	Туре 2	04	150	150	150
Resiste 400-5.3	Appleton	Type 2	01	150	150	150
Resiste 800-5.3	Appleton	Type 2	01	150	150	150
Resiste 800-4.5	Appleton	Type 1	03	150	150	150
Resiste 500-7.6	Appleton	Type 1	05	150	150	150
P354	Kanzaki Specialty Papers	Type 1	01	150	150	150
ST-5	Kanzaki Specialty Papers	Type 2	04	150	150	150
KT-300	Kanzaki Specialty Papers	Type 2	01	150	150	150
TF1767	Mitsubisi HiTec	Type 2	03	150	150	150
T1733	Mitsubisi HiTec	Type 2	03	150	150	150
KL615 s B+	Kanzan	Type 1	01	150	150	150
TF11KS-ET	NIPPON PAPER INDUSTRIES	Type 4	07	250	250	200
PD160R	OJI PAPER MFG	Туре 4	07	250	250	200

Baggage tag and 2" paper


	Manufacturer	Media type	Recommended		
Specified original paper types			Print	Print speed	
			density	AEA	ESC/POS (mm/s)
PolyTherm 300-3.0	Appleton	Туре 3	02	High	200
PolyTherm 300-4.1	Appleton	Туре 3	01	High	200
PolyTherm 500-4.1	Appleton	Type 2	02	High	200
Resiste 190-3.2	Appleton	Туре 3	05	High	200
KPT 3370	Kanzaki Specialty Papers	Type 2	04	High	200
KPT 33100	Kanzaki Specialty Papers	Туре 3	04	High	200
KLS46	Kanzan	Туре 3	01	High	200
AL60KT-S	Jujo Thermal Oy	Type 1	06	High	200
140LES	RICOH	Type 2	05	High	200
150LCS-B	RICOH	Туре 2	05	High	200

Printable Area


50.8 mm paper width printing (ESC/POS mode)




54.0 mm paper width printing (ESC/POS mode)




54.0 mm paper width printing (AEA mode)




79.5 mm paper width printing



82.5 mm paper width printing



Printing and Cutting Positions




The numeric values are typical values.

CAUTION

The values above may vary slightly as a result of paper slack or variations in the paper. Take this into account when setting the cutting position of the autocutter.

Black Marks

Black marks are detected on the far left of the back of the paper (non-thermal face).




CAUTION

Reflection rate of black marks must be 10% or less, and that of the areas without black marks must be 75% or more. (Measured with Macbeth density meter PCMII (filter D).)

Corner R Detection (Only for Models with Corner R Detection)


Shape and quality of corner R should be compliant with IATA RESOLUTION 722e.



Electrical Characteristics



Be sure to use the power supply that came with your printer.




Power	115V/60Hz	Serial I/F	No power-saving (normal)	1.26W
consumption during standby (at 23°C {73.4°F}, normal print density)			Sleep 1	1.00W
			Sleep 2	0.61W
			Sleep 3	0.33W
donony			Power off	0.32W
		USB I/F	No power-saving (normal)	1.21W
			Sleep 1	0.94W
			Sleep 2	0.56W
			Sleep 3	0.34W
			Power off	0.32W
		Ethernet I/F	No power-saving (normal)	3.20W
			Sleep 1	2.94W
			Sleep 2	2.59W
			Sleep 3	0.35W
			Power off	0.32W
	230V/50Hz	Serial I/F	No power-saving (normal)	1.38W
			Sleep 1	1.12W
			Sleep 2	0.73W
			Sleep 3	0.44W
			Power off	0.43W
		USB I/F	No power-saving (normal)	1.33W
			Sleep 1	1.06W
			Sleep 2	0.67W
			Sleep 3	0.45W
			Power off	0.43W
		Ethernet I/F	No power-saving (normal)	3.36W
			Sleep 1	3.09W
			Sleep 2	2.73W
			Sleep 3	0.46W
			Power off	0.43W



If printing is continuously performed with a high ratio, the overcurrent protection may be activated and result in uneven print density or a low voltage error. Therefore, the printing length must not exceed the following values when printing with high print ratio.

Print width: Number of dots being energized per one dot line



Reliability

Life	Printer Paper feeding of 100 km or 5 years, which comes first	
	Print head	300,000 boarding passes, 100,000 baggage tags
	Autocutter	100,000 cuts (autocutting of perforated area of thick paper)
MTBF		360,000 hours


Environmental Conditions


Temperature/	Operating	5 to 45°C {41 to 113°F}, 10 to 80% RH		
Humidity Storage		-20 to 50°C {-4 to 122°F}, 10 to 90% RH (except for paper)		
		(%RH) 90 34°C {93.2°F}, 80% 1:p		
Acoustic noise	(operating)	Approximately 57 dB (bystander position) (including autocutting operation) Note: The values above are measured in the Epson evaluation condition. Acoustic noise differs depending on the paper used, printing contents, and the setting values, such as print speed or print density.		

External Dimensions and Mass

Model without LCD and BP-Tray


- Height: Approximately 122 mm {4.80"}
- Width: Approximately 156 mm {6.14"}
- Depth: Approximately 230 mm {9.06"}
- Mass: Approximately 2.8 kg {6.17 lb}






Model with LCD and BP-Tray

- Height: Approximately 148 mm {5.83"}
- Width: Approximately 156 mm {6.14"}
- Depth: Approximately 328 mm {12.91"}
- Mass: Approximately 2.8 kg {6.17 lb}



Power Supply Unit (PS-180)



Electric	Input conditions	Input voltage: AC100V to AC240V
characteristics		Frequency: 50-60 Hz
		Input current (rating): 1.3A
	Output conditions	Output voltage (rating): DC24V ± 5%
		Output current (rating): 2.1A
Case specifications	Dimensions	68 × 136 × 33 mm {2.68 × 5.35 × 1.30"}
	$(H \times W \times D)$	(excluding projections)
	Weight	Approx. 0.4 kg {14.11 oz} (excluding the AC cable)
	Color	Black (matte)

CAUTION

For Energy Star printers, always use the power supply that came with your printer.

NOTE


For detailed information about the PS-180, see the instruction manual for the PS-180.

Setup

This chapter describes setup and installation of the product and peripherals.

Flow of Setup

This chapter consists of the following sections, along with the setup flow of the product and peripherals.



Installing the Printer

Important Notes

- The printer must be installed horizontally on a flat surface (not tilted).
- Do not place the printer in dusty locations.
- Do not knock or strike the printer. This may cause printing errors.
- Do not place any liquids or drinks on the printer case.

Changing the Paper Width

The printer is initially set to print on 54.0 mm width paper, but you can change the printer to print on 82.5 mm, 79.5 mm, or 50.8 mm width paper by removing or moving the paper guides installed in the printer.


CAUTION

- Because some parts of the print head contact the platen and they may become worn out in narrower paper width printing, once you use the printer in narrower paper width printing, you cannot change it back to wider one.
- When changing the paper width, be sure to change the setting for the paper width with the customized value. To set the customized value, see "Setting the Memory Switches" on page 57.
- 50.8 mm width paper printing is supported by only the ESC/POS mode.

To change the paper width to 82.5 mm, remove the paper guide installed in groove **b**. (See page 45.)

To change the paper width to 79.5 mm, remove the paper guides installed in grooves **b** and **d**, and install one of them in groove **c**. (See page 46.)


To change the paper width to 50.8 mm, remove the paper guide installed in groove **b**, and install it in groove **a**. (See page 47.)




Setting the Paper Width to 82.5 mm

Follow the steps below to set the paper width to 82.5 mm.

- ◀ Make sure the printer is turned off.
- Open the paper loading cover by pulling up the cover open lever.




Remove the screw fixing the paper guide installed in groove **b** to remove the paper guide.




Setting the Paper Width to 79.5 mm

Follow the steps below to set the paper width to 79.5 mm.

- Make sure the printer is turned off.
- Open the paper loading cover by pulling up the cover open lever.



Remove the screws fixing the paper guides installed in grooves **b** and **d** to remove the paper guides.




- 4 Install one of the removed paper guides in the groove **c** so that the projections of the paper guide are aligned with the holes along the groove.
- **5** Fix the paper guide with the screw.


Setting the Paper Width to 50.8 mm (Only for ESC/POS mode)

Follow the steps below to set the paper width to 50.8 mm. This paper width is available only in the ESC/POS mode.

- ◀ Make sure the printer is turned off.
- 2 Open the paper loading cover by pulling up the cover open lever.



3 Remove the screw fixing the paper guide installed in grooves **b** to remove the paper guide.



- Install the removed paper guide in the groove **a** so that the projection of the paper guide is aligned with the hole along the groove.
- **5** Fix the paper guide with the screw.

Setting the DIP Switches

On this printer, you can make various settings with DIP switches.

Functions of the DIP switches differ depending on the interface.

Setting Procedure

Follow the steps below to change the DIP switch settings.




Before you remove the DIP switch cover, turn the printer off.

Otherwise, a short-circuit may cause the printer to malfunction.

CAUTION

DIP switch settings are enabled only when the power is turned on or the printer is reset via the interface. If the settings are changed after that, the functions will not change.


- Make sure the power supply for the printer is turned off.
- Remove the screw that secures the left case.
- 3 Slide the left case to the rear to release the groove and two hooks of the left case, and remove the left case.



- Set the DIP switches, using the tip of a tool, such as a small screwdriver.
- Install the left case and secure it with the screw.

 Align the groove on top of the left case with the rib of the upper case.

 Align the two hooks of the left case with the two holes of the board plate and slide it to the front.



For Serial Interface

sw	Function	ON	OFF	Initial setting
1	Reserved (Do not change)	Fixed	to ON	ON
2	Printer mode	ESC/POS commands	AEA commands	OFF
3	Transmission speed selections	See the "Transmission S	See the "Transmission Speed (DIP Switches 3/	
4	11a1 131 11331011 3peca 3ciection 13	4)" table below.		ON
5	DSR (hardware) reset	Enabled	Disabled	OFF
6	Reserved (Do not change)	Fixed to OFF		OFF
7	Reserved (Do not change)	Fixed to OFF		OFF
8	Reserved (Do not change)	Fixed -	to OFF	OFF

Transmission Speed (DIP Switches 3/4)

Transmission speed (bps)	SW 3	SW 4
Setting with the memory switch*: 2400, 4800, 9600, 19200 (initial setting), 38400, 57600, 115200	ON	ON
9600	OFF	ON
19200	ON	OFF
38400	OFF	OFF

bps: bits per second

* When DIP switches 3 and 4 are set to ON, the value (initially 19200) can be set to any of the values listed in the lower portion of the row using a command, memory switch setting mode, or the TM-L500A Utility. (See "Setting the Memory Switches" on page 57.)



Depending on print conditions, such as print duty, print head temperature, and data transmission speed, print speed is automatically adjusted, which can cause white lines due to intermittent print (the motor sometimes stops). To avoid this, set the transmission speed higher or keep the print speed constant by setting it lower. (See "Setting the Memory Switches" on page 57.)

For USB Interface

sw	Function	ON	OFF	Initial setting
1	Reserved (Do not change)	Fixed	to ON	ON
2	Printer mode	ESC/POS commands	AEA commands	OFF
3	Reserved (Do not change)	Fixed	to ON	ON
4	Reserved (Do not change)	Fixed to ON		ON
5	Reserved (Do not change)	Fixed to OFF		OFF
6	Reserved (Do not change)	Fixed to OFF		OFF
7	USB interface class	Printer class	Vendor class	OFF
8	Reserved (Do not change)	Fixed to OFF		OFF

For Ethernet Interface

sw	Function	ON	OFF	Initial setting
1	Reserved (Do not change)	Fixed	to ON	ON
2	Printer mode	ESC/POS commands	AEA commands	OFF
3	Reserved (Do not change)	Fixed to ON		ON
4	Reserved (Do not change)	Fixed to ON		ON
5	Reserved (Do not change)	Fixed to OFF		OFF
6	Reserved (Do not change)	Fixed to OFF		OFF
7	Reserved (Do not change)	Fixed to OFF		OFF
8	Reserved (Do not change)	Fixed to OFF		OFF

Connecting the Printer to the Host Computer

For Serial Interface

Connect the printer to a host computer by a serial interface (RS-232) cable.




Be sure to turn off the power supply for both the printer and host computer before connecting the cables.


NOTE

Use a null modem serial cable to connect the printer.

- Insert the interface cable connector firmly into the interface connector on the connector panel.
- 2 When using connectors equipped with screws, tighten the screws to secure the connectors firmly.




- When using interface cables equipped with a grounding line, attach the ground line to the screw hole marked "FG" on the printer.
- Connect the other end of the interface cable to the host computer.



For USB Interface

Connect the printer to a host computer by a USB interface cable.

✓ Install the cable hook.




Put the USB cable through the cable hook.

CAUTION

Putting the USB cable through the cable hook prevents the cable from coming unplugged.

- 3 Connect the USB cable from the host computer to the USB upstream connector.
- ▲ Connect the other end of the interface cable to the host computer.



For Ethernet Interface

Connect the printer to a network by a LAN cable via a hub.



 When LAN cables are installed outdoors, make sure devices without proper surge protection are cushioned by being connected through devices that do have surge protection.

Otherwise, the devices can be damaged by lightning.

 Never attempt to connect the customer display cable, drawer kick-out cable, or a standard telephone line cable to the 10/100BASE-T LAN connector.



For Ethernet interface communication settings, use TM-L500A Utility or EPSON TMNet WinConfig utility. For detailed information about the setting methods, see the TM-L500A Utility User's Manual or EPSON TM Net WinConfig User's Guide.

Connect a 10/100BASE-T cable to the 10/100BASE-T LAN connector by pressing firmly until the connector clicks into place.


Connecting the Power Supply Unit (PS-180)

Use the PS-180 as the power supply unit.

Before using the power supply unit, read carefully the user's manual enclosed with it.




- Always use the EPSON PS-180 as the power supply unit.
 Using a nonstandard power supply can result in electric shock and fire.
- Should a fault ever occur in the EPSON PS-180, immediately turn off the power to the printer and unplug the power supply cable from the wall socket.




Connecting the Power Supply Unit

- 1 Make sure the printer's power supply is turned off and the AC cable has been unplugged from the wall socket.
- 2 Insert the connector of the DC cable onto the power supply connector.



Connect the plug of the AC cable to the wall socket.





 Be sure to unplug the AC cable from the wall socket whenever connecting or disconnecting the power supply unit to the printer.

Failure to do so may result in damage to the power supply unit or the printer.

Make sure the wall socket power supply satisfies the rated voltage requirements
of the power supply unit. Never insert the power supply cable plug into a socket
that does not meet the rated voltage requirements of the power supply unit.

Doing so may result in damage to both the power supply and the printer.

Setting the Memory Switches

With the memory switch function, which is software setting for this printer, you can set the various functions.

For an outline of the functions, see the following section. Use TM-L500A Utility, ESC/POS commands, or AEA commands to set the memory switches.



- For detailed information about the TM-L500A Utility, see the TM-L500A Utility User's Manual.
- For detailed information about ESC/POS commands, see the ESC/POS Application Programming Guide.
- For detailed information about AEA commands, see the AEA2009.

	Settings\Setting Methods		TM-L500A Utility		ESC/POS	AEA
			ESC/POS mode	AEA mode	Commands	Commands
	BU	ISY condition	~	~	~	
	Do	ata receive error	~	~	~	~
	Αι	utomatic line spacing	~	v	~	~
	Pa	per jam detection	~	v	~	~
	US	B power saving	~	<i>V</i>	~	~
	AE	A device mode		<i>V</i>		~
	Se	rial DSR software reset		<i>V</i>		~
S		Default character code table	V	~	~	~
Memory Switches		Default international character font	~	~	~	~
' Swi		Transition pattern for power saving	~	~	~	~
nor		Sleep 3	~	~	~	~
Me	lues	Adjustment of TOF-cut position	~	~	~	~
	Customized Values	Paper width			~	
	nize	Print density			~	~
	ıstor	Print speed	~	~	~	~
	ŭ	Maximum amount of paper fed from when paper is inserted until a mark is detected	V		~	
		Mark type	V	~	~	
		Media type			~	~

		User/Context mode	~	~	~	~
	ctions	Buzzer volume	V	V	V	~
S	Func	LCD backlight brightness*	-	V	-	~
itche	Inique F	LCD contrast*	-	V	-	~
Memory Switches	_	AEA error judgement for wrong coupon type	-	V	-	~
Men	Model's	Font compatible mode	-	V	1	~
		Truncate function	-	V	-	~
	_	ansmission conditions for serial erface	V	V	V	~

^{*:} Only for the model with LCD

Functions

BUSY condition

CAUTION

When you use AEA commands, be sure not to change the initial setting.

- Receive buffer full (initial setting)
- Receive buffer full or printer offline

Data receive error

- Ignored
- Receive error (initial setting)

Automatic line spacing

- Always enabled
- Always disabled (initial setting)

Paper jam detection

- Disabled
- Enabled (initial setting)



Setting of paper jam detection is invalid for the model with corner R detection.

USB power saving

- Disabled
- Enabled (initial setting)

AEA device mode

- Baggage Tag mode (initial setting)
- Boarding Pass mode

Serial DSR software reset

- Resets (initial setting)
- Does not reset

Default character code table

ESC/POS commands: Selectable from 43 pages (initial setting: PC437 USA, Standard Europe) AEA commands: Selectable from 30 pages (initial setting: PC437 USA, Standard Europe)



The pages for ESC/POS commands consist of Bitmap fonts while the pages for AEA commands consist of scalable fonts.

Default international character font

ESC/POS mode: Selectable from 18 types (initial setting: USA)

AEA mode: Selectable from 16 types (initial setting: USA)



The types for ESC/POS commands consist of Bitmap fonts while the types for AEA commands consist of scalable fonts.

Transition pattern for power saving

- No power saving
- Pattern 1 (initial setting)
- Pattern 2
- Pattern 3

Sleep 3




For good print quality, set the media type, depending on the original paper number (See "Paper Specifications" on page 27.).

- Enabled
- Disabled (initial setting)

Adjustment of TOF-cut position

Selectable from -8 mm to 8 mm (The initial setting differs depending on the model.)



Paper width

- 50.8 mm (only for ESC/POS mode)
- 54.0 mm (initial setting)
- 79.5 mm
- 82.5 mm



When changing the paper width, you need to remove or move the paper guide. To change the paper width, see "Changing the Paper Width" on page 44.

Print density

Selectable from levels 1 to 9 (70% ~ 110%) (initial setting: level 7)



- If the print density is set to a darker level, printing speed may be reduced.
- If the print density is set to a darker level, paper dust accumulates on the print head and print may be faint. For information on how to clean the thermal head, see "Cleaning the Thermal Head" on page 75.
- For good print quality, set the print density, depending on the original paper number (See "Paper Specifications" on page 27.).

Print speed

Selectable from levels 1 to 10 (Slow ~ Fast) (initial setting: level 6)



- Depending on print conditions, such as print duty, print head temperature, and data transmission speed, print speed is automatically adjusted, which may cause white lines due to intermittent print (the motor sometimes stops). To avoid this, keep the print speed constant by setting it lower, or set the transmission speed higher for the serial interface. (See "Transmission Speed (DIP Switches 3/4)" on page 50.)
- For good print quality, set the print speed, depending on the original paper number (See "Paper Specifications" on page 27.).

Maximum amount of paper fed from when paper is inserted until a mark is detected

- 8" (initial setting)
- 600 mm

Mark type

- Auto detection (initial setting)
- Hole
- Black mark
- No mark

Media type

Selectable from 4 types (initial setting: Type 2)



For good print quality, set the media type, depending on the original paper number (See "Paper Specifications" on page 27.).

User/Context mode

- Single user/Single context (initial setting)
- Single user/Multi context
- Multi user/Multi context

Buzzer volume

Selectable from Off and levels 1 to 5 (initial setting: level 5)

LCD backlight brightness

Selectable from Off, Bright and Dim (initial setting: Bright)

LCD contrast

Selectable from levels 1 to 3 (initial setting: level 3)

AEA error judgement for wrong coupon type

- AEA error
- No AEA error (initial setting)

Font compatible mode

- PECTAB-compliant font
- IER506-compatible font (initial setting)

Truncate function

- Does not truncate
- Truncates (no error) (initial setting)
- Truncates (error)

Transmission conditions for serial interface

Transmission speed

When DIP switches 3 and 4 are set to ON, the value (initially 19200 bps) can be set to 2400, 4800, 9600, 19200, 38400, 57600, or 115200 bps. (See "Transmission Speed (DIP Switches 3/4)" on page 50.)



The transmission speed can be set with DIP switches 3 and 4 (See "Transmission Speed (DIP Switches 3/4)" on page 50.) or the memory switch. When DIP switches 3 and 4 are set to ON, the setting with the memory switch is enabled.

Parity bit

- None (initial setting)
- Odd
- Even

Flow control (Only for AEA mode)

- RTS/CTS control (initial setting)
- DTR/DSR control



In the ESC/POS mode, Flow control is fixed to DTR/DSR + RTS/CTS control.

Setting Menu on the LCD

If your printer is equipped with an LCD, you can set the buzzer volume, LCD contrast, and LCD brightness with the buttons on the control panel.

• Buzzer volume: The buzzer sounds when the printer is in an error status.

You can adjust the volume of the buzzer from OFF to level 5.

• LCD contrast: You can adjust the contrast of the LCD from level 1 to 3.

• LCD brightness: You can select the brightness of the LCD from Bright/Dim/Off.



The buzzer volume, LCD contrast, and LCD brightness can be set also with the customized value. To set the customized value, see "Setting the Memory Switches" on page 57.

Follow the steps below to set menu on the LCD.

- Turn on the printer.
- 2 When "On Line" is displayed on the LCD, press the ON/Off Line (Back) button to put the printer offline.
- Press the Menu (OK) button to display "(Setting menu)" on the LCD.
- Use the Unload (↑) button and Feed (↓) button to display the setting item for which you want to make a setting, and press the Menu (OK) button to select it.
- Use the Unload (\uparrow) button and Feed (\downarrow) button to display the setting options, and press the Menu (OK) button to set it.
- To make another setting, press the On/Off Line (Back) button once to return to the menu selecting screen.

To finish setting, press the On/Off Line (Back) button twice to exit the menu mode.

Application Development Information

This chapter describes how to control the printer and gives information useful for printer application development.

How to Control the Printer

Use a driver, AEA commands, or ESC/POS commands to control the printer.



A model with LCD can be controlled by AEA commands.

EPSON Advanced Printer Driver (APD)

EPSON Advanced Printer Driver is a Windows printer driver for EPSON TM printers. The Status API (Epson original DLL) that monitors printer status and sends ESC/POS commands is also attached to this driver.

For information about the driver operating environment, see the installation manual for APD.



When you use APD, be sure to set the DIP switch for printer mode to enable ESC/POS commands. (See "Setting the DIP Switches" on page 48.)



You can use all functions, including ones not supported by APD, by using ESC/POS commands through your driver. Use the control A command of APD, or Status API to send ESC/POS commands from the driver.

AEA Commands

AEA specifications for Automated Ticket and Boarding Pass equipment (ATB), Parametric Tables (PECTAB), Self Service and Baggage Tag Printers (BTP) related firmware are an industry standard.

See the AEA2009 for more details.



When you use AEA commands, be sure to set the DIP switch to enable AEA commands. (See "Setting the DIP Switches" on page 48.)

ESC/POS Commands

ESC/POS is the Epson original printer command system. With ESC/POS commands, you can directly control all the TM printer functions, but detailed knowledge of printer specifications or combination of commands is required, compared to using a driver.

To use ESC/POS commands, you need to agree to a nondisclosure contract first and obtain the ESC/POS Application Programming Guide. Ask your dealer for details.



When you use ESC/POS commands, be sure to set the DIP switch to enable ESC/POS commands.(See "Setting the DIP Switches" on page 48.)

Software and Manuals

The following software and manuals are provided for application development.

How to Get Drivers, Manuals, and the Utility

You can obtain drivers, manuals, and the TM-L500A Utility from one of the following URLs.

For customers in North America, go to the following web site:

http://www.epsonexpert.com/ and follow the on-screen instructions.

For customers in other countries, go to the following web site:

https://download.epson-biz.com/?service=pos/

Printer Driver

Software	Manual
EPSON Advanced Printer Driver (APD):	APD Install Manual
EPSON Advanced Printer Driver is a Windows printer driver for EPSON TM printers. The Status API (Epson original DLL) that monitors printer status and sends ESC/POS commands is also attached to this driver.	 APD TM/BA/EU Printer Manual APD Printer Specification Devmode API/PRINTERINFO Manual Status API Manual Sample Program Guide

Utilities

Software	Manual
TM-L500A Utility: Use for various settings.	TM-L500A Utility User's Manual
EPSON TM Net WinConfig: Use for IP address or wireless LAN setting.	EPSON TM Net WinConfig User's Guide

Self-Test Mode

In the self-test mode, the printer prints the current status of the printer and resident characters as a test print.

You can confirm the following information with the status print.

- Model name
- Control software version
- Printer settings
- User counter
- Maintenance counter

Starting the Self-Test

Follow the steps below to start the self-test.

- Install the roll paper.
- Close all covers.
- While pressing the Unload (1) button, turn on the printer. (Keep pressing the button until the printer starts printing.)

The printer starts printing the current status of the printer on the paper.



With the Ethernet interface, before printing starts, it takes 15 seconds if the IP address is fixed and 20 seconds if the IP address is obtained with the automatic setting. (It may take longer, depending on the response time from the host.)

When the printer finishes printing the current printer status, the following message is printed and the Paper LED flashes. (The printer is now in the self-test printing standby status.):

"If you want to continue SELF-TEST printing, please press Unload button."

To start the test print, press the Unload (1) button (less than 1 second). The printer prints a rolling pattern on the paper, using only the built-in character set.

NOTE

If you press the Unload (\uparrow) button for more than 1 second, the printer prints the other settings and counter value.

After printing the following message and autocutting the paper, the printer is initialized and returned to the normal mode.

"*** completed***"

Handling

This chapter describes basic handling of the printer.

Usage Precautions

- Install the printer horizontally.
- When installing, leave enough space around the printer for loading paper, turning on/off the power switch, removing jammed paper, and so on.
- Make sure cords and foreign objects are not caught in the printer.
- Do not open the covers during printing or autocutting.
- Make sure that the printer is not subjected to any impact or vibration.
- Do not put any food or drink on the printer case.
- Do not move the printer with the paper loading cover open. The cover may close unexpectedly.
- To prevent a paper jam, do not prevent paper from being ejected from the paper exit and do not pull the paper being ejected.

Installing and Replacing Paper

WARNING

- Do not open the covers during printing/autocutting. The printer may be damaged.
- Do not touch the manual cutter with your hands.

 Otherwise, you may be injured because the manual cutter blade is sharp.


CAUTION

- Use paper that meets the printer specifications. For details about paper specifications, see "Paper Specifications" on page 27.
- When changing the paper width, you need to remove or move the paper guide and to change the setting for the paper width with the customized value. To change the paper width, see "Changing the Paper Width" on page 44.
- To adjust the cutting position, define a character string in the CUTPOS field in the printer environment data for baggage tags and boarding passes. (The adjustable range: -30 to 30)


Installing Paper

When the Paper LED is on, follow the steps below to load paper.

- Turn on the printer.
- Open the paper loading cover by pulling up the cover open lever.



3 Insert the end of the paper under the rollers. The paper is fed automatically.



Close the paper loading cover.
The paper is fed to the position of a punch hole or a black mark, and cut automatically.

CAUTION

Close the paper loading cover immediately. If it is left open for 1 minute or longer, paper feeding may not be correct.

NOTE


For the models with the BP-tray, up to 20 autocut boarding passes can be stored in the BP tray. When you use roll paper, use roll paper with 3" inner core. Curled paper may fall out.

Replacing Paper


Follow the steps below to replace paper.

- Turn on the printer.
- 2 Hold down the Unload (1) button until the paper starts feeding backward.
- 3 After paper feeding stops, remove the paper by pulling it backward.

✓ Open the paper loading cover by pulling up the cover open lever.



Insert the end of the paper under the rollers.
The paper is fed automatically.



6 Close the paper loading cover.

The paper is fed to the position of a punch hole or a black mark, and cut automatically.



Close the paper loading cover immediately. If it is left open for 1 minute or longer, paper feeding may not be correct.



For the models with the BP-tray, up to 20 autocut boarding passes can be stored in the BP tray. When you use roll paper, use roll paper with 3" inner core. Curled paper may fall out.

Removing Jammed Paper


When a paper jam occurs, never pull out the paper forcibly.

Follow the steps below to remove the jammed paper.




Do not touch the thermal head (See"Cleaning the Printer" on page 75.) because it can be very hot after printing.

- Turn off the printer.
- 2 Open the platen cover (or BP-tray for the models with the BP-tray).




3 Push down the platen lever to open the platen frame.



Pull out the jammed paper forward, and cut any distorted, crumpled, or torn parts of the paper.

5 Open the paper loading cover by pulling up the cover open lever.



- 6 Pull out the paper backward, and cut any distorted, crumpled, or torn parts of the paper if there are any.
- **7** Close the platen frame and the platen cover (or BP-tray for the models with the BP-tray).


Cleaning the Printer

Cleaning the Printer Case

Be sure to unplug the AC cable from the wall socket and turn off the printer before cleaning. Wipe the dirt off the printer case with a dry cloth or a damp cloth.

CAUTION

Never clean the product with alcohol, benzine, thinner, or other such solvents. Doing so may damage or break the parts made of plastic and rubber.




Cleaning the Thermal Head

Epson recommends cleaning the thermal head periodically (generally every 3 months) to maintain receipt print quality.




- After printing, the thermal head can be very hot. Do not touch it and let it cool before you clean it.
- Do not damage the thermal head by touching it with your fingers or any hard object.
- 1 Hold down the Unload (1) button until the paper starts feeding backward.
- 2 After paper feeding stops, remove the paper by pulling it backward.
- 3 Turn off the printer.


■ Open the platen cover (or BP-tray for the models with the BP-tray).



5 Push down the platen lever to open the platen frame.



6 Clean the thermal elements of the thermal head with a cotton swab moistened with an alcohol solvent (ethanol or IPA).



7 Close the platen frame and the platen cover (or BP-tray for the models with the BP-tray).

Preparing for Transport

Follow the steps below to transport the printer.

- Turn off the printer.
- Remove the power supply connector.
- Remove the roll paper.
- Pack the printer upright.

Appendix

Specifications of Interfaces and Connectors

RS-232 Serial Interface

Interface board specifications (RS-232-compliant)

ľ	tem	Specifications
Data transfer m	ethod	Serial
Synchronization		Asynchronous
Handshake	ESC/POS mode	DTR/DSR + RTS/CTS control
	AEA mode	Select one of the following with a memory switch: • DTR/DSR • RTS/CTS
Signal level	MARK	-3V to -15V logic "1"/OFF
	SPACE	+3V to +15V logic "0"/ON
Transmission spe (bps: bits per se		 Select one of the following with DIP switches 3 and 4: 9600/19200/38400 bps Select one of the following with a memory switch: 2400/4800/9600/19200/38400/57600/115200 bps
Bit lengths		8 bits
Parity selection		Select one of the following with a memory switch: None Even Odd
Stop bit		1 or more bits However, the stop bit for data transfer from the printer is fixed to 1 bit.
Connector	Printer side	DSUB 9-pin (male) connector, DSUB 25-pin (female) connector

Functions of each connector pin



Receive buffer full:

- When the remaining space in the receive buffer drops to 128 bytes, the printer status becomes "buffer full" and it remains "buffer full" until the space in the receive buffer increases to 256 bytes.
- The printer ignores the data received when the remaining space in the receive buffer is 0 byte.

ESC/POS mode

DSUB9 Pin no.	DSUB25 Pin no.	Signal name	Signal direction	Function
1	_	NC	_	Not connected
2	3	RXD	Input	Receive data
3	2	TXD	Output	Transmit data
4	20	DTR	Output	Indicates whether or not the printer is BUSY. SPACE indicates that the printer is ready to receive data, and MARK indicates that the printer is BUSY. Memory switch 1-3 changes the BUSY condition for the printer.
5	7	GND	_	Signal ground
6	6	DSR	Input	Indicates whether or not the host computer is ready to receive data. SPACE indicates that the host computer is ready to receive data, and MARK indicates that the host computer is not ready to receive data. The printer checks this signal before transmitting data. (Except when transmitting data with some commands.) Changing the setting of DIP switch allows this signal to be used as a reset signal for the printer. The printer is reset when the signal remains MARK for 1 ms or more.
7	4	RTS	Output	Same as DTR signal.
8	5	CTS	Input	Indicates whether or not the host computer is ready to receive data. SPACE indicates that the host computer is ready to receive data, and MARK indicates that the host computer is not ready to receive data. The printer checks this signal before transmitting data. (Except when transmitting data with some commands.)
9	_	NC	_	Not connected

NOTE

The printer goes BUSY (MARK) under the following conditions:

	Printer status	Memory 1	y switch -3
		ON	OFF
	1. During the period from when the power is turned on (including resetting through the interface) to when the printer becomes ready to receive data.	BUSY	BUSY
	2. During a self-test	BUSY	BUSY
Offline	3. When the paper loading cover is open.	_	BUSY
Off	4. When the platen frame is open.	_	BUSY
	5. When the printer stops printing due to a paper-end.	_	BUSY
	6. When the printer stops printing due to a paper jam.	_	BUSY
	7. When an error has occurred.	_	BUSY
8. \	When the receive buffer becomes full.	BUSY	BUSY

AEA mode

DSUB9 Pin no.	DSUB25 Pin no.	Signal name	Signal direction	Function
1	_	NC	_	Not connected
2	3	RXD	Input	Receive data
3	2	TXD	Output	Transmit data
4	20	DTR	Output	<when control="" cts="" flow="" is="" rts="" selected=""> Indicates whether or not the printer power is ON. SPACE indicates that the printer power is ON, and MARK indicates that the printer power is OFF. <when control="" dsr="" dtr="" flow="" is="" selected=""> Indicates whether or not the printer is BUSY. SPACE indicates that the printer is ready to receive data, and MARK indicates that the printer is BUSY. The printer goes BUSY when the printer is made offline by pressing down the On/Off Line button or when the receive buffer is full.</when></when>
5	7	GND	_	Signal ground

DSUB9 Pin no.	DSUB25 Pin no.	Signal name	Signal direction	Function
6	6	DSR	Input	<when control="" cts="" flow="" is="" rts="" selected=""></when>
				Indicates whether or not the host computer power is ON.
				SPACE indicates that the host computer is ON, and MARK indicates that the host computer is OFF.
				Changing the setting of DIP switch or memory switch allows this signal to be used as a reset signal for the printer. This reset signal is used for detecting the MARK status of the host computer and for resetting the printer.
				<when control="" dsr="" dtr="" flow="" is="" selected=""></when>
				Indicates whether or not the host computer is ready to receive data.
				SPACE indicates that the host computer is ready to receive data, and MARK indicates that the host computer is not to ready to receive data.
				When DTR/DSR control is selected, check the status of this signal before transmitting data.
7	4	RTS	Output	<when control="" cts="" flow="" is="" rts="" selected=""></when>
				Indicates whether or not the printer is BUSY.
				SPACE indicates that the printer is ready to receive data, and MARK indicates that the printer is BUSY.
				The printer goes BUSY when the printer is made offline by pressing down the On/Off Line button or when the receive buffer is full.
				<when control="" dsr="" dtr="" flow="" is="" selected=""></when>
				Indicates whether or not the printer power is ON.
				SPACE indicates that the printer power is ON, and MARK indicates that the printer power is OFF.
8	5	CTS	Input	<when control="" cts="" flow="" is="" rts="" selected=""></when>
				Indicates whether or not the host computer is ready to receive data.
				SPACE indicates that the host computer is ready to receive data, and MARK indicates that the host computer is not ready to receive data.
				When RTS/CTS control is selected, check the status of this signal before transmitting data.
				<when control="" dsr="" dtr="" flow="" is="" selected=""></when>
				This signal is not used.
9	_	SG	_	Signal ground
	ı	l .	ı	I .

10BASE-T/100BASE-TX Ethernet Interface

Software specifications

Basic communication protocols

• IP, ARP, ICMP, UDP, TCP: Basic communications protocols for various functions (used by

higher-level protocols below)

Printing communications protocols

• LP, LPR: Transfers printing data.

• TCP socket port: Transfers printing data and printer status with direct socket

communications (bi-directional).

Protocol for obtaining status and setting

• HTTP: Displays module status and makes setting with the Web

browser.

• SNMP: Obtains status and/or sets module or printer with the

dedicated/commercial MIB tool.

• ENPC: Obtains status and/or sets the interface unit and printer.

• TFTP: Updates the interface unit firmware.

Automatic IP Address Assignment Protocols

Automatic IP addressing is executed in order shown in the table below. If DHCP is disabled or IP addressing for DHCP fails, then IP addressing for the next protocols is executed. If APIPA is disabled or IP address cannot be obtained, the internal setting parameters are used.

Protocol	Order	Application
DHCP	1	Obtains IP address.
APIPA	2	Assigns IP address.
Manual setting	3	Uses the internal parameters.

Internal parameter settings

Internal parameter settings can be changed with the following:

- ENPC protocol: Epson provides a dedicated utility that makes miscellaneous setting with the ENPC protocol.
- HTTP browser: An HTTP browser can make setting when connected to the module.
- arp commands and ping commands (Only IP address is settable.):

This function is available only when it has been enabled. The setting can be made only from a host PC that supports both arp and ping commands and is in the same segment as the module.

Autiala	Darware at a sa	Default	Ut	ility	Bro	wser	Status
Article	Parameters	values	View	Setting	View	Setting	sheet print
IP address		192.168.192.168	Yes	Yes	Yes	Yes	Yes
Subnet mask		255.255.255.0	Yes	Yes	Yes	Yes	Yes
Gateway address		0.0.0.0	Yes	Yes	Yes	Yes	Yes
DHCP	Enable/Disable	Disable	Yes	Yes	Yes	Yes	Yes
APIPA	Enable/Disable	Disable	Yes	Yes	Yes	Yes	Yes
Arp/ping IP setting	Enable/Disable	Enable	Yes	Yes	Yes	Yes	No
Community name 1 (read-only)	Max. 16 characters	"public"	Yes	No	Yes	No	Yes
Community name 2 (read-write)	Max. 16 characters	None	Yes	Yes	Yes	Yes	Yes
IP Trap 1 Enable	Enable/Disable	Disable	Yes	Yes	Yes	Yes	No
IP Trap 2 Enable	Enable/Disable	Disable	Yes	Yes	Yes	Yes	No
Community name (IP Trap #1)	Max. 16 characters	None	Yes	Yes	Yes	Yes	No
Community name (IP Trap #2)	Max. 16 characters	None	Yes	Yes	Yes	Yes	No
IP trap #1 address		None	Yes	Yes	Yes	Yes	No
IP trap #2 address		None	Yes	Yes	Yes	Yes	No
Password		None	No	Yes	No	Yes	No
Physical layer Auto negotia setting /10Base-T Hal /10Base-T Full /100Base-TX F /100Base-TX F		Auto negotiation	Yes	Yes	Yes	Yes	Yes
Hardware version	_	_	Yes	No	Yes	No	Yes
Firmware version	_	_	Yes	No	Yes	No	Yes
MAC address	_	_	Yes	No	Yes	No	Yes

USB (Universal Serial Bus) Interface

Outline

- Full-speed transmission at 12 Mbps [bps: bits per second]
- Plug & Play, Hot Insertion & Removal

USB transmission specifications

USB function

Overall s	pecifications		USB 2.0						
Transmiss	sion speed		USB Full-Speed (12 Mbps)						
Transmiss	sion method		USB bulk transmission meth	od					
Power su	pply specifications		USB self power supply func	tion					
Current	consumed by USB b	us	0 mA						
USB pack	cet size (with full-spe	ed connection)							
	USB bulk OUT (TM)		64 bytes						
	USB bulk IN (TM)		64 bytes						
USB devi	ce class		Both vendor-defined class supported. Switching of the switch on startup.	· ·					
USB desc	criptor		USB vendor-defined class	USB printer class					
	Vendor ID		04b8h 04b8h						
	Product ID		0202h 0E08h						
	String Descriptor	Manufacturer Product Serial number	EPSON TM-L500A Character string based on the product serial number						

Status transmission from printer with USB interface

In order to ensure that there is no lack of status data, it is necessary to periodically retrieve status data at the host computer.

Unlike RS-232 transmission, status cannot spontaneously interrupt data transmission to the host computer.

The printer has a 128-byte status data buffer. Statuses that exceed the buffer capacity are canceled.

Character Code Tables

CAUTION

- The character code tables show only character configurations. They do not show the actual print pattern.
- "SP" in the table shows a space.

Common to All Pages

When the international character set (See "International Character Sets" on page 130.) is USA:

HEX	()	1					3		4		5		6		7
0	NUL	0	DLE	16	SP	32	0	48	@	64	Р	80	,	96	р	112
1		1	XON	17	<u>!</u>	33	1	49	Α	65	Q	81	a	97	q	113
2		2		18	"	34	2	50	В	66	R	82	b	98	r	114
3		3	XOF	F 19	#	35	3	51	C	67	S	83	C	99	S	115
4	EOT	4	DC4	20	\$	36	4	52	D	68	Τ	84	a	100	t	116
5	ENQ	5	NAK	21	%	37	5	53	Ε	69	J	85	Ф	101	u	117
6	ACK	6	-	22	&	38	6	54	F	70	٧	86	f	102	٧	118
7		7		23	•	39	7	55	G	71	W	87	g	103	W	119
8		8	CAN	24	(40	8	56	Н	72	Χ	88	h	104	Χ	120
9	HT	9		25)	41	9	57	Ι	73	Υ	89	i	105	У	121
Α	LF	10		26	*	42	:	58	J	74	Z	90	j	106	Z	122
В		11	ESC	27	+	43	;	59	K	75	[91	k	107	{	123
С	FF	12	FS	28	,	44	<	60	L	76	\	92	1	108		124
D	CR	13	GS	29	-	45	=	61	М	77]	93	m	109	}	125
Е		14	RS	30	•	46	>	62	N	78	^	94	n	110	~	126
F		15		31	/	47	?	63	0	79	_	95	0	111	SP	127

Page 0 (PC437: USA, Standard Europe)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$\$	176	L	192	Ш	208	α	224	Ш	240
1	ü	129	æ	145	ĺ	161	9888	177	Τ	193	₹	209	ദ	225	+1	241
2	é	130	Æ	146	Ó	162	\$\$\$\$\$	178	Т	194	π	210	Γ	226	٨١	242
3	â	131	ô	147	ú	163		179	ŀ	195	Ш	211	π	227	≤	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	F	212	Σ	228	ſ	244
5	à	133	Ò	149	Ñ	165	4	181	+	197	F	213	σ	229	J	245
6	å	134	û	150	<u>a</u>	166	1	182	ŧ	198	Π	214	μ	230	÷	246
7	Ç	135	ù	151	0	167	П	183	╟	199	#	215	τ	231	*	247
8	ê	136	ÿ	152	٠.	168	٣	184	L	200	ŧ	216	Φ	232	0	248
9	ë	137	Ö	153	L	169	≒	185	F	201	J	217	Θ	233	•	249
А	è	138	Ü	154	Г	170		186	π	202	Γ	218	Ω	234	٠	250
В	ï	139	¢	155	<u>1</u>	171	ī	187	īī	203		219	δ	235	√	251
С	î	140	£	156	<u>1</u> 4	172	╗	188	ŀ	204		220	۵	236	n	252
D	ì	141	¥	157	ī	173	Ш	189	=	205	I	221	ф	237	2	253
E	Ä	142	Pt	158	«	174	1	190	쀼	206	I	222	3	238	I	254
F	Å	143	f	159	»	175	٦	191	工	207		223	N	239	SP	255

Page 1 (Katakana)

HEX	8	9	А	В	С	D	Е	F
0	– 128	1	SP 160	– 176	夕 192	208	= 224	X ₂₄₀
1	- 129	T 145	• 161	7 177	ب 193	L 209	‡ ₂₂₅	图 241
2	1 30	146	Γ 162	1 178	" 194	メ 210	‡ ₂₂₆	年 242
3	1 31		J 163	ウ 179	₹ ₁₉₅	t 211	‡ ₂₂₇	月 ₂₄₃
4	1 32	–	164	I ₁₈₀	\ 196	† 212	 1 228	B 244
5	1 33	– 149	165	才 _[181]	ታ ₁₉₇	1 213	229	時 245
6	1 34	150	7 ₁₆₆	力 _[182]	- 198	3 ₂₁₄	230	分 246
7	135	₁₅₁	7 167	† 183	ヌ 199	ラ 215	7 231	秒 247
8	136	Γ ₁₅₂	1 168	ク _[184]	ネ 200	ا 216	232	T 248
9	I 137	1 153	ウ 169	ኃ 185	J 201	ル 217	233	ホ 249
Α	138	L 154	I 170] _[186]	N 202	ν ₂₁₈	♦ 234	Ø 250
В	I 139	J 155	才 171	ቻ 187	۲ ₂₀₃	1 219	♣ 235	町 251
С	140	ر ₁₅₆	† 172	シ ₁₈₈	7 204	7 220	236	村 252
D	141	157	1 ₁₇₃	λ _[189]	1 205	ン 221	O 237	λ ₂₅₃
E	142	(158	3 174	t ₁₉₀	赤 206	222	/ 238	33 254
F	+ 143	ノ 159	ッ 175	ソ _[191]	₹ 207	223	1 239	SP 255

Page 2 (PC850: Multilingual)

HEX		8		9		Α		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$	176	L	192	ð	208	Ó	224	ı	240
1	ü	129	æ	145	ĺ	161	\$\$\$\$\$	177	Τ	193	Đ	209	ദ	225	+1	241
2	é	130	Æ	146	Ó	162	3888	178	Т	194	Ê	210	Ô	226		242
3	â	131	ô	147	ú	163		179	ŀ	195	Ë	211	Ò	227	3 4	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	È	212	õ	228	¶	244
5	à	133	Ò	149	Ñ	165	Á	181	+	197	1	213	Õ	229	§	245
6	å	134	û	150	<u>a</u>	166	Â	182	ã	198	Í	214	μ	230	÷	246
7	Ç	135	ù	151	0	167	À	183	Ã	199	Î	215	þ	231	,	247
8	ê	136	ÿ	152	٠.	168	©	184	L	200	Ϊ	216	Ъ	232	0	248
9	ë	137	Ö	153	R	169	#	185	ſŗ	201	J	217	Ú	233	•	249
Α	è	138	Ü	154	Г	170	=	186	π	202	Γ	218	Û	234	٠	250
В	ï	139	Ø	155	넴	171	ī	187	īī	203		219	Ù	235	1	251
С	î	140	£	156	<u>1</u> 4	172	ı	188	ŀ	204		220	ý	236	з	252
D	ì	141	Ø	157	i	173	¢	189	=	205		221	Ý	237	2	253
E	Ä	142	×	158	«	174	¥	190	쀼	206	Ì	222	_	238		254
F	Å	143	f	159	»	175	٦	191	¤	207		223	_	239	SP	255

Page 3 (PC860: Portuguese)

HEX		8		9		Α		В		С		D		Е		F
0	Ç	128	É	144	á	160	***	176	L	192	Ш	208	α	224	Ξ	240
1	ü	129	À	145	ĺ	161	***	177	Τ	193	₹	209	ß	225	<u>+</u>	241
2	é	130	È	146	Ó	162	***	178	Т	194	π	210	Γ	226	٨١	242
3	â	131	ô	147	ú	163		179	ŀ	195	Ш	211	π	227	≤	243
4	ã	132	õ	148	ñ	164	+	180	_	196	F	212	Σ	228	ſ	244
5	à	133	Ò	149	Ñ	165	1	181	+	197	F	213	σ	229	J	245
6	Á	134	Ú	150	<u>a</u>	166	1	182	ŧ	198	Π	214	μ	230	÷	246
7	Ç	135	ù	151	ō	167	П	183	╟	199	#	215	τ	231	*	247
8	ê	136	Ì	152	٠.	168	Ŧ	184	L	200	‡	216	ф	232	0	248
9	Ê	137	Õ	153	Ò	169	1	185	F	201	L	217	Θ	233	•	249
А	è	138	Ü	154	7	170		186	π	202	Γ	218	Ω	234	٠	250
В	Í	139	¢	155	1/2	171	ī	187	īī	203		219	δ	235	√	251
С	Ô	140	£	156	1 4	172	ī	188	ŀ	204		220	۵	236	n	252
D	Ì	141	Ù	157	i	173	Ш	189	=	205	I	221	ф	237	2	253
E	Ã	142	Pt	158	«	174	4	190	쀼	206	I	222	ε	238		254
F	Â	143	Ó	159	»	175	٦	191	工	207		223	N	239	SP	255

Page 4 (PC863: Canadian-French)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	É	144		160	\$\$\$\$\$	176	L	192	Ш	208	α	224	Ш	240
1	ü	129	È	145	١.	161	\$\$\$\$\$	177	Τ	193	₹	209	ß	225	+1	241
2	é	130	Ê	146	Ó	162	***	178	Т	194	π	210	Γ	226	٨١	242
3	â	131	ô	147	ú	163		179	ŀ	195	Ш	211	π	227	<u>~</u>	243
4	Â	132	Ë	148		164	+	180	_	196	F	212	Σ	228	ſ	244
5	à	133	Ϊ	149		165	1	181	+	197	F	213	σ	229	J	245
6	¶	134	û	150	3	166	1	182	ŧ	198	Π	214	μ	230	÷	246
7	Ç	135	ù	151	_	167	П	183	╟	199	#	215	τ	231	*	247
8	ê	136	¤	1 52	Î	168	7	184	L	200	ŧ	216	ф	232	0	248
9	ë	137	Ô	153	L	169	1	185	F	201	J	217	Θ	233	•	249
А	è	138	Ü	154	Г	170		186	π	202	Γ	218	Ω	234	٠	250
В	ï	139	¢	155	<u>1</u> 2	171	ī	187	īī	203		219	δ	235	√	251
С	î	140	£	156	1 4	172	T	188	ŀ	204		220	۵	236	n	252
D	=	141	Ù	157	3 4	173	П	189	=	205	I	221	ф	237	2	253
E	À	142	Û	158	«	174	1	190	뀨	206	I	222	3	238		254
F	§	143	f	159	»	175	٦	191	工	207		223	N	239	SP	255

Page 5 (PC865: Nordic)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	É	144	á	160		176	L	192	Ш	208	α	224	Ξ	240
1	ü	129	æ	145	ĺ	161	***	177	Τ	193	Ŧ	209	ß	225	±	241
2	é	130	Æ	146	Ó	162	**	178	Т	194	π	210	Γ	226	2	242
3	â	131	ô	147	ú	163		179	<u> </u>	195	Ш	211	π	227	≤	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	F	212	Σ	228	ſ	244
5	à	133	Ò	149	Ñ	165	4	181	+	197	F	213	σ	229	J	245
6	å	134	û	150	<u>a</u>	166	1	182	ŧ	198	Π	214	μ	230	÷	246
7	Ç	135	ù	151	0	167	П	183	╟	199	#	215	τ	231	*	247
8	ê	136	ÿ	152	į	168	Ŧ	184	L	200	ŧ	216	ф	232	0	248
9	ë	137	Ö	153	L	169	#	185	F	201	L	217	Θ	233	•	249
А	è	138	Ü	154	Г	170		186	π	202	Γ	218	Ω	234	٠	250
В	ï	139	Ø	155	1/2	171	ī	187	īī	203		219	δ	235	√	251
С	î	140	£	156	1 4	172	ī	188	ŀ	204		220	۵	236	n	252
D	ì	141	Ø	157	i	173	Ш	189	=	205	I	221	ф	237	2	253
E	Ä	142	Pt	158	«	174	1	190	쀼	206	I	222	3	238		254
F	Å	143	f	159	¤	175	٦	191	±	207		223	N	239	SP	255

Page 11 (PC851: Greek)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	Ί	144	ï	160	\$\$\$\$\$	176	L	192	T	208	ζ	224	ı	240
1	ü	129	SP	145	ί	161	***	177	Τ	193	Υ	209	η	225	±	241
2	é	130	Ŋ	146	Ó	162	**	178	Т	194	ф	210	θ	226	U	242
3	â	131	ô	147	Ú	163		179	ł	195	Χ	211	L	227	φ	243
4	ä	132	Ö	148	A	164	+	180	_	196	Ψ	212	K	228	χ	244
5	à	133	Ύ	149	В	165	K	181	+	197	Ω	213	λ	229	§	245
6	Ά	134	û	150	Γ	166	٨	182	Π	198	α	214	μ	230	ψ	246
7	Ç	135	ù	151	Δ	167	М	183	Р	199	β	215	٧	231	,	247
8	ê	136	Д	152	E	168	N	184	L	200	γ	216	ξ	232	0	248
9	ë	137	Ö	153	Z	169	#	185	Γ	201	J	217	0	233	•	249
Α	è	138	Ü	154	Н	170	=	186	π	202	Γ	218	π	234	3	250
В	ï	139	á	155	10	171	ī	187	īī	203		219	ρ	235	Ü	251
С	î	140	£	156	Θ	172	ı	188	ļĻ	204		220	σ	236	ΰ	252
D	Έ	141	έ	157	Ι	173	Ξ	189	=	205	δ	221	ς	237	Ŵ	253
E	Ä	142	ή	158	«	174	0	190	뀨	206	3	222	τ	238		254
F	Ή	143	Ĺ	159	»	175	٦	191	Σ	207		223	_	239	SP	255

Page 12 (PC853: Turkish)

HEX		8		9		Α		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$	176	L	192	SP	208	Ó	224	-	240
1	ü	129	Ċ	145	ĺ	161	8888	177	Τ	193	SP SS	209	ß	225	SP	241
2	é	130	Ċ	146	Ó	162	3888	178	Т	194	Ê	210	Ô	226	l	242
3	â	131	ô	147	ú	163		179	ŀ	195	Ë	211	Ò	227	'n	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	È	212	Ġ	228	J	244
5	à	133	Ò	149	Ñ	165	Á	181	+	197	1	213	ġ	229	§	245
6	ĉ	134	û	150	Ğ	166	Â	182	ŝ	198	Í	214	μ	230	÷	246
7	Ç	135	ù	151	ğ	167	À	183	ŝ	199	Î	215	Ħ	231		247
8	ê	136	İ	152	Ĥ	168	S	184	L	200	Ϊ	216	ħ	232	0	248
9	ë	137	Ö	153	ĥ	169		185	Γ	201	¬	217	Ú	233		249
Α	è	138	Ü	154	SP	170	=	186	π	202	Γ	218	Û	234	•	250
В	ï	139	ĝ	155	1/2	171	ī	187	īī	203		219	Ù	235	SP	251
С	î	140	£	156	Ĵ	172	ı	188	ŀ	204		220	Ŭ	236	3	252
D	ì	141	Ĝ	157	Ş	173	Ż	189	=	205	SP	221	ŭ	237	2	253
E	Ä	142	×	158	«	174	Ż	190	쀼	206	Ì	222	•	238		254
F	Ĉ	143	ĵ	159	»	175	٦	191	¤	207		223	_	239	SP	255

Page 13 (PC857: Turkish)

HEX		8		9		Α		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$\$	176		192	0	208	Ó	224	ı	240
1	ü	129	æ	145	ĺ	161	9888	177	4	193	<u>a</u>	209	ß	225	+1	241
2	é	130	Æ	146	Ó	162	***	178	Т	194	Ê	210	Ô	226	SP	242
3	â	131	ô	147	ú	163		179	<u> </u>	195	Ë	211	Ò	227	3 4	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	È	212	õ	228	¶	244
5	à	133	Ò	149	Ñ	165	Á	181	+	197	€	213	Õ	229	§	245
6	å	134	û	150	Ğ	166	Â	182	ã	198	Í	214	μ	230	÷	246
7	Ç	135	ù	151	ğ	167	À	183	Ã	199	Î	215	SP	231	,	247
8	ê	136	İ	152	į	168	©	184	╝	200	Ϊ	216	×	232	0	248
9	ë	137	Ö	153	®	169	≒ =	185	ᄕ	201	J	217	Ú	233	:	249
Α	è	138	Ü	154	Г	170	==	186	긕	202	Γ	218	Û	234	٠	250
В	ï	139	Ø	155	<u>1</u> 2	171	ī	187	īī	203		219	Ù	235	1	251
С	î	140	£	156	<u>1</u> 4	172	ᅱ	188	브느	204		220	ì	236	з	252
D	1	141	Ø	157	i	173	¢	189		205		221	ÿ	237	2	253
Е	Ä	142	Ş	158	«	174	¥	190	쀼	206	Ì	222	_	238		254
F	Å	143	Ş	159	»	175	٦	191	¤	207		223	-	239	SP	255

Page 14 (PC737: Greek)

HEX		8		9		А		В		С		D		Е		F
0	Α	128	Р	144	L	160	33333	176	L	192	П	208	ω	224	Д	240
1	В	129	Σ	145	K	161	***	177	Τ	193	₹	209	á	225	<u>+</u>	241
2	Γ	130	T	146	λ	162	**	178	Т	194	π	210	έ	226	2	242
3	Δ	131	Υ	147	μ	163		179	<u> </u>	195	Ш	211	ή	227	≤	243
4	E	132	ф	148	٧	164	+	180	_	196	F	212	Ϊ	228	Ϊ	244
5	Z	133	Χ	149	ξ	165	1	181	+	197	F	213	Ĺ	229	Ϋ	245
6	Н	134	Ψ	150	0	166	1	182	ŧ	198	Π	214	Ó	230	÷	246
7	Θ	135	Ω	151	π	167	П	183	╟	199	#	215	Ú	231	≈	247
8	Ι	136	α	152	ρ	168	₹	184	L	200	ŧ	216	Ü	232	0	248
9	K	137	β	153	σ	169	1	185	F	201	L	217	Ŵ	233	•	249
А	٨	138	γ	154	ς	170		186	π	202	Γ	218	Ά	234	•	250
В	М	139	δ	155	τ	171	ī	187	īī	203		219	Έ	235	√	251
С	N	140	3	156	U	172	ī	188	ŀ	204		220	Ή	236	n	252
D	Ξ	141	ζ	157	φ	173	П	189	=	205	I	221	Ί	237	2	253
E	0	142	η	158	χ	174	4	190	쀼	206	I	222	Ŋ	238		254
F	П	143	θ	159	ψ	175	٦	191	±	207		223	Ϋ́	239	SP	255

Page 15 (ISO8859-7: Greek)

HEX		8		9		Α		В		С		D		Е		F
0	SP	128	SP	144	SP	160	0	176	ί	192	П	208	ΰ	224	π	240
1	SP	1120	SP	1144	٤	1100	+	1170	٨	1192	Р	1200	_	1224	_	1240
'	-	129		145		161	±	177	A	193	۲	209	α	225	ρ	241
2	SP	400	SP		,	400	2		В	-	SP		β		ς	
3	SP	130	SP	146	_	162	3	178	_	194	_	210	<u> </u>	226		242
٥	101	131	101	147	£	163	3	179	ı	195	Σ	211	γ	227	σ	243
4	SP	1.0.	SP	1	€	1.00	-	1	Δ	1.00	Т	1	δ	1	τ	12 .0
		132		148	₹	164		180	۵	196	'	212	U	228	L	244
5	SP		SP		Dp		.,.		Ε		Υ		ε		U	
6	SP	133	SP	149	-' 	165	11	181		197		213	_	229		245
0	101	134	101	150	i	166	Ά	182	Z	198	Ф	214	ζ	230	φ	246
7	SP	1.0.	SP	1.00	§	1.00		1.02	Н	1.00	Χ		η	1200	ν	12 10
		135		151		167		183		199		215	''	231	χ	247
8	SP	400	SP	450		400	Έ	101	Θ		Ψ		θ		Ψ	
9	SP	136	SP	152	_	168	111	184	_	200	_	216		232		248
9	101	137	101	153	©	169	Ή	185	Ι	201	Ω	217	L	233	ω	249
Α	SP		SP				Ί		K		Ϊ		К		Ï	
		138		154	٠	170		186		202		218		234		250
В	SP	139	SP	155	«	171	»	187	٨	203	Ϋ	219	λ	235	Ü	251
<u> </u>	SP	108	SP	1100		1171	ď	1107	м	1200	á	219		200	á	1201
•	-	140		156	"	172	U	188	М	204	á	220	μ	236	Ó	252
D	SP		SP		_		1/2		N		έ		٧		Ú	
		141		157		173		189		205		221	·	237		253
E	SP	142	SP	158	SP	174	Ύ	190	Ξ	206	ή	222	ξ	238	Ŵ	254
F	SP		SP		_		Д		0		ĺ		0		SP	
		143		159		175	1,	191		207		223		239		255

Page 16 (WPC1252)

HEX		8		9		А		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	À	192	Đ	208	à	224	ð	240
1	SP	129	٤	145	i	161	<u>+</u>	177	Á	193	Ñ	209	á	225	ñ	241
2	,	130	,	146	¢	162	2	178	Â	194	Ò	210	â	226	Ò	242
3	f	131	"	147	£	163	з	179	Ã	195	Ó	211	ã	227	Ó	243
4	"	132	77	148	¤	164	,	180	Ä	196	Ô	212	ä	228	ô	244
5		133	•	149	¥	165	μ	181	Å	197	õ	213	å	229	õ	245
6	†	134	-	150		166	¶	182	Æ	198	Ö	214	æ	230	Ö	246
7	‡	135	_	151	§	167	٠	183	Ç	199	×	215	Ç	231	÷	247
8	^	136	~	152		168	٦	184	È	200	Ø	216	è	232	Ø	248
9	*	137	TM	153	©	169	1	185	É	201	Ù	217	é	233	ù	249
Α	Š	138	Š	154	<u>a</u>	170	OI	186	Ê	202	Ú	218	ê	234	ú	250
В	<	139	^	155	«	171	»	187	Ë	203	Û	219	ë	235	û	251
С	Œ	140	œ	156	-	172	<u>1</u> 4	188	Ì	204	Ü	220	ì	236	ü	252
D	SP	141	SP	157	-	173	1/2	189	Í	205	Ý	221	ĺ	237	ý	253
E	Ž	142	ž	158	®	174	3 4	190	Î	206	Þ	222	î	238	þ	254
F	SP	143	Ϋ	159	-	175	ડ	191	Ϊ	207	ß	223	ï	239	ÿ	255

Page 17 (PC866: Cyrillic #2)

HEX		8		9		А		В		С		D		Е		F
0	A	128	Р	144	a	160	\$\$\$\$\$	176	L	192	Ш	208	р	224	Ë	240
1	Б	129	С	145	б	161	\$\$\$\$	177	Τ	193	Ŧ	209	O	225	ë	241
2	В	130	T	146	В	162	**	178	Т	194	π	210	T	226	9	242
3	Γ	131	У	147	Γ	163		179	<u> </u>	195	Ш	211	У	227	€	243
4	Д	132	Ф	148	Д	164	+	180	_	196	F	212	ф	228	Ϊ	244
5	E	133	X	149	е	165	1	181	+	197	F	213	Х	229	ï	245
6	Ж	134	Ц	150	Ж	166	1	182	ŧ	198	Π	214	Ц	230	ў	246
7	3	135	Ч	151	3	167	Π	183	╟	199	#	215	Ч	231	ў	247
8	И	136		152	И	168	₹	184	L	200	ŧ	216	Ш	232	0	248
9	Й	137	Щ	153	Й	169	1	185	F	201	J	217	Щ	233	•	249
А	K	138	Ъ	154	K	170		186	π	202	Γ	218	Ъ	234	٠	250
В	Л	139	Ы	155	Л	171	า	187	īī	203		219	Ы	235	√	251
С	М	140	Ь	156	М	172	1	188	ŀ	204		220	Ь	236	No	252
D	Н	141	Э	157	Н	173	Ш	189	=	205	I	221	Э	237	¤	253
E	0	142	Ю	158	0	174	1	190	뀨	206	I	222	Ю	238	I	254
F	П	143	Я	159	П	175	٦	191	工	207		223	Я	239	SP	255

Page 18 (PC852: Latin2)

HEX		8		9		А		В		С		D		Е		F
0	C)	128	É	144	á	160	\$\$\$\$\$	176	L	192	đ	208	Ó	224	ı	240
1	ü	129	Ĺ	145	ĺ	161	3333	177	Τ	193	Đ	209	ß	225	?	241
2	é	130	ĺ	146	Ó	162	***	178	Т	194	Ď	210	Ô	226	ı	242
3	â	131	ô	147	ú	163		179	ŀ	195	Ë	211	Ń	227	*	243
4	ä	132	Ö	148	Ą	164	+	180	_	196	ď	212	ń	228)	244
5	ů	133	Ľ	149	ą	165	Á	181	+	197	Ň	213	ň	229	§	245
6	Ć	134	ľ	150	Ž	166	Â	182	Ă	198	Í	214	Š	230	÷	246
7	Ç	135	Ś	151	ž	167	Ě	183	ă	199	Î	215	Š	231		247
8	}	136	Ś	152	Ę	168	Ş	184	L	200	ě	216	Ŕ	232	0	248
9	:Ф	137	Ö	153	Ф	169		185	F	201	L	217	Ú	233	:	249
А	Ő	138	Ü	154	€	170		186	π	202	Γ	218	ŕ	234	•	250
В	Ő	139	Ť	155	Ź	171	ī	187	īī	203		219	Ű	235	ű	251
С	î	140	ť	156	Č	172	ı	188	ŀ	204		220	ý	236	Ř	252
D	Ź	141	Ł	157	Ş	173	Ż	189	=	205	Ţ	221	Ý	237	ř	253
E	Ä	142	×	158	«	174	Ż	190	#	206	Ů	222	ţ	238		254
F	Ć	143	č	159	»	175	٦	191	¤	207		223	ĺ	239	SP	255

Page 19 (PC858: Euro)

HEX		8		9		Α		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$\$	176		192	ð	208	Ó	224	ı	240
1	ü	129	æ	145	ĺ	161	9888	177	4	193	Đ	209	ദ	225	+1	241
2	é	130	Æ	146	Ó	162	***	178	Т	194	Ê	210	Ô	226	=	242
3	â	131	ô	147	ú	163		179	<u> </u>	195	Ë	211	Ò	227	3 4	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	È	212	õ	228	¶	244
5	à	133	Ò	149	Ñ	165	Á	181	+	197	€	213	Õ	229	§	245
6	å	134	û	150	<u>a</u>	166	Â	182	ã	198	Í	214	μ	230	÷	246
7	Ç	135	ù	151	ō	167	À	183	Ã	199	Î	215	þ	231	,	247
8	ê	136	ÿ	152	į	168	©	184	╝	200	Ϊ	216	Þ	232	0	248
9	ë	137	Ö	153	®	169	≒	185	ľ	201	J	217	Ú	233	:	249
Α	è	138	Ü	154	Г	170	==	186	긕	202	Γ	218	Û	234	٠	250
В	ï	139	Ø	155	<u>1</u> 2	171	ī	187	īī	203		219	Ù	235	1	251
С	î	140	£	156	<u>1</u> 4	172	╗	188	ᆙ	204		220	ý	236	3	252
D	ì	141	Ø	157	ī	173	¢	189		205		221	Ý	237	2	253
E	Ä	142	×	158	«	174	¥	190	뀨	206	Ì	222		238		254
F	Å	143	f	159	»	175	٦	191	¤	207		223	•	239	SP	255

Page 20 (KU42: Thai)

HEX		8		9		Α		В		С		D		E		F
0	Γ	128	0	144	SP	160	8	176	ខ	192	ļ	208	-	224	€4	240
1	٦	129	ត	145	ก	161	âl.	177	ว็	193	ļļ	209	æ	225	+α	241
2	L	130	ø	146	ป	162	Ø	178	ព	194	โ	210	ક	226	گم	242
3	J	131	ព	147	ค	163	Ø	179	ล	195	ใ	211	+	227	-a	243
4		132	ы	148	ฆ	164	ព	180	Ĵ	196	ኚ	212	٧	228	a a	244
5	_	133	اق	149	1	165	M	181	ମ	197	ๆ	213	•	229	ध्य	245
6	<u> </u>	134	٦	150	٩	166	ປົ	182	Н	198	។	214	-0	230	+ 4	246
7	+	135	ଶ	151	ฉ	167	น	183	ส	199	٩	215	ەھ	231	2	247
8	Т	136	æ	152	ឋ	168	ป	184	ĥ	200	a	216	ફે	232	પ્રહ	248
9	Т	137	76	153	ซ	169	ป	185	พ	201	Δ	217	+0	233	દેષ	249
Α	+	138	ູ	154	Ŋ	170	W	186	อ	202	a	218	-a	234	+₹	250
В		139	A	155	Ŋ	171	ฝ	187	ปี	203	æ	219	99	235	占	251
С	+	140	۲	156	ฎ	172	ฟ	188	66	204	ДІ	220	દર	236	ये	252
D	1	141	6	157	ปี	173	ฟ	189	ป	205	۴	221	49	237	ইব	253
E	→	142	5	158	ą	174	ม	190	1	206	0	222	٦-	238	4	254
F	↓	143	ļ	159	ฑ	175	ม	191	ኀ	207	ಡ	223	D A	239	SP	255

Page 21 (TIS11: Thai)

HEX	8	9	Α	В	С	D	Е	F
0	- 128	. 144	[160	্ব 176	រា 192	208 208	ا 224	o 240
1	3 129	시 145	្រា _[161]	n 177	្ស 193	3 209	ll 225	0 241
2	8 130	ال م 146	ປ _{ີ 162}	N 178	ខ 194	1 210	٦ ₂₂₆	७ 242
3	₺ [131	% 147	ប 163	a 179	រី 195	ነ 211	າ 227	ព 243
4	<mark>ا</mark> 132	4 148	ብ 164	ឲ 180	ព 196	212	\ 228	و 244
5	<mark>م</mark> 133	. 149	ฅ 165	9 181	ର 197	a 213	1 ₂₂₉	و 245
6	2 134	% 150	រុ 166	្ស 182	រា [198	~ 214	ໆ ₂₃₀	៦ ₂₄₆
7	* 135	% 151	167	f 183	ን 199	4 215	ය ₂₃₁	៨ 247
8	4 136	5 152	ា 168	ິນ _[184]	ศ 200	216	232	ぱ ₂₄₈
9	a 137	Γ ₁₅₃	ឯ 169	น _[185]	谐 201	ข 217	پ 233	k 249
А	الم 138	1 154	វ 170	ប _{ា86}	ส	218	~ 234	៕ 250
В	<mark>ន្ទ</mark> 139	L 155	ឋ _[171]	ป _[187]	អ 203	– 219	• 235	℃ 251
С	4 140	ا 156	M 172	₩ ₁₈₈	ឃ 204	⊥ 220	د 236	~ 252
D	ط ^ا [141		Q 173	ฝ ₁₈₉	อ ₂₀₅	T 221	° 237	ຄ [253
E	2 142		រ្វ [174	W 190	១ 206	+ 222	• 238	y 254
F	2 143	159	រ្វ [175	៕ 191	។ 207	B 223	0 239	SP 255

Page 26 (TIS18: Thai)

HEX		8		9		Α		В		С		D		Ε		F
0	Г	128	ኛ	144	SP	160	কৈঃ	176	ม	192	66	208	ļ	224	0	240
1	٦	129	ด	145	ก	161	ຶ່າ	177	ม	193	ę	209	ļļ	225	ត	241
2	L	130	- >	146	ป	162		178	ឱ	194	า	210	โ	226	p	242
3	J	131	e e	147	ป	163	âl.	179	ว็	195	ຶ່ງ	211	ใ	227	ព	243
4		132	લ્લ	148	ค	164	ด	180	ព	196	Δ	212	ኚ	228	9	244
5	_	133	4+	149	ฅ	165	ต	181	ล	197	а	213	า	229	ھ	245
6	<u> </u>	134	7	150	ฆ	166	ព	182	ฦ	198	æ	214	ๆ	230	๖	246
7	+	135	Þε	151	1	167	M	183	Ĵ	199	굄	215	ಡ	231	ଖ	247
8	Т	136	દેવ	152	จ	168	ປົ	184	ର୍ମ	200	ď	216		232	æ	248
9	Т	137	+₫	153	ฉ	169	೫	185	谐	201	a	217	ע	233	76	249
А	+	138	^վ	154	ឋ	170	ປ	186	ส	202	•	218	દ	234	ځه	250
В		139	-ব	155	ซ	171	ป	187	ĥ	203	- &	219	+	235	-য	251
С	+	140	a d	156	ผ	172	ฝ	188	พ	204	Be	220	૮	236	ने य	252
D	1	141	ইব	157	Ŋ	173	ฝ	189	อ	205	33	221	0	237	ইব	253
E	→	142	+ _d	158	ป็	174	ฟ	190	ปี	206	+	222	ч	238	4	254
F	↓	143	ļ	159	ฏ	175	ฟ	191	។	207	₿	223	0	239	SP	255

Page 30 (TCVN-3: Vietnamese)

HEX		8		9		Α		В		С		D		Е		F
0	SP		SP		SP		SP		SP		é		SP		SP	
		128		144		160		176		192	נ	208		224		240
1	SP		SP		SP		SP		SP		٥		ő		ů	
		129		145		161	1	177		193	ė	209	0	225	u	241
2	SP		SP		SP	•	SP		SP	•	ê	•	õ	•	ũ	
		130		146]	162	1	178		194	0	210	0	226	u	242
3	SP		SP		SP		SP		SP		ê		ó		ú	
		131		147		163		179		195	נ	211	٦	227	ч	243
4	SP		SP		SP		SP		SP		ễ		Ō		ų	
		132		148		164		180		196	נ	212	Ÿ	228	ų	244
5	SP		SP		SP		à		SP		é		ô		ù	
		133		149		165		181		197	١	213	_	229		245
6	SP		SP		SP		å		ă		ê		ő		ű	
		134		150		166		182	Ÿ	198		214		230		246
7	SP		SP		SP		ã		â		ì		õ		ũ	
		135		151		167		183		199		215		231		247
8	SP		SP		ă		á		ã		í		ố		ű	
		136		152		168		184		200		216		232		248
9	SP		SP		â		ą		ã		SP		ô		ự	
		137		153		169		185		201		217	<u> </u>	233	~	249
Α	SP		SP		ê		SP		á		SP		ď		ŷ	
		138		154		170		186	<u> </u>	202		218		234		250
В	SP		SP		ô		à		â		SP		ő		ŷ	
		139		155		171		187		203		219		235		251
С	SP		SP		ď		å		è		ĩ		õ		ỹ	
		140		156		172		188		204		220	Ľ	236	,	252
D	SP		SP		ď		ã		SP		í		ớ		ý	
		141		157		173		189		205		221	Ľ	237	,	253
E	SP		SP		đ		å		é		į		ģ		У.	
		142		158		174		190		206	:	222	Ÿ	238		254
F	SP		SP		SP		SP		ĩ		ò		ù		SP	
		143		159		175		191		207		223		239		255

Page 31 (TCVN-3: Vietnamese)

HEX		8		9		Α		В		С		D		Е		F
0	SP		É		SP		SP									
		128		144		160		176		192	_	208		224		240
1	SP		SP		Ă		SP		SP		Ė		Ô		Ű	
		129		145		161		177		193		209	Ŭ	225	_	241
2	SP		SP		Â		SP		SP		Ê		õ		ũ	
		130		146		162		178		194		210	Ŭ	226	_	242
3	SP		Ê		Ó		Ú									
		131		147		163		179		195		211	ŭ	227		243
4	SP		Ë		0		U									
		132		148		164		180		196		212	·	228	<u> </u>	244
5	SP		SP		SP		À		SP		È		ô		Ű	
		133		149		165		181		197		213		229		245
6	SP		SP		SP		Â		Ă		È		ő		ΰ	
		134		150		166		182		198		214		230		246
7	SP		SP		Ð		Ã		Â		Ì		ő		Ű	
		135		151		167		183		199		215		231		247
8	SP		SP		SP		Á		Â		Î		ő		Ű	
		136		152		168	ļ	184		200		216	_	232		248
9	SP		SP		SP		Ą		Ã		SP		Ô		ľ	
		137		153		169		185		201		217	<u> </u>	233	<u> </u>	249
Α	SP		SP		Ê		SP		Ã		SP		ď		Ŷ	
		138		154		170		186		202		218		234		250
В	SP		SP		Ô		À		Â		SP		ð		Ŷ	\square
		139		155		171		187		203		219		235		251
C	SP		SP		ď		Å		È		Ĩ		õ		Ϋ́	\square
		140		156		172		188		204		220		236		252
D	SP		SP		ľ		Ã		SP		Í		Ő		Ý	\square
		141		157		173		189		205	_	221	_	237	Ľ	253
E	SP		SP		SP		Á		Ê		İ		ď		Υ	
		142		158		174		190		206		222	۳	238	•	254
F	SP		SP		SP		SP		Ě		Ò		Ù		SP	
		143		159		175		191		207		223		239		255

Page 32 (PC720: Arabic)

HEX		8		9		Α		В		С		D		Е		F
0	SP	400	SP	444	ب	400	388888	470	L	400	Ш	200	ڧ	004	Ξ	0.40
1	SP	128	w	144		160		176		192		208		224	=	240
'		129		145	ö	161	***	177	_	193	₹	209	ط	225		241
2	é		۰		ت		**		_		π		ظ		ĄΣ	
		130		146		162	**	178	Т	194	π	210		226		242
3	â	131	ô	147	ث	163		179	ŀ	195	Ш	211	٤	227	=	243
4	SP		¤		~		1		_		F		غ		-	
		132		148	ح	164		180		196		212	٠	228		244
5	à	133	_	149	ح	165	╡	181	+	197	F	213	ف	229	9	245
6	SP		û		خ		1		F		П		μ			
		134		150	_	166	_"_	182		198		214	~	230		246
7	Ç	135	ù	151	د	167	П	183	╟	199	#	215	ق	231	≈	247
8	ê		۶		ذ		7		L		#		5]		0	
		136	~	152		168		184		200		216		232		248
9	ë	137	Ĩ	153	7	169	1	185	Γ	201		217	J	233	•	249
Α	è	138	וֹ	154	j	170		186	π	202	Г	218	م	234	•	250
В	ı.	1100	£	1134		1170		1100		1202	_	1210		204	Г	1230
	ï	139	ؤ	155	3	171	ī	187	ī	203		219	Ċ	235	4	251
С	î		£	455	ش	4=-	긔		ŀ				18	0.5.5	n	
_	SP	140		156	_	172		188		204	_	220		236		252
D	02	141	ļ	157	ď	173	Ш	189	=	205		221	9	237	2	253
Е	SP	142	ئ	158	«	174	4	190	#	206		222	ی	238		254
F	SP	1142	1	Iιηα		11/4		Liao	—	1200		1444		ZJ8	SP	1204
		143	,	159	»	175	٦	191	=	207		223	ي	239	<u></u>	255

Page 33 (WPC775: Baltic Rim)

HEX		8		9		А		В		С		D		Е		F
0	Ć	128	É	144	Ā	160	\$\$\$\$\$	176	L	192	ą	208	Ó	224	ı	240
1	ü	129	æ	145	Ī	161	8888	177	Τ	193	Č	209	ß	225	+1	241
2	é	130	Æ	146	Ó	162	8888	178	Т	194	ę	210	Ō	226	"	242
3	ā	131	ō	147	Ż	163		179	ŀ	195	ė	211	Ń	227	34	243
4	ä	132	Ö	148	Ż	164	+	180	_	196	į	212	õ	228	¶	244
5	ģ	133	Ģ	149	Ź	165	Ą	181	+	197	Š	213	Õ	229	§	245
6	å	134	¢	150	"	166	Č	182	Ų	198	ų	214	μ	230	÷	246
7	Ć	135	Ś	151		167	Ę	183	Ū	199	ū	215	ń	231	"	247
8	}	136	Ś	152	©	168	Ė	184	L	200	ž	216	Ķ	232	0	248
9	ē	137	Ö	153	R	169	#	185	ſŗ	201		217	ķ	233	•	249
Α	Ŗ	138	Ü	154	Г	170	=	186	π	202	Γ	218	Ļ	234	٠	250
В	ŗ	139	Ø	155	10	171	ī	187	īī	203		219]	235	1	251
С	ī	140	£	156	<u>1</u> 4	172	ᅱ	188	ŀ	204		220	ņ	236	3	252
D	Ź	141	Ø	157	Ł	173	Į	189	=	205	I	221	Ē	237	2	253
E	Ä	142	×	158	«	174	Š	190	쀼	206	I	222	Ņ	238		254
F	Å	143	¤	159	»	175	٦	191	Ž	207		223	,	239	SP	255

Page 34 (PC855: Cyrillic)

HEX		8		9		А		В		С		D		Е		F
0	ħ	128	Љ	144	a	160	\$\$\$\$\$	176	L	192	Л	208	Я	224	ı	240
1	Ъ	129	Ъ	145	A	161	3333	177	Τ	193	Л	209	р	225	Ы	241
2	ŕ	130	Њ	146	б	162	**	178	Т	194	М	210	Р	226	Ы	242
3	ŕ	131	Њ	147	Б	163		179	<u> </u>	195	М	211	С	227	3	243
4	ë	132	ħ	148	Ц	164	+	180	_	196	Н	212	С	228	3	244
5	Ë	133	ħ	149	Ц	165	Х	181	+	197	Н	213	Т	229	Ш	245
6	€	134	Ŕ	150	Д	166	X	182	K	198	0	214	T	230	Ш	246
7	€	135	Ŕ	151	Д	167	И	183	K	199	0	215	У	231	Э	247
8	S	136	ÿ	152	е	168	N	184	L	200	П	216	У	232	Э	248
9	S	137	ў	153	Ε	169	1	185	Γ	201	J	217	Ж	233	Щ	249
Α	i	138	Ų	154	ф	170		186	π	202	Γ	218	Ж	234	Щ	250
В	Ι	139	Ų	155	ф	171	ī	187	īī	203		219	В	235	Ч	251
С	ï	140	Ю	156	Γ	172	ī	188	ᆙ	204		220	В	236	Ч	252
D	Ϊ	141	Ю	157	Γ	173	Й	189		205	П	221	Ь	237	§	253
E	j	142	Ъ	158	«	174	Й	190	쀼	206	Я	222	Ь	238		254
F	J	143	Ъ	159	»	175	٦	191	¤	207		223	Μō	239	SP	255

Page 35 (PC861: Icelandic)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	É	144	á	160	***	176	L	192	Ш	208	α	224	Ξ	240
1	ü	129	æ	145	ĺ	161	***	177	Τ	193	₹	209	ß	225	±	241
2	é	130	Æ	146	Ó	162	**	178	Т	194	π	210	Γ	226	2	242
3	â	131	ô	147	ú	163		179	<u> </u>	195	Ш	211	π	227	≤	243
4	ä	132	Ö	148	Á	164	+	180	_	196	F	212	Σ	228	ſ	244
5	à	133	þ	149	Í	165	1	181	+	197	F	213	σ	229	J	245
6	å	134	û	150	Ó	166	1	182	F	198	Γ	214	μ	230	÷	246
7	Ç	135	Ý	151	Ú	167	П	183	╟	199	#	215	τ	231	*	247
8	ê	136	ý	152	ij	168	Ŧ	184	L	200	ŧ	216	ф	232	0	248
9	ë	137	Ö	153	٦	169	1	185	F	201	J	217	Θ	233	•	249
А	è	138	Ü	154	Г	170		186	П	202	Γ	218	Ω	234	٠	250
В	Đ	139	Ø	155	1/2	171	ī	187	īī	203		219	δ	235	√	251
С	ð	140	£	156	1 4	172	ᆌ	188	ŀ	204		220	۵	236	n	252
D	Þ	141	Ø	157	i	173	П	189	=	205	I	221	ф	237	2	253
E	Ä	142	Pt	158	«	174	4	190	#	206	I	222	3	238		254
F	Å	143	f	159	»	175	٦	191	<u></u>	207		223	N	239	SP	255

Page 36 (PC862: Hebrew)

HEX		8		9		Α		В		С		D		Е		F
0	В	128]	144	á	160	33333	176	L	192	Ш	208	α	224	Ш	240
1	ו	129	Ū	145	ĺ	161	***	177	Τ	193	₹	209	ß	225	+1	241
2	J	130	IJ	146	Ó	162	**	178	Т	194	π	210	Γ	226	2	242
3	٦	131	٩	147	ú	163		179	<u> </u>	195	Ш	211	π	227	≤	243
4	П	132	9	148	ñ	164	+	180	_	196	F	212	Σ	228	ſ	244
5	1	133	ץ	149	Ñ	165	4	181	+	197	F	213	σ	229	J	245
6	T	134	Я	150	<u>a</u>	166	\parallel	182	ŧ	198	Π	214	μ	230	÷	246
7	Π	135	7	151	0	167	П	183	╟	199	#	215	τ	231	*	247
8	ט	136	7	152	٠.	168	₹	184	L	200	ŧ	216	Φ	232	0	248
9	٦	137		153	L	169	1	185	F	201	J	217	Θ	233	•	249
Α	٦	138	Л	154	Г	170		186	π	202	Γ	218	Ω	234	٠	250
В)	139	¢	155	<u>1</u> 2	171	ī	187	īī	203		219	δ	235	√	251
С	ל	140	£	156	<u>1</u> 4	172	귀	188	ŀ	204		220	۵	236	n	252
D		141	¥	157	i	173	Ш	189	=	205	I	221	ф	237	2	253
E	ŋ	142	Pt	158	«	174	ī	190	뀨	206	I	222	ω	238		254
F	l	143	f	159	»	175	٦	191	⊥	207		223	N	239	SP	255

Page 37 (PC864: Arabic)

HEX		8		9		Α		В		С		D		Ε		F
0	0	128	β	144	SP	160	•	176	¢	192	ذ	208	_	224	1 E	240
1	٠	129	8	145	-	161	١	177	۶	193	J	209	ف	225	3	241
2	•	130	ф	146	Ľ	162	۲	178	Ĩ	194	ز	210	ق	226	ن	242
3	1	131	±	147	£	163	٣	179	ή	195	w	211	ک	227	٥	243
4	3333	132	12	148	¤	164	٤	180	ؤ	196	ŵ	212	١	228	#	244
5	ı	133	14	149	Ĺ	165	٥	181	ċ	197	4	213	٩	229	S	245
6		134	₹₹	150	SP	166	۳	182	ٿ	198	Ą.	214	ن	230	يي	246
7	+	135	«	151	€	167	٧	183	1	199	4	215	æ	231	٠	247
8		136	»	152	L	168	٨	184	7	200	Ë	216	و	232	و:	248
9	Τ	137	مح يّ	153	ب	169	4	185	ä	201	4	217	S	233	7	249
Α	\perp	138	ኢ	154	ت	170	·9	186	ت	202	·4	218	1:	234	<i>Κ</i>	250
В	1	139	SP	155	ث	171	**	187	ث	203	 -	219	ضر	235	ل	251
С	٦	140	SP	156	•	172	سر	188	ج	204	٦	220	•	236	1	252
D	Γ	141	8	157	ج	173	ŵ	189	_	205	÷	221	ċ	237	ي	253
E	L	142	K	158	ح	174	مر	190	خ	206	×	222	غ	238	I	254
F	J	143	د	159	خ	175	?	191	د	207	ع	223	م	239	SP	255

Page 38 (PC869: Greek)

HEX		8		9		Α		В		С		D		Е		F
0	SP	128	Ί	144	ï	160	188888	176	L	192	T	208	ζ	224	-	240
1	SP	129	Ϊ	145	ί	161	***	177	Τ	193	Υ	209	η	225	±	241
2	SP	130	Ŋ	146	Ó	162	**	178	Т	194	ф	210	θ	226	U	242
3	SP	131	SP	147	Ú	163		179	+	195	Χ	211	L	227	φ	243
4	SP	132	SP	148	A	164	+	180	-	196	Ψ	212	K	228	χ	244
5	SP	133	Ύ	149	В	165	K	181	+	197	Ω	213	λ	229	§	245
6	Ά	134	Ϋ	150	Γ	166	٨	182	П	198	α	214	μ	230	ψ	246
7	€	135	©	151	Δ	167	М	183	Р	199	β	215	٧	231	;	247
8	•	136	Д	152	Ε	168	N	184	╝	200	γ	216	ξ	232	0	248
9	7	137	2	153	Z	169	1	185	Γ	201	L	217	0	233	:	249
Α	1	138	3	154	Н	170		186	Т	202	Γ	218	π	234	ω	250
В	۲	139	á	155	<u>1</u> 2	171	ī	187	īī	203		219	ρ	235	Ü	251
С	,	140	£	156	Θ	172	T	188	ŀ	204		220	σ	236	ΰ	252
D	Έ	141	É	157	Ι	173	Ξ	189	=	205	δ	221	ς	237	Ŵ	253
E	_	142	ή	158	«	174	0	190	뀨	206	3	222	τ	238		254
F	Ή	143	Ĺ	159	»	175	٦	191	Σ	207		223	ĺ	239	SP	255

Page 39 (ISO8859-2: Latin2)

HEX		8		9		А		В		С		D		Е		F
0	33333	128	L	144	SP	160	0	176	Ŕ	192	Đ	208	ŕ	224	đ	240
1	***	129	Τ	145	Ą	161	ą	177	Á	193	Ń	209	á	225	ń	241
2	3888	130	Т	146		162	c	178	Â	194	Ň	210	â	226	ň	242
3		131	<u> </u>	147	Ł	163	}	179	Ă	195	Ó	211	ă	227	Ó	243
4	\dashv	132	_	148	¤	164	_	180	Ä	196	Ô	212	ä	228	ô	244
5	-	133	+	149	Ľ	165	ľ	181	Ĺ	197	Ő	213	ĺ	229	Ő	245
6	Γ	134		150	Ś	166	Ś	182	Ć	198	Ö	214	Ć	230	Ö	246
7		135		151	§	167	*	183	Ç	199	×	215	Ç	231	÷	247
8	©	136	L	152	 	168	,	184	Č	200	Ř	216	Č	232	ř	248
9	┯	137	ľ	153	Š	169	š	185	É	201	ٿ	217	é	233	ů	249
Α	=	138	Т	154	Ş	170	Ş	186	Ę	202	Ú	218	ę	234	ú	250
В	ī	139	īī	155	Ť	171	ť	187	Ë	203	Ű	219	ë	235	ű	251
С	ī	140	ŀ	156	Ź	172	Ź	188	Ě	204	Ü	220	ě	236	ü	252
D	¢	141	=	157	-	173	~	189	Í	205	Ý	221	ĺ	237	ý	253
E	¥	142	쀼	158	Ž	174	ž	190	Î	206	Ţ	222	î	238	ţ	254
F	٦	143	®	159	Ż	175	Ż	191	Ď	207	ß	223	ď	239	•	255

Page 40 (ISO8859-15: Latin9)

HEX		8		9		Α		В		С		D		Е		F
0	SP	400	SP	4.44	SP	400	0	470	À	400	Đ	000	à	004	ð	0.40
1	SP	128	SP	144		160	_	176	ſ	192	~	208	_	224	~	240
'	JOF	129	Jor	145	Ī	161	±	177	Á	193	Ñ	209	á	225	ñ	241
2	SP	400	SP	4.40	¢	400	2	470	Â	40.4	Ò	040	â		Ò	
	SP	130	0.0	146	<u>.</u>	162	_	178		194	_	210	~	226		242
3	125	131	SP	147	£	163	3	179	Ã	195	Ó	211	ã	227	Ó	243
4	SP		SP		€	1	Ž	1	Ä		ô	1	ä		ô	
		132		148	•	164		180		196		212		228		244
5	SP	133	SP	149	¥	165	μ	181	Å	197	õ	213	å	229	õ	245
6	SP	1.00	SP	1	Š	1.00	a	1.0.	Æ	1.0.	Ö	12.0		1220	Ö	12 .0
		134		150	٥	166	¶	182	ж	198	U	214	æ	230	U	246
7	SP		SP		§		•		Ç		×		Ç		÷	
		135		151		167		183		199		215		231		247
8	SP	400	SP	450	š	400	ž	404	È		Ø	040	è	000	Ø	0.40
9	SP	136	SP	152	_	168	1	184		200		216	_	232	_	248
9	JOP	137		153	©	169	'	185	É	201	Ù	217	é	233	ù	249
Α	SP		SP		<u>a</u>		ō		Ê		Ú		ê		ú	
		138		154		170		186		202		2 1 8		234		250
В	SP	139	SP	155	«	171	»	187	Ë	203	Û	219	ë	235	û	251
C	SP	1100	SP	1100		1171	ſΤ	1107	÷	1200	Ü	1210	ì	1200	77	1201
	-	140		156		172	Œ	188	Ì	204	U	220	ı	236	ü	252
D	SP		SP		_		œ		Í		Ý		í		ý	
		141		157		173		189		205		221		237	,	253
E	SP	142	SP	158	®	174	Ϋ	190	Î	206	Þ	222	î	238	þ	254
F	SP		SP		-		;		Ϊ		ß		ï		ÿ	
		143		159		175	ሪ	191		207	IJ	223	<u>'</u>	239	J	255

Page 41 (PC1098: Farsi)

HEX		8		9		Α		В		С		D		Е		F
0	SP	128	ؤ	144	ح	160	**	176	L	192	ċ	208	ک	224	-	240
1	SP	129	_5	145	خ	161	**	177	Τ	193	ع	209	ک	225	ß	241
2	•	130	ب	146	خ	162	**	178	Т	194		210	گ	226	: :	242
3	•	131	T	147	า	163		179	\vdash	195	غ	211	گ	227	ı	243
4	?	132	ږ	148	ذ	164	+	180	-	196	ċ	212	J	228	٥	244
5	*	133	پ	149	J	165	ض	181	+	197	غ	213	١	229	١	245
6	Ĩ	134	ت	150	ز	166	ض	182	ظ	198	غ	214	م	230	۲	246
7	Ľ	135	ت	151	ڎ	167	ط	183	ع	199	ف	215	-0	231	٣	247
8	Ĩ	136	ث	152	٣	168	ط	184	L	200	ف	216	ن	232	۴	248
9	1	137	Ļ	153	w	169	1	185	F	201	J	217	نـ	233	۵	249
Α	L	138	ج	154	ŵ	170		186	π	202	Γ	218	و	234	9	250
В	7	139	÷	155	ŵ	171	ī	187	īī	203		219	٥	235	٧	251
С	۶	140	3	156	ص	172	刊	188	ŀ	204		220	æ	236	٨	252
D	וֹ	141	÷	157	4	173	إل	189	=	205	ق	221	8	237	٩	253
E	Ĺ	142	×	158	«	174	ظ	190	#	206	ق	222	ð	238		254
F	į	143	ح	159	»	175	٦	191	SP	207		223	ی	239	SP	255

Page 42 (PC1118: Lithuanian)

HEX		8		9		А		В		С		D		Е		F
0	Ç	128	É	144	á	160	\$\$\$\$\$	176	L	192	ą	208	α	224	Ш	240
1	ü	129	æ	145	ĺ	161	***	177	Τ	193	Č	209	β	225	+	241
2	é	130	Æ	146	Ó	162	3888	178	Т	194	ę	210	Γ	226	۸۱	242
3	â	131	ô	147	ú	163		179	ŀ	195	ė	211	π	227	≤	243
4	ä	132	Ö	148	ñ	164	+	180	_	196	į	212	Σ	228	"	244
5	à	133	Ò	149	Ñ	165	Ą	181	+	197	š	213	σ	229	"	245
6	å	134	û	150	а	166	Č	182	Ų	198	ų	214	μ	230	÷	246
7	Ç	135	ù	151	0	167	Ę	183	Ū	199	ū	215	τ	231	*	247
8	ê	136	ÿ	152	٠.	168	Ė	184	L	200	Ž	216	ф	232	0	248
9	ë	137	Ö	153	L	169	#	185	ſŗ	201	J	217	Θ	233	•	249
Α	è	138	Ü	154	Г	170	=	186	π	202	Γ	218	Ω	234	•	250
В	ï	139	¢	155	12	171	ī	187	īī	203		219	δ	235	1	251
С	î	140	£	156	<u>1</u> 4	172	ı	188	ŀ	204		220	۵	236	n	252
D	ì	141	¥	157	i	173	Į	189	=	205	I	221	φ	237	2	253
Е	Ä	142	Pt	158	«	174	Š	190	쀼	206		222	3	238		254
F	Å	143	f	159	»	175	٦	191	Ž	207		223	N	239	SP	255

Page 43 (PC1119: Lithuanian)

HEX		8		9		А		В		С		D		Е		F
0	Α	128	Р	144	a	160	\$\$\$\$\$	176	L	192	ą	208	р	224	Ë	240
1	Б	129	С	145	б	161	***	177	Τ	193	Č	209	С	225	ë	241
2	В	130	T	146	В	162	**	178	Т	194	ę	210	T	226	2	242
3	Γ	131	У	147	Γ	163		179	ŀ	195	ė	211	У	227	≤	243
4	Д	132	Ф	148	Д	164	+	180	_	196	į	212	ф	228	"	244
5	E	133	Χ	149	е	165	Ą	181	+	197	Š	213	Χ	229	"	245
6	Ж	134	Ц	150	Ж	166	Č	182	Ų	198	ų	214	Ц	230	÷	246
7	3	135	Ч	151	3	167	Ę	183	Ū	199	ū	215	ጘ	231	₩	247
8	И	136		152	И	168	Ė	184	L	200	Ž	216		232	0	248
9	Й	137		153	Й	169		185	ſŗ	201	J	217	=	233	•	249
Α	K	138	Ъ	154	Κ	170	==	186	π	202	Γ	218	Ъ	234	•	250
В	Л	139	Ы	155	Г	171	ī	187	īī	203		219	Б	235	7	251
С	М	140	Ь	156	М	172	ᅱ	188	ŀ	204		220	Ь	236	n	252
D	Н	141	Э	157	Н	173	Į	189	=	205	I	221	Э	237	2	253
E	0	142	Ю	158	0	174	Š	190	쀼	206		222	Ю	238		254
F	П	143	Я	159	П	175	٦	191	Ž	207		223	Я	239	SP	255

Page 44 (PC1125: Ukrainian)

HEX		8		9		А		В		С		D		Е		F
0	Α	128	Р	144	a	160	18888	176	L	192	Ш	208	р	224	Ë	240
1	Б	129	С	145	б	161	***	177	Τ	193	₹	209	С	225	ë	241
2	В	130	T	146	В	162	**	178	Т	194	π	210	Т	226	٢	242
3	Γ	131	У	147	Γ	163		179	ŀ	195	Ш	211	У	227	۲	243
4	Д	132	Ф	148	Д	164	7	180	-	196	F	212	Ф	228	£	244
5	Ε	133	Χ	149	е	165	=	181	+	197	F	213	Χ	229	ε	245
6	Ж	134	Ц	150	Ж	166	=	182	ŧ	198	Π	214	=	230	Ι	246
7	3	135	Ч	151	З	167	П	183	╟	199	#	215	ᠴ	231	j	247
8	И	136		152	И	168	7	184	L	200	‡	216		232	Ϊ	248
9	Й	137	Щ	153	Й	169	1	185	ſŗ	201		217	=	233	Ϊ	249
А	K	138	Ъ	154	K	170	=	186	π	202	Γ	218	Ъ	234	• •	250
В	Л	139	Ы	155	Л	171	ī	187	īī	203		219	Б	235	+1	251
С	М	140	Ь	156	М	172	ᆌ	188	ŀ	204		220	Ь	236	₽	252
D	Н	141	Э	157	Н	173	Ш	189	=	205	I	221	Э	237	¤	253
E	0	142	Ю	158	0	174	1	190	쀼	206	I	222	Ю	238		254
F	П	143	Я	159	П	175	٦	191	工	207		223	Я	239	SP	255

Page 45 (WPC1250: Latin 2)

HEX		8		9		А		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	Ŕ	192	Đ	208	ŕ	224	đ	240
1	SP	129	٤	145	~	161	±	177	Á	193	Ń	209	á	225	ń	241
2	,	130	,	146	ŭ	162	ı	178	Â	194	Ň	210	â	226	ň	242
3	SP	131	"	147	Ł	163	}	179	Ă	195	Ó	211	ă	227	Ó	243
4	77	132	77	148	¤	164	_	180	Ä	196	Ô	212	ä	228	ô	244
5		133	•	149	Ą	165	μ	181	Ĺ	197	Ő	213	ĺ	229	Ő	245
6	†	134	-	150	1	166	¶	182	Ć	198	Ö	214	Ć	230	Ö	246
7	‡	135	_	151	§	167	٠	183	Ç	199	×	215	Ç	231	÷	247
8	SP	136	SP	152		168	,	184	Č	200	Ř	216	Č	232	ř	248
9	*	137	TM	153	©	169	ą	185	É	201	Ů	217	é	233	ů	249
А	Š	138	Š	154	Ş	170	တ္	186	Ę	202	Ú	218	Ф	234	ú	250
В	<	139	>	155	«	171	»	187	Ë	203	Ű	219	ë	235	ű	251
С	Ś	140	Ś	156	7	172	Ľ	188	Ě	204	Ü	220	ě	236	ü	252
D	Ť	141	ť	157	-	173	?	189	Í	205	Ý	221	ĺ	237	ý	253
E	Ž	142	ž	158	®	174	ľ	190	Î	206	Ţ	222	î	238	ţ	254
F	Ź	143	Ź	159	Ż	175	Ż	191	Ď	207	ß	223	ď	239	•	255

Page 46 (WPC1251: Cyrillic)

HEX		8		9		А		В		С		D		Е		F
0	Ъ	128	ħ	144	SP	160	0	176	A	192	Р	208	a	224	р	240
1	Ĺ	129	4	145	ў	161	+1	177	Б	193	\Box	209	б	225	C	241
2	,	130	,	146	ÿ	162	Ι	178	В	194	T	210	В	226	Т	242
3	ŕ	131	"	147	J	163	j	179	Γ	195	У	211	Γ	227	У	243
4	"	132	77	148	¤	164	۲	180	Д	196	ф	212	Д	228	ф	244
5		133	•	149	۲	165	μ	181	Ε	197	Χ	213	е	229	Χ	245
6	†	134	-	150	1	166	¶	182	Ж	198	Ц	214	Ж	230	Ц	246
7	‡	135	-	151	§	167	٠	183	3	199	Ч	215	3	231	Ч	247
8	€	136	SP	152	Ë	168	ë	184	И	200		216	И	232	Ш	248
9	*	137	M	153	(0)	169	₽.	185	Й	201		217	Й	233	=	249
А	Ъ	138	Ъ	154	Э	170	ε	186	K	202	Ъ	218	K	234	Ъ	250
В	<	139	>	155	«	171	»	187	Л	203	Ы	219	Л	235	Ы	251
С	Њ	140	Њ	156	Г	172	j	188	М	204	Ь	220	М	236	Ь	252
D	Ŕ	141	Ŕ	157	-	173	S	189	Н	205	Э	221	Н	237	Э	253
E	ħ	142	ħ	158	®	174	S	190	0	206	Ю	222	0	238	Ю	254
F	Ų	143	Ų	159	Ϊ	175	ï	191	Π	207	Я	223	П	239	Я	255

Page 47 (WPC1253: Greek)

HEX		8		9		Α		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	Ϊ	192	П	208	ΰ	224	π	240
1	SP	129	٤	145	.,,	161	±	177	A	193	Р	209	α	225	ρ	241
2	,	130	,	146	Ά	162	2	178	В	194	SP	210	β	226	ς	242
3	f	131	"	147	£	163	3	179	Γ	195	Σ	211	γ	227	σ	243
4	77	132	"	148	¤	164	_	180	Δ	196	T	212	δ	228	τ	244
5		133	•	149	¥	165	μ	181	Ε	197	Υ	213	ε	229	U	245
6	†	134	_	150		166	¶	182	Z	198	Ф	214	ζ	230	φ	246
7	‡	135	_	151	§	167	٠	183	Н	199	X	215	η	231	χ	247
8	SP	136	SP	152		168	Έ	184	Θ	200	Ψ	216	θ	232	ψ	248
9	*	137	TM	153	©	169	Ή	185	Ι	201	Ω	217	L	233	W	249
Α	SP	138	SP	154	<u>a</u>	170	Ί	186	K	202	Ϊ	218	K	234	Ϊ	250
В	<	139	>	155	«	171	»	187	٨	203	Ÿ	219	λ	235	Ü	251
С	SP	140	SP	156	7	172	ď	188	М	204	á	220	μ	236	Ó	252
D	SP	141	SP	157	-	173	1/2	189	N	205	έ	221	٧	237	Ú	253
E	SP	142	SP	158	R	174	Ϋ	190	Ξ	206	ή	222	ξ	238	Ŵ	254
F	SP	143	SP	159	_	175	Д	191	0	207	Ĺ	223	0	239	SP	255

Page 48 (WPC1254: Turkish)

HEX		8		9		Α		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	À	192	Ğ	208	à	224	ğ	240
1	SP	129	٤	145	i	161	±	177	Á	193	Ñ	209	á	225	ñ	241
2	,	130	,	146	¢	162	2	178	Â	194	Ò	210	â	226	Ò	242
3	f	131	"	147	£	163	3	179	Ã	195	Ó	211	ã	227	Ó	243
4	"	132	77	148	¤	164	•	180	Ä	196	Ô	212	ä	228	ô	244
5		133	•	149	¥	165	μ	181	Å	197	Õ	213	å	229	Õ	245
6	†	134	_	150	1	166	¶	182	Æ	198	Ö	214	æ	230	Ö	246
7	‡	135	_	151	§	167	٠	183	Ç	199	×	215	Ç	231	÷	247
8	^	136	~	152	•	168	٦	184	È	200	Ø	216	è	232	Ø	248
9	*	137	TM	153	©	169	1	185	É	201	Ù	217	é	233	ù	249
Α	Š	138	Š	154	<u>a</u>	170	0	186	Ê	202	Ú	218	ê	234	ú	250
В	<	139	>	155	«	171	»	187	Ë	203	Û	219	ë	235	û	251
С	Œ	140	œ	156	7	172	<u>1</u> 4	188	Ì	204	Ü	220	ì	236	ü	252
D	SP	141	SP	157	-	173	1/2	189	Í	205	İ	221	ĺ	237	1	253
E	SP	142	SP	158	®	174	34	190	Î	206	Ş	222	î	238	Ş	254
F	SP	143	Ϋ	159	_	175	į	191	Ϊ	207	ß	223	ï	239	ÿ	255

Page 49 (WPC1255: Hebrew)

HEX		8		9		А		В		С		D		Е		F
0	€		SP		SP		0				П		У]	
		128	٤	144		160		176	:	192	<u> </u>	208		224	_	240
1	SP	129	•	145	i	161	±	177	v:	193		209	ב	225	U	241
2	,	130	,	146	¢	162	2	178	-:	194	•	210	7	226	ע	242
3	ı	1100	"	1140	<u>ر</u>	1102	3	1170		1184		1210	7	1220	Π	1242
Ľ	f	131		147	£	163		179	т:	195	•	211	ı	227	1	243
4	77	132	77	148	D	164		180		196	11	212	П	228	9	244
5		133	•	149	¥	165	μ	181		197	וי	213	1	229	Ч	245
6	†	134	-	150	1	166	¶	182	÷	198	11	214	T	230	У	246
7	‡	135	_	151	§	167	•	183	_	199	′	215	П	231	7	247
8	^	1100	~	1101		1107		1100		1100	"	1210	ŋ	1201	-	1277
		136		152		168		184	•	200		216	U	232	'	248
9	*	137	TM	153	©	169	1	185	•	201	SP	217	٦	233	W	249
А	SP	138	SP	154	×	170	÷	186	SP	202	SP	218	٦	234	Л	250
В	<	139	>	155	«	171	»	187	٠.	203	SP	219)	235	SP	251
С	SP	140	SP	156	7	172	<u>1</u>	188		204	SP	220	7	236	SP	252
D	SP	141	SP	157	-	173	<u>1</u>	189		205	SP	221	0	237	SP	253
E	SP	142	SP	158	®	174	3 4	190	-	206	SP	222	ŋ	238	SP	254
F	SP	143	SP	159	-	175	ડ	191	-	207	SP	223	l		SP	255

Page 50 (WPC1256: Arabic)

HEX		8		9		Α		В		С		D		Е		F
0	€		Ű		SP		0		^		ذ		à		"	
		128	٤	144		160		176		192		208		224	ΛR	240
1	پ	129	•	145	•	161	±	177	۶	193	J	209	ل	225		241
2		1.20	,	1	¢	1.0.	2	1	ĩ	1.00	٠.	1200	â	1220		<u> </u>
	,	130		146	Ψ	162		178		194	ر	210	a	226	=	242
3	f	404	"	4.47	£	400	3	470	ٲ	405	w	044	م	007	_	0.40
4		131	77	147		163	_	179		195		211		227	_	243
4	"	132		148	¤	164		180	ؤ	196	ؿ	212	ن	228	ô	244
5		400	•	149	¥	165	μ	4.04	Į	407	ص	040	Þ	000	9	0.45
6		133		1149	<u> </u>	1100	•	181	_	197		213		229		245
	†	134	_	150	i	166	¶	182	ئ	198	ض	214	و	230	-	246
7	‡		1		§		•		1		×		Ç		÷	
		135		151		167		183		199		215		231		247
8	^	136	ک	152		168	_	184	ب	200	ط	216	è	232	w	248
9	v	1100	TM	1102	(C)	1100	1	1104	- v	1200	ظ	1210	á	1202	ù	1240
	*	137		153	8	169	•	185	ä	201		217	é	233		249
Α	ٿ		נ		فع	470	•	1.00	ت		ع	0.4.0	ê	00.4	٥	
В		138		154		170		186		202		218		234	_	250
	<	139	>	155	«	171	»	187	ث	203	غ	219	ë	235	û	251
С	Œ		œ		7		14		2 -		_		ی		ü	
	<u> </u>	140		156		172		188	ج	204		220	_	236		252
D	3	141	SP	157	-	173	1/2	189	ح	205	ف	221	ي	237	SP	253
Е	ĵ	1	SP	1.2.	®	1	3 4	1.22	÷		ق	1	î	1	SP	1-20
		142		158		174		190	خ	206	٥	222		238		254
F	ڈ	143	ں	159	-	175	?	191	د	207	1	223	Ϊ	239	ے	255

Page 51 (WPC1257: Baltic Rim)

HEX		8		9		А		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	Ą	192	Š	208	ą	224	Š	240
1	SP	129	٤	145	SP	161	±-	177	Į	193	Ń	209	į	225	ń	241
2	,	130	,	146	¢	162	2	178	Ā	194	Ņ	210	ā	226	ņ	242
3	SP	131	"	147	£	163	3	179	Ć	195	Ó	211	Ć	227	Ó	243
4	77	132	"	148	¤	164	_	180	Ä	196	Ō	212	ä	228	ō	244
5		133	•	149	SP	165	μ	181	Å	197	õ	213	å	229	õ	245
6	†	134	_	150	1	166	¶	182	Ę	198	Ö	214	ę	230	Ö	246
7	‡	135	_	151	§	167	٠	183	Ē	199	×	215	ē	231	÷	247
8	SP	136	SP	152	Ø	168	Ø	184	Č	200	Ų	216	Č	232	ų	248
9	*	137	TM	153	©	169	1	185	É	201	Ł	217	é	233	}	249
Α	SP	138	SP	154	Ŗ	170	ŗ	186	Ź	202	Ś	218	Ź	234	Ś	250
В	<	139	>	155	«	171	»	187	Ė	203	Ū	219	ė	235	ū	251
С	SP	140	SP	156	7	172	1 4	188	Ģ	204	Ü	220	ģ	236	ü	252
D		141	-	157	-	173	1/2	189	Ķ	205	Ż	221	ķ	237	Ż	253
E	~	142	c	158	®	174	34	190	Ī	206	Ž	222	ī	238	Ž	254
F		143	SP	159	Æ	175	æ	191	Ļ	207	ß	223]	239	•	255

Page 52 (WPC1258: Vietnamese)

HEX		8		9		Α		В		С		D		Е		F
0	€	128	SP	144	SP	160	0	176	À	192	Đ	208	à	224	đ	240
1	SP	129	"	145	i	161	±	177	Á	193	Ñ	209	á	225	ñ	241
2	,	130	,	146	¢	162	2	178	Â	194	?	210	â	226		242
3	f	131	"	147	£	163	3	179	Ă	195	Ó	211	ă	227	Ó	243
4	"	132	77	148	¤	164	`	180	Ä	196	Ô	212	ä	228	ô	244
5		133	•	149	¥	165	μ	181	Å	197	ď	213	å	229	ď	245
6	†	134	-	150		166	¶	182	Æ	198	Ö	214	æ	230	Ö	246
7	‡	135	_	151	§	167	•	183	Ç	199	×	215	Ç	231	÷	247
8	^	136	~	152	•	168	٦	184	È	200	Ø	216	è	232	Ø	248
9	*	137	TM	153	©	169	1	185	É	201	Ù	217	é	233	ù	249
Α	SP	138	SP	154	<u>a</u>	170	0	186	Ê	202	Ú	218	ê	234	ú	250
В	<	139	>	155	«	171	»	187	Ë	203	Û	219	ë	235	û	251
С	Œ	140	œ	156	7	172	1 4	188	`	204	Ü	220	_	236	ü	252
D	SP	141	SP	157	-	173	1/2	189	Í	205	ľ	221	ĺ	237	ľ	253
E	SP	142	SP	158	®	174	3 4	190	Î	206	~	222	î	238	₫	254
F	SP	143	Ϋ	159	_	175	i	191	Ϊ	207	ß	223	Ϊ	239	ÿ	255

Page 53 (KZ1048: Kazakhstan)

HEX		8		9		А		В		С		D		Е		F
0	Ъ	128	ħ	144	SP	160	0	176	A	192	Р	208	a	224	р	240
1	Ĺ	129	4	145	¥	161	+1	177	Б	193	С	209	б	225	С	241
2	,	130	,	146	¥	162	Ι	178	В	194	T	210	В	226	Т	242
3	ŕ	131	"	147	9	163	i	179	Γ	195	У	211	Γ	227	У	243
4	77	132	77	148	¤	164	θ	180	Д	196	Ф	212	Д	228	ф	244
5		133	•	149	θ	165	μ	181	Ε	197	X	213	е	229	Χ	245
6	†	134	-	150		166	¶	182	Ж	198	Ц	214	Ж	230	Ц	246
7	‡	135	-	151	§	167	٠	183	3	199	Ч	215	3	231	Ч	247
8	€	136	SP	152	Ë	168	ë	184	И	200	Ш	216	И	232	Ш	248
9	*	137	TM	153	©	169	No	185	Й	201	Щ	217	Й	233	Щ	249
А	Ъ	138	Љ	154	F	170	F	186	K	202	Ъ	218	K	234	Ъ	250
В	<	139	>	155	«	171	»	187	Л	203	Ы	219	Л	235	Ы	251
С	Ь	140	Њ	156	7	172	ə	188	М	204	Ь	220	М	236	Ь	252
D	K	141	Ķ	157	-	173	Ң	189	Н	205	Э	221	Н	237	Э	253
E	h	142	h	158	R	174	Ң	190	0	206	Ю	222	0	238	Ю	254
F	Ų	143	Ų	159	Υ	175	γ	191	Π	207	Я	223	П	239	Я	255

Page 255 (User-Defined Page)

HEX		8	(9		A		В	(С	[)	E	Ξ	F	=
0	Ç		É		á						Н		SP		SP	
	3	128		144		160		176		192		208		224		240
1	ü		æ		í						Ι		SP		SP	
		129		145		161		177		193		209		225		241
2	é		Æ		Ó						SP		SP		SP	
		130		146		162		178		194		210		226		242
3	â		ô		ú						SP		SP		SP	
		131		147		163		179		195		211		227		243
4	ä		Ö		ñ						SP		SP		SP	
		132		148		164		180		196		212		228		244
5	à		Ò		Ñ		Á		-		SP		SP		SP	
		133		149		165		181		197		213		229		245
6	å		û		Ğ		Â		â				SP		SP	
		134		150		166		182		198		214		230		246
7	Ç		ù		ğ		À		Ä		•		SP		SP	
		135		151		167		183		199		215		231		247
8	ê		ÿ		Ċ		İ		L		SP		SP		SP	
		136		152		168		184		200		216		232		248
9	ë		Ö		•		╣		ΙĒ		SP		SP		SP	
		137		153		169		185		201		217		233		249
Α	è		Ü		•				╨		SP		SP		SP	
		138		154		170		186		202		218		234		250
В	ï		Ø		•		╗		ī		SP		SP		SP	
		139		155		171		187		203		219		235		251
С	î		£		•		긔		ŀ		SP		SP		SP	
		140		156		172		188		204		220		236		252
D	ì		Ø		i		¢		=		SP		SP		SP	
		141		157		173		189		205		221		237		253
E	Ä		Ş		•		•		쀼		SP		SP		SP	
		142		158		174		190		206		222		238		254
F	Å		Ş		¤		•		•		SP		SP		SP	
		143		159		175		191		207		223		239		255

International Character Sets

Country						ASC	II co	de (H	lex)					
Country	23	24	25	2A	40	5B	5C	5D	5E	60	7B	7C	7D	7E
USA	#	\$	%	*	@	[\]	۸	,	{		}	~
France	#	\$	%	*	à	0	Ç	§	۸	,	é	ù	è	
Germany	#	\$	%	*	§	Ä	Ö	Ü	۸	`	ä	ö	ü	β
U.K.	£	\$	%	*	@	[\]	۸	`	{		}	~
Denmark I	#	\$	%	*	@	Æ	Ø	Å	۸	`	æ	ø	å	~
Sweden	#	¤	%	*	É	Ä	Ö	Å	Ü	é	ä	ö	å	ü
Italy	#	\$	%	*	@	0	\	é	۸	ù	à	ò	è	ì
Spain I	Pt	\$	%	*	(3)	i	Ñ	٠.	^	,		ñ	}	?
Japan	#	\$	%	*	(3)	[¥]	<	,	{		}	?
Norway	#	¤	%	*	É	Æ	Ø	Å	Ü	é	æ	ø	å	ü
Denmark II	#	\$	%	*	Έ	Æ	Ø	Å	Ü	é	æ	Ø	å	ü
Spain II	#	\$	%	*	á	i	Ñ	٠.	é	,	í	ñ	ó	ú
Latin America	#	\$	%	*	á	i	Ñ	ن.	é	ü	í	ñ	ó	ú
Korea	#	\$	%	*	(3)	[₩]	^	,	{		}	?
Slovenia/Croatia	#	\$	%	*	Ž	Š	Đ	Ć	Č	ž	š	đ	ć	č
China	#	¥	%	*	@	[\]	٨	`	{		}	~
Vietnum	<u>đ</u>	\$	%	*	@	[\]	٨	`	{		}	~
Arabia	#	\$	%	*	@	[\]	٨	`	{		}	~