EPSON

Document Capture Pro Server Authentication Edition

System Installation Guide

About this Guide

About this Guide

Using this Guide

Marks and Symbols



A Caution:

Instructions that must be followed carefully to avoid bodily injury.



Important:

Instructions that must be observed to avoid damage to your equipment.

Note:

Provides complementary and reference information.

Related Information

→ Links to related sections.

Screenshots Used in This Guide

Setting items may vary depending on products and setting conditions.

Operating System References

Windows

In this manual, terms such as "Windows Server 2025", "Windows Server 2022", "Windows Server 2019", "Windows Server 2016", "Windows Server 2012 R2", and "Windows Server 2012" refer to the following operating systems. Additionally, "Windows" is used to refer to all versions.

| | Microsoft ® | Windows Server® | 2025 | operating s | ystem |
|--|-------------|-----------------|------|-------------|-------|
|--|-------------|-----------------|------|-------------|-------|

- ☐ Microsoft® Windows Server® 2022 operating system
- ☐ Microsoft® Windows Server® 2019 operating system
- ☐ Microsoft® Windows Server® 2016 operating system
- ☐ Microsoft® Windows Server® 2012 R2 operating system
- ☐ Microsoft® Windows Server® 2012 operating system

Definition of the Terms Used in this Guide

The following terms are used in this guide.

About this Guide

Document Capture Pro Server AE

Document Capture Pro Server AE means Document Capture Pro Server Authentication Edition.

Document Capture Pro Server AE host computer

Document Capture Pro Server AE host computer indicates the computer which is installed Document Capture Pro Server AE.

Web Config (device's web page)

The web server that is built into the device. It is called Web Config. You can check and change the device's status on it using the browser.

Device

Refers to the scanner or multi-function device used by Document Capture Pro Server AE. It also includes scanners that use a Network Interface Panel or Network Interface unit.

Contents

Contents

| About this Guide | 5. Setting the System and Registering |
|--|---|
| Using this Guide | Information |
| Marks and Symbols.2Screenshots Used in This Guide.2Operating System References.2Definition of the Terms Used in this Guide.2 | Login.28Initial Configuration Screen.29Setting Each Item.29SMTP Server Settings.29LDAP Server Settings.31 |
| Setting Up | LDAF Server Settings |
| Setup Procedure 6 | 6. Operational Check |
| What You Need to Set Up | Device and Job Configuration |
| 1. Prepare Device and Checking | Registering a Job |
| Information | Assigning Job Groups to Devices |
| Related Hardware | Assigning a Job to User |
| Document Capture Pro Server AE Host | Register to an Authentication Card 47 |
| Computer | Checking Job Execution |
| Client Computer | 7. Check Before Practical Use of the |
| Checking Registration Information | System |
| Device | Registering All Devices |
| Card Reader | Registering Jobs for Production Environment 50 |
| Groups | Setting the Groups for Production Environment 50 |
| User | User Registration |
| Port number information | User Account Registration |
| 2. Operational Check of the | |
| Installation Environment | Uninstalling and Updating |
| Checking Essential Software | Uninstalling |
| Installing Essential Software | Check the user account 54 |
| Checking Connection for the Device | Uninstalling the back-end service application 54 Delete Document Capture Pro Server setting |
| 3. Devices Preparation | data |
| Settings the Device for Operational Check 17 | Log out from the front-end Web application 57 Stop the Web site for Document Capture Pro |
| Server Settings for the Device | Server |
| Connecting the Card Reader | Delete front-end Web application from IIS 57 |
| | Delete front-end Web application files |
| 4. System Installation | Uninstalling scanner drivers |
| Running the Installer | extensions module58 |
| Pre-Installation | Restart the Web site for Document Capture |
| Installing Document Capture Pro Server AE 24 | Pro Server |
| | |

Contents

| Solving Problems |
|--|
| Administrator pages and user pages do not appear60 |
| Cannot Authenticate a Card or Authentication |
| Is Slow |
| Repair Installation |
| User / Groups Relation Information Is Cleared |
| When a Scanner Job Is Restored 62 |
| Jobs are not displayed in the control panel of the |
| device |
| It takes time for the job to be displayed on the |
| control panel |
| Specify the server's IP address |
| Change the network metric values |
| Panel Messages |
| Appendix |
| Card Reader Compatible List |
| Roles and Features to be Installed 69 |
| Ports to be used |
| Windows Services and Executable Files |
| Document Capture Pro Server AE Work Folder 72 |
| Trademarks |
| Caution |

Setting Up

Setting Up

Setup Procedure

Follow the procedures below to set up this system.

| | Procedure | Operations | Approximate Work Time (mins.) |
|---|---|--|-------------------------------------|
| 1 | Preparing device and checking information Checking hardware and software requirements for Document Capture Pro Server AE host computer. | | 60 |
| | | Checking hardware requirements and the OS environment for the client computer. | |
| | | Checking requirements for the device, the card reader and authentication card. | |
| | | ☐ Acquiring the installer | |
| | | Checking and recording server settings and registration information. * | |
| 2 | Operational check of the | ☐ Checking the components | 10 |
| | installation environment | ☐ Checking the firewall and port | |
| | | Check the device, database, and client computer connections | |
| 3 | Devices preparation | Setting up the devices for operational check. | 5 |
| 4 | System installation | Installing and configuring the system and components using an installer. | 30 |
| | | When installing an SQL server. | |
| | | Installing and configuring the system and components using an installer. | 15 |
| | | When using an existing SQL Server | |
| 5 | Setting the system and registering information | Setting each server | 10 |
| 6 | Operational check | ☐ Registering the device | 15 |
| | | ☐ Registering job groups and job | |
| | | ☐ Assigning jobs to users | |
| | | ☐ Checking execution of job | |
| 7 | Check before practical use of the | ☐ Registering all devices | 60 |
| | system | ☐ User registration | |
| | | ☐ Notification email settings | |

^{*} By writing down the collected information on the Setup Information Collection Sheet (Excel file), the required information is covered and the setup will proceed smoothly.

Setting Up

What You Need to Set Up

The setting requires the following.

| | Items | Description |
|---|--|---|
| 1 | Device | Device compatible with Document Capture Pro Server AE and authentication function. |
| 2 | Card reader and the authentication card (optional) | Card reader and card that can connect to the device over a USB connection. This is not necessary if user authentication does not require an card reader. |
| 3 | Document Capture Pro Server AE host computer | A computer on which Document Capture Pro Server AE is installed. |
| 4 | Database server | Microsoft SQL Server 2014 Express is bundled with the installer, so you can build a new system on the Document Capture Pro Server AE host computer. |
| 5 | SMTP server | For sending email notifications. |
| 6 | Computer for administrator | A computer for managing Document Capture Pro Server AE. This allows you to access the Web page for the Document Capture Pro Server AE host computer. It is also used as a single user's computer. |
| 7 | Document Capture Pro Server AE installer | The installer for Document Capture Pro Server AE. |

1. Prepare Device and Checking **Information**

Check the preparations necessary to build an authentication system for Document Capture Pro Server AE, such as the device, usage conditions, and setting information.

Related Hardware

Document Capture Pro Server AE Host Computer

The following shows the system requirements for the computer being installed as the main system and the necessary components.

Hardware

Minimum system requirements

- ☐ CPU: 2.1 GHz or faster processor
- ☐ RAM: 4 GB or more
- ☐ Hard disk free space: 50 GB or more (Except for database capacity)
- ☐ Display: 1280 x 1024 or higher



A Caution:

- ☐ You cannot install this system on a computer being used for domain control.
- This system does not support a Multihomed computer environment. In this situation, address resolution may not be completed for the system.

Note:

Make sure the system configuration matches the current environment, such as the network communication speed, number of devices, number of users, and so on.

Operating system

The computer must be running any of the following Windows Server Operating System.

| os | Service packs | Edition |
|------------------------|---------------|------------------------------------|
| Windows Server 2012 | - | Essentials / Standard / Datacenter |
| Windows Server 2012 R2 | - | Essentials / Standard / Datacenter |
| Windows Server 2016 | - | Essentials / Standard / Datacenter |
| Windows Server 2019 | - | Essentials / Standard / Datacenter |
| Windows Server 2022 | - | Essentials / Standard / Datacenter |

| OS | Service packs | Edition |
|---------------------|---------------|------------------------------------|
| Windows Server 2025 | - | Essentials / Standard / Datacenter |

Note:

For Windows Server 2016, Windows 2019, Windows 2022, and Windows Server 2025, you must select the **Desktop Experience Server** option when installing the operating system. For Windows Server 2012 and Windows Server 2012 R2, you can install the desktop experience when installing this system.

Operation in a virtual environment

| This is also available under the following virtual environments, but performance may be degraded |
|--|
| ☐ Hyper-V: Versions in conjunction with a running OS |
| ☐ VMWare: vSphere Ver.4.1, 5.5, 6.0, 7.0 |

Required components, software

| .NET Framework 4.5 or later |
|--|
| Installed by default on Windows Server 2012 or later |
| Microsoft Web Deploy v3.6 or v4.0 |

Web server

The followings IIS (Microsoft Internet Information Services) versions are operated within this system.

| os | Version |
|--|---------|
| Windows Server 2012 | 8.0 |
| Windows Server 2012 R2 | 8.5 |
| Windows Server 2016, Windows Server 2019, Windows Server 2022, Windows Server 2025 | 10.0 |

Database server

The following database servers are supported.

| Microsoft SQL Server 2014 Express * |
|-------------------------------------|
| Microsoft SQL Server 2012 |
| Microsoft SQL Server 2014 |
| Microsoft SQL Server 2016 |
| Microsoft SQL Server 2019 |
| Microsoft SQL Server 2022 |

^{* :} Included in the package in this system.

SMTP server

The following email services support OAuth 2.0 authentication.

| Service name | Microsoft Exchange Online, Outlook.com |
|--------------|--|
|--------------|--|

For other email services, the following authentication and encryption methods must be supported.

| Security | Settings |
|-----------------------|---|
| Authentication method | No authentication, SMTP authentication, POP before SMTP |
| Encryption | No encryption, StartTLS, SMTP over TLS |

Directory services

This system can be synchronized with the LDAP server that manages the user account. The following services are supported.

| Service name | Version |
|------------------|---|
| Active Directory | Windows Server 2012, Windows Server 2012 R2, Windows Server 2016, Windows Server 2019, Windows Server 2022, Windows Server 2025 |
| OpenLDAP | Ver.2.3, Ver.2.4 |

Device (Scanner or Multi-function device)

Device (Scanner or Multi-function device) compatible with Document Capture Pro Server AE and authentication function

You need the device (scanner or multi-function device) that is compatible with the Document Capture Pro Server AE and the authentication function to use the authentication function on this system. You also can use the device (scanner or multi-function device) that is compatible with Document Capture Pro Server for operations such as registering scanners, jobs, and executing jobs from the registered device, but authentication-related functions such as user management, group management, and so on cannot be used.

Complete the network connection settings for the device (scanner or multi-function device) in advance. See the device's manual for details.

Card reader and authentication card

You can check information on card readers and authentication cards for which operations have already been confirmed on this manual.

Related Information

→ "Card Reader Compatible List" on page 67

Client Computer

This computer accesses the system's administrator page and user page.

Supported operating systems

Display size is 1280 x 1024 or higher and one of the following compatible browsers must be available.

Compatible browsers

Note:

You need to enable cookies and JavaScript in the browser.

| Browser | Version |
|-------------------|-----------------|
| Internet Explorer | 9 or later |
| Microsoft Edge | Ver.20 or later |
| Google Chrome | Ver.49 or later |
| Mozilla Firefox | 45 or later |
| Safari | 6.x or later |

Checking Registration Information

Before setting up this system, check the account, connected mail server, etc. By writing down the collected information on the Setup Information Collection Sheet (Excel file), the required information is covered and the setup will proceed smoothly.

System Configuration

Ask your respective server administrators about setting items for the server and the acquisition of email addresses.

A-1 - Document Capture Pro Server AE Log in Account

This is the configuration information of this system server (this system). The account information is used during service execution and registration of this system.

A-2 - SQL Server Setting Information

This is used to access the database. This is unnecessary if you are installing the SQL server during setup.

A-3 - Document Capture Pro Server AE System Account

This is the administrator account information for this system. This is necessary to access the administrator menu during setup.

A-4 - SMTP Server Setting Information

The system use this to send emails.

A-5 - LDAP Server Setting Information

This system uses this to acquire user information from the LDAP server. This is not necessary if you are not connecting to an LDAP server.

Device

B-1 - Device Information

This is device information used with this system.

Card Reader

C-1 - Card Reader Information

This is the card reader information used in the authentication system. The card reader should support the type of card used for the authentication card information.

C-2 - Card Information

This is the authentication card information used in the authentication system.

Groups

D-1 - Group Information

This is the group information for users of the system. Information of users that is managed by linking to an LDAP server is not necessary.

User

E-1 - User Information

This is the user account information for users of the system. Information of users that is managed by linking to an LDAP server is not necessary.

Port number information

Information on the port number used by Document Capture Pro Server AE can be found in the Appendix.


Related Information

→ "Ports to be used" on page 70

2. Operational Check of the Installation Environment

2. Operational Check of the Installation Environment

Checking Essential Software



- 2. Check the list of programs.
 - Make sure essential software are listed.
- 3. If they are not installed, download from the following Microsoft Web site.
 - □ .NET Framework 4.6 https://www.microsoft.com/en-US/download/details.aspx?id=48130
 - ☐ Microsoft Web Deploy 4.0
 - https://www.microsoft.com/en-US/download/details.aspx?id=106070

Installing Essential Software

Run downloaded installer, and then follow the on-screen instructions to install essential software.




Important:

If you have installed Microsoft Web Deploy 3.6, you need to restart the server on Windows Server 2012 and Windows Server 2012 R2.

2. Operational Check of the Installation Environment

Note:

If the following screen is displayed during installing the Web Deploy, select Typical.



Checking Connection for the Device

Check the connection between the Document Capture Pro Server AE host computer and the device. It is confirmed by trying to display the Web Config page for the device.

You need to enable cookies and JavaScript in the browser.

- 1. Run Internet Explorer on the computer that Document Capture Pro Server AE will be installed.
- 2. Enter the IP address for the device as shown below, and then press **Enter**.

http://192.0.2.111 (If the IP address is 192.0.2.111)


Note:

When accessing the administrator login page through SSL communication (https), a privacy and security warning page may be displayed. When you access the login page, a warning about the security certificate may be displayed. (The screen displayed and wording depend on the browser you are using.)

This happens when the browser attempts an SSL encrypted communication when the Web site is using a self-signed certificate. To avoid displaying this warning, use a certificate issued by a trusted certification authority.

2. Operational Check of the Installation Environment

3. If the Web Config menu is displayed, confirmation is complete. Close Web Config.



Note:

If the Web Config menu is not displayed, check the followings.

- ☐ The device is turned on.
- ☐ *The cookies and JavaScript are enabled.*
- ☐ *The IP address is correct.*

3. Devices Preparation

Settings the Device for Operational Check


Before registering devices on this system, the following device settings should be completed.

- ☐ Server settings for the device
- ☐ Connect card reader (When the card reader is used for user authentication)

Server Settings for the Device

Specify settings to connect the device to the system.


- Connect the device to same network as this system.
 See the manual supplied with the device for more details.
- 2. Open Web Config by entering device's IP address on browser of administrator's client computer.
- 3. Click **Log in** (or **Administrator Login**) and then enter the password to login to the detailed settings screen.



Note:

If you have not set an administrator password, see the product manual.

4. Click Scan (or Services) > Document Capture Pro.




- 5. Set each items as follows.
 - ☐ Mode:

Select Server Mode.

☐ Server Address:


Specify the computer that installed this system. You can specify IPv4, FQDN format, and host name.




For models displaying Authentication Settings, select **Enable** and proceed to step 11.

- 6. Click Next.
- 7. Confirm displayed contents, and then click **OK**.
- 8. After a moment, press F5 key and reload the Web Config.

9. Select **Product Security > Basic**.



10. Select On (Document Capture Pro Server AE) in Authentication.




- 11. Click Next.
- 12. Confirm displayed contents, and then click **OK**.
- After a moment, press F5 key and reload the Web Config.
 The settings complete when the product information screen is displayed.

Connecting the Card Reader

You can connect the card reader by using a USB cable. The following is an example of a document scanner.

1. Connect the USB cable for the card reader to the USB port.



2. Tap **Settings** > **Device Information** on the device's control panel.



3. Flick the screen, and then check that **Connected** is indicated with **Authentication Device Status**.



Note:

You can also confirm the status from **Status** > **Product Status** > **Card Reader Status** on the Web Config.

4. System Installation

Install components and this system.

Running the Installer

When this system is installed for the first time, the initial setup installs and configures the components. This step is skipped when repairing the installation.




Caution:

- □ Before starting the installation, close all anti-virus programs and running applications. If any applications are running, it may not be correctly installed.
- ☐ If SSL 3.0 IIS support is enabled, it is disabled when the program is installed and the computer needs to be restarted. If you do not want to restart after installation, disable SSL 3.0 IIS support before you start the installation.
- ☐ For Windows Server 2016, Windows 2019 and Windows Server 2022, you must select the Desktop Experience Server option when installing the operating system.
 - For Windows Server 2012 and Windows Server 2012 R2, you can install the desktop experience when installing this system. In that case, restart the computer after finishing installation certainly. If you do not want to restart the computer after installing this system, install the Desktop Experience in the computer from **Roles** and **Features** for Windows and then restart the computer beforehand.
- 1. Log in to the computer which you set up using the user name and the password decided by the *A-1 -Document Capture Pro Server AE Log in Account*.
- 2. Double-click Setup.exe to run the installer.

Note:

If the **Roles** and **Features** are not installed, the screen that is as following is displayed. In this case, click **Install** to add **Roles** and **Features** to Windows.

When installing the Desktop Experience, restart the computer after installing.



3. Check the End-User License Agreement, and then select I accept the terms in the License Agreement.



4. Click Install.

The Document Capture Pro Server AE installation starts.

Pre-installation menu is displayed when installing for the first time. Go to the next section.

If you are repairing an installation, go to the installation section for Document Capture Pro Server AE.

Related Information

→ "Installing Document Capture Pro Server AE" on page 24

Pre-Installation

Note:

If you close the installer and restart the computer, double-click Setup.exe to run the installer after the computer has restarted.

- 1. Specify the database you want to use, and then click **Next**.
 - ☐ Install SQL Server 2014 Express:


Select this if you want to build a database by installing SQL Server 2014 Express.

☐ Use existing SQL server:

Select this if you want to use an existing SQL server.

Note:

SQL Server 2014 Express is a new installation and database construction takes about 15 to 20 minutes.




- 2. Go to the steps indicated below according to the database that you selected in step 1.
 - ☐ Install SQL Server 2014 Express:

Go to step 3.

☐ Use existing SQL server:

Configure the following, and them click Next. Perform an access test to the database server.


| Specify the SQL server instance to use. | Specify the database by either entering it directly or by selecting using Browse . |
|--|--|
| Use the SQL Server that was previously installed in the Authentication Subsystem | Select this if you want to use an SQL server that was previously installed in the Document Capture Pro Server AE. Previously used login ID and the password are used. |
| Use SQL Server supplied by the customer | Select this if you want to use an existing SQL server. You need the login ID and password for the server. |



When the results are displayed, click \mathbf{OK} to select the SQL Server you want to use.

3. Click Next.

Installation and component setup starts. You cannot cancel this operation.



Note.

The following setup is performed here.

- ☐ Installation of SQL Server 2014 Express (when Install SQL Server 2014 Express is selected)
- ☐ Enable message queue (MSMQ) (Windows function)
- ☐ Enable Microsoft Internet Information Services (IIS) (Windows function)
- ☐ Create and bind self-signing certificate

Related Information

- → "Document Capture Pro Server AE Host Computer" on page 8
- → "Installing Document Capture Pro Server AE" on page 24

Installing Document Capture Pro Server AE

When repairing, the installer starts from this procedure.


Note:

The following settings and installation are performed here.


- ☐ Copying system files
- ☐ Access right setting of files and folders
- ☐ Setting of config files according to the installation environment
- ☐ *Registration to registry*
- ☐ Registration of Web application
- ☐ Registration of Windows services
- ☐ Registration of short cut
- ☐ Registration of MSMQ
- ☐ Creating a database
- ☐ Setting a firewall
- ☐ Disabling SSL3.0 of IIS

1. Click Next.

You can change the installation destination by clicking Change.



2. Specify the URL for the Web site for the Administrator page and the User page, and then click Next.



- 3. Enter the Administrator ID, Password, and Email Address decided in *A-3 Document Capture Pro Server AE System account*, and then click **Next**.
 - ☐ System ID (Administrator ID):

Enter the user ID between 1 and 256 characters.

You can use alphanumeric, symbol, space and additional Latin characters. See the following table for details.

☐ Password:

Enter the password between 1 and 128 characters.

You can use alphanumeric, symbol, space and additional Latin characters. See the following table for details.

☐ Email address

Enter the recipient email address which receive the email from this system.


Available characters

| SP* | ! | " | # | \$ | % | & | 1 | (|) | * | + | , | - | | / |
|-----|---|---|---|----|---|---|---|---|---|---|---|---|---|---|---|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | : | ; | < | = | > | ? |
| @ | Α | В | С | D | Е | F | G | Н | ı | J | К | L | М | N | 0 |
| Р | Q | R | S | Т | U | ٧ | W | Х | Υ | Z | [| \ |] | ۸ | _ |
| ` | a | b | С | d | e | f | g | h | i | j | k | I | m | n | o |
| р | q | r | S | t | u | v | w | х | у | Z | { | 1 | } | 2 | |
| À | Á | Â | Ã | Ä | Å | Æ | Ç | È | É | Ê | Ë | Ì | ĺ | Î | Ϊ |
| Đ | Ñ | Ò | Ó | Ô | Õ | Ö | Ç | Ø | Ù | Ú | Û | Ü | Ý | þ | ß |
| à | á | â | ã | ä | å | æ | ç | è | é | ê | ë | ì | í | î | ï |
| ð | ñ | ò | ó | ô | õ | ö | | Ø | ù | ú | û | ü | ý | þ | ÿ |

* Space character


The administrator account created here is registered as the built-in user.

You can change the administrator password and email address after setting up the system.



4. Click Install.

Installation starts, and then the progress meter is displayed.



- When the restart is required, restart the computer.
 When installation is complete, the complete message screen is displayed.
- 6. Click **OK**.

5. Setting the System and Registering Information

Make the initial settings for the server and systems that communicate with this system from the administrator's client computer.

Login

Login as the system administrator of the system, and make settings for each item.

1. Access the Web site you set while installing the Document Capture Pro Server AE from a browser on the administrator's client computer.

http://<Web site address that is set to IIS>/AuthSubSystemWeb/

01

https://<Web site address that is set to IIS>/AuthSubSystemWeb/


Example (In case that the IP address is 192.0.2.123):

http://192.0.2.123/AuthSubSystemWeb/

https://192.0.2.123/AuthSubSystemWeb/

Note

- ☐ When using the Document Capture Pro Server AE host computer, you can also access from Start menu > Epson Software > Document Capture Pro Server AE > Document Capture Pro Server AE.
- ☐ Enable JavaScript.
- 2. Enter the ID and password for *A-3 Document Capture Pro Server AE System account* set when installing this system, and then select (**Local**) as the domain.



3. Click **Log in**.

When you login, the initial configuration menu is displayed automatically.



Do not use your browser's navigation buttons, such as Back or Forward, otherwise Document Capture Pro Server AE may not operate correctly.


Initial Configuration Screen

Set the system and users related to the system. If you have not completed the setup, you cannot proceed to the operational check.

Depending on the item, you can skip the settings by pressing the skip button.

You can set the following items.

- ☐ SMTP server settings
- ☐ LDAP server settings




Setting Each Item

SMTP Server Settings

You need to make settings for the email sending server to send email to administrators and users from the system.

Click SMTP Server on the initial configuration menu.

2. Set each item.



See the following to make settings.

| Items | Description | | | |
|-------------------|--|--|--|--|
| Server Address | Enter the IP address or the host name of the SMTP server within 255 characters. | | | |
| Port Number | Enter the port number for the SMTP server (outgoing email server) with a number between 0 and 65535. The default number is 25. | | | |
| Secure Connection | Select the encryption method for the SMTP server from None , SSL/TLS , or STARTTLS . | | | |

| Items | Description | | | |
|-------------------------|---|--|--|--|
| Authentication Method | Select the authentication type for the SMTP Server. Setting content varies depending on the selected items. | | | |
| | SMTP Auth | | | |
| | □ Account: | | | |
| | The login ID for SMTP authentication. Enter within 255 characters. | | | |
| | □ Password: | | | |
| | The password for SMTP authentication. Select to enter a password. Enter within 255 characters. | | | |
| | POP before SMTP | | | |
| | □ Server Address: | | | |
| | Enter the IP address or host name for the email receiving server (POP 3 server) within 255 characters. | | | |
| | □ Port Number: | | | |
| | Enter the port number of the incoming email server with a number between 0 and 65535. The default number is 110. | | | |
| | □ Account: | | | |
| | The login ID for POP before SMTP authentication. Enter within 255 characters. | | | |
| | □ Password: | | | |
| | The password for POP before SMTP authentication. Select to enter a password. Enter within 255 characters. | | | |
| | SMTP Auth (OAuth 2.0) | | | |
| | ☐ Email services: | | | |
| | Select the Email service you want to use. | | | |
| | ☐ Reauthentication: | | | |
| | Select this if re-authentication is required, such as when authentication on the SMTP authentication server becomes invalid or communication fails. | | | |
| Email sender address | Set the email address used as the email sent from the system. | | | |
| Email recipient address | Enter the recipient email address for test transmissions. | | | |
| Send test email | Sends an email to the target address. | | | |
| ОК | Registers the settings to the system. | | | |

3. Click **Send test email**.

Sends an email to the target address.

4. Click **OK**.


You are returned to the system configuration menu.

LDAP Server Settings


Set when using an LDAP server.

You can register users that are managed by an LDAP server as Document Capture Pro Server AE users.

1. Click **LDAP server settings** on the initial configuration menu.



2. Set each item.



See the following to make settings.

Note:

 $\textit{If you want to use the organizational unit (OU) and attributes managed by the LDAP \textit{ server}, \textit{ set } \textbf{\textit{Group Settings}}. \\$

| Items | Description | | |
|-------------------|---|--|--|
| LDAP connection | Set whether or not to link to an LDAP server. | | |
| LDAP server type | Select the type of LDAP server from Active Directory and OpenLDAP . | | |
| Server Address | Enter the host name or IP address of the LDAP server within 255 characters. | | |
| Port Number | Enter the port number of the LDAP server with a number between 0 and 65535. | | |
| Secure Connection | Select the encryption method for the LDAP server from None , SSL/TLS , or STARTTLS . | | |


| Items | Description | | | |
|-------------------------|---|--|--|--|
| Authentication protocol | Select the authentication protocol from PLAIN , DIGEST-MD5 , or GSSAPI (Kerberos V5) . | | | |
| Base DN | Enter the identifier of the search base of the directory service. | | | |
| | Example: DC = Idap, DC = xxx, DC = com | | | |
| Anonymous access | Select whether or not to search using anonymous authentication. | | | |
| Administrator DN | Enter the identifier of the LDAP server administrator. | | | |
| | Example: CN = myldap, OU = mySercice, DC = ldap, DC = xxx, DC = com | | | |
| Administrator password | Enter the administrator password used during the search. | | | |
| | Select this to enter a password. | | | |
| Search filter | Specify the search criteria when acquiring user information. | | | |
| | Example: cn=Epson Tarou | | | |
| | employeeNumber>=1000 | | | |
| | (&(cn=Tarou)(sn=Epson)) | | | |
| User Attribute | Associate the attributes for registration information (User ID , Full name , Email address , Card ID) with the attributes for the system's LDAP server. Select the attributes from the Select user attributes menu. | | | |
| | The default value varies depending on the type of LDAP server. | | | |
| Select user attributes | Open the Select user attributes menu. | | | |
| Group Settings | Select the creation unit for the system's user attributes. When using an organization unit (OU) for LDAP, enter the acquired hierarchy. If you want to use the LDAP attributes enter the attribute name. All levels are used if you specify "0" as the hierarchy. | | | |
| LDAP Synchronization | Set the interval to synchronize user information on the LDAP server with this system. | | | |
| | You cannot change settings that do not synchronize automatically from the configuration menu by default. To change these settings, you need to set them again after setting all the configuration items on the configuration menu. | | | |
| Test connection | Check the connection test to the LDAP server. | | | |
| ОК | Registers the settings to the system. | | | |

3. Click **Test connection** to perform a connection test to the LDAP server and then a search test.


The results are displayed on the LDAP Connection Test menu. Some users retrieved by the **Search filter** setting are displayed.

- 4. After checking the content, click **OK** to close the LDAP Connection Test menu.
- 5. Click **OK**.

6. Click **Finish** on the initial configuration menu.



The administrator's dashboard is displayed.



6. Operational Check

6. Operational Check


Check that the user can log in with an authentication card, and scan on this system.

Note

You can also check operations for the Document Capture Pro Server AE host computer. In that case, "administrator's client computer" should read "Document Capture Pro Server AE host computer."

Device and Job Configuration

The following shows the data structure of Document Capture Pro Server AE devices and jobs.



| Registered Device | Job Group Associated with the Device | Jobs Displayed on the Panel (Jobs Associated with a Job Group) |
|-------------------|--------------------------------------|--|
| Sc-01 Document | JG-01 (Planning Division Job Group) | Job-A (Save as PDF and transfer to folder) |
| Scanner | | Job-B (Save as JPEG and attach to email) |
| Sc-02 Document | | Job-C (Transfer scan results to printer) |
| Scanner | | Job-D (Save as PDF and transfer to web folder) |


6. Operational Check

| Registered Device | Job Group Associated with the Device | Jobs Displayed on the Panel (Jobs Associated with a Job Group) | | |
|---------------------------|--------------------------------------|--|--|--|
| Sc-03 Document Scanner | JG-02 (Sales Division Job Group) | Job-A (Save as PDF and transfer to folder) | | |
| Scanner | | Job-C (Transfer scan results to printer) | | |
| Mf-01 MFP | JG-03 (General Affairs Division Job | Job-E (Save as JPEG and attach to email) | | |
| | Group) | Job-F (Save as PDF and transfer to web folder) | | |


The values in parentheses are setting examples.

Registering the Devices

- 1. Select **Device Management** from the menu.
- 2. Click Add New Scanner.



3. Set each item.



| Items | Description |
|-------------------------|--|
| Scanner Name | Set the device name. You can enter up to 30 characters. |
| | You cannot use a name that has already been registered. |
| Location | Enter the location of the device if necessary. |
| Driver | Select the device's model name. |
| | You cannot change the model name when using the edit or duplicate functions. |
| IP Address or Host Name | Set the device's IP address or host name. |
| Check Connection | Performs a connection test to the device. |
| Authenticated | Displayed when the device which supports the authentication function is selected in Driver . |
| | Select when using the authentication function that is required to log in to the device. |
| | Entering the password that is set to the device on Password . |
| | If you do not set the administrator password to the device, leave here blank. |
| Protect with Password | This is displayed when Authenticated is disabled. |
| | When this is selected, you must enter a password when entering the job selection screen from the device's control panel. |
| Password | Set a password. You can enter 1 to 8 characters. You can use alphanumeric characters and the following symbols. |
| | !, @, #, \$, %, ^, &, *, (,), +, =, -, _, /, \ (backslash), (space) |
| | If you do not specify this, leave it blank. |

4. Click Check Connection.

Check that the **Success** is displayed next to the **Check Connection**.



Check the following if the **Failure** is displayed.

- ☐ The computer was restarted when Desktop Experience was installed.
- ☐ The mode settings (the server settings) on the device are complete.
- ☐ The correct IP address for the device has been entered.
- ☐ The port number used by this system allows communication between the device and the server.

5. Click Save.

You are returned to the **Device Management** screen.

If you cannot register the device you want, check that the filled items are correct.

Related Information

→ "Server Settings for the Device" on page 17

Registering a Job

Register a job to the system for an operational check. Save the job that is the scanning result to the folder for checking system operation.


See Document Capture Pro Server AEAdministrator's Guide for more details. You can read it by clicking ②.

1. Click **Job Management** from the menu.


Job Management screen is displayed.

2. Click **Add Job Group**.


Add Job Group screen is displayed.




3. Enter any name in **Job Group Name**.



4. Select the device name that is registered on this system in **Driver**.




- 5. Click Save.
- 6. Click Add New Job.



Add New Job screen is displayed.


7. Enter any job name in **Job Name**.



It is displayed on the device's control panel which is set on **Job Name**.


8. Specify each items in 1. Scan.

It is okay to keep the current values since this is for an operational check.




9. Click **2. Save** or ...

10. Specify each items in 2. Save.



11. Click **3. Index** or


12. Specify each items in 3. Index.



- 13. Click **4. Send** or _____.
- 14. Select Folder from Destination Type.



15. Select [New Destination] from Destination Type.




16. Enter each items.

You can check that scanning result is sent to specified folder by clicking Check Connection.

Note

Enter the full path for the User Name.


- ☐ When joining a domain: {domain}/{User Name}
- ☐ When operating in a workgroup: {host name}/{User Name} You can replace the host name with an IP address.



If the connection fails, check that folder path or access rights are set correctly.


17. Click Save.

Job List screen is displayed. Check that created job is registered in the list.



18. Click Back to Job Management.

Job Management screen is displayed. Check that created job group is registered, and then number of created job is displayed in **Number of Registered Jobs**.



If you are creating several jobs in the same job group, click **Job List** and then make these jobs.

Assigning Job Groups to Devices

Assigning a registered job group to each device.


This explanation assumes that the devices, job groups and jobs are already registered.

- 1. Select **Device Management**.
- 2. Click the link for the Scanner Name.




3. Select the **Device Information** tab.

Select the card reader name or card ID format that is connected to the device.



4. Select the **Job Group** tab.



- 5. Select the job group in the pull down menu.
- 6. Click Save

Return to the Device Management screen.

Assigning a Job to User

Assign jobs to a user to enable only the jobs that are permitted in advance.

Assigned jobs are listed on the device's control panel.

Use the administrator's account here for operational check.


1. Select **Users** > **User List** from the menu.

2. Click the link for the **User ID**.

Select the **User ID** that is set on *A-3 - Document Capture Pro Server AE System account*.



3. Select the **Job Assignment** tab.



- 4. Select the job groups in the pull-down menu.
- 5. Select the jobs you want to assign and then click

Note:

You can check the status of the job assignment by clicking **Checking Status** as necessary.

6. Click **OK**

7. Click **OK** on the confirmation screen.

Return to the user list screen.

Register to an Authentication Card

This is required only when using user authentication with the card reader.

Register the authentication card, and check the operations for the card reader.



Caution:

For the card reader connected to the device, use the product with the same model number as the card reader that was used to authenticate the card. If the card reader is different, you may not be able to log in.

1. Hold the authentication card over the card reader.

The unregistered card settings menu is displayed on the device's control panel.



Note:

When the device is in power-saving mode, it may take some time to recognize the authentication card. Please your authentication card again.

2. Tap Register.



3. Enter the ID and password of *A-3 - Document Capture Pro Server AE System account* in the control panel of the device, and then select (**Local**) from the domain.



4. Press Register.



Authentication is performed, and the registration completion menu is displayed.

Checking Job Execution


Check that specified job is executed.

1. Set scanned original on the device.



- 2. Log in to the device by one of the following ways.
 - ☐ Holding the authentication card over the card reader.

☐ Entering the **User ID** and **Password**, select (**Local**) from the domain, and then tap **Log in**.



- 3. Tap Job Name which you registered.
 - If you are assigned only one job, job selection screen is skipped. Go to next step.
- 4. Tap Start.



The device starts scanning.

Check that the scanning result is saved in the specified location.

7. Check Before Practical Use of the System

Make the settings necessary for practical use. Make these settings from the administrator's client computer.

Note:

You can also make settings on the Document Capture Pro Server AE host computer. In that case, "administrator's client computer" should read "Document Capture Pro Server AE host computer".

Registering All Devices

Register all devices you want to install.

- 1. Connect the device you want to register to the network.
- 2. Open a device's Web Config from administrator's client computer.
- 3. Make the server settings for connecting to this system from **Services** > **Document Capture Pro**.
- 4. Connect card reader to the device if necessary.
- 5. Log in to the administrator's page, and then edit registering and information for the device from the **Device Management**.
- 6. Register by repeating the steps above.

Related Information

- → "Settings the Device for Operational Check" on page 17
- → "Registering the Devices" on page 36
- → "Assigning Job Groups to Devices" on page 44

Registering Jobs for Production Environment

Create job groups and jobs necessary for the operation. See *Document Capture Pro Server AE Administrator's Guide* for detail of job settings.

Setting the Groups for Production Environment


By default, **Unassigned users** are registered to a group. When you set **Unassigned users**, the settings are copied and applied to the group.

When you make settings before synchronizing, they are also applied to groups that are managed by linking to an LDAP server.


1. Select **Group** on the menu.

If you are not logged in to the administrator page, log in with an account from A-3 - Document Capture Pro Server AE System account.

2. Click **Unassigned users** from **Group** in the Group list.



3. Click Job Assignment.



- 4. Select job group from the **Job Group**.
- 5. Select the job that you want to activate, and then click

Note:

You can confirm device name that related job in [Enabled Jobs] by clicking Checking Status.

- 6. Click OK.
- 7. Click **OK** on the completion menu.

User Registration

Register users to the system before starting operations.

You can register users directly by using this system, or register accounts managed by an LDAP server.

User Account Registration


Register users directly to this system.

If you have a lot of users, you can register in bulk by using a CSV file. See *Document Capture Pro Server AE Administrator's Guide* for details.

1. Select **Users** on the menu.

Login using the account in A-3 - Document Capture Pro Server AE System account Information if you are not already logged in.

- 2. Click Add.
- 3. Set each item.



See Document Capture Pro Server AE Administrator's Guide for details on each item.

4. Click OK.

Synchronizing with an LDAP Server

If you want to register a user account managed by an LDAP server, synchronize the LDAP server with this system's server.

- 1. Select **System Settings** > **LDAP Server** from the menu.
 - Login using the account in A-3 Document Capture Pro Server AE System account if you are not already logged in.
- 2. Select the **Sync.** tab, and then click **Execute**.
 - Synchronization starts, and the synchronization results are displayed.
- 3. Click **OK**.

Uninstalling and Updating

Uninstalling

Check the user account

☐ Message queue (MSMQ)

☐ Microsoft Internet Information Services (IIS)


You need to log on to Windows Server as an administrator or as a member of the Administrators group.

Uninstalling the back-end service application


| Make sure you backup your data and settings before uninstalling. |
|--|
| See the Document Capture Pro Server AEAdministrator's Guide for details. |
| If you want to uninstall the system, you must uninstall the following two programs. |
| ☐ Authentication Subsystem |
| ☐ Document Capture Pro Server |
| Note: ☐ The following software and components are not uninstalled. ☐ .NET Framework ☐ SQL Server ☐ Microsoft Web Deploy ☐ Desktop Experience |
| ☐ For the following software and components, only the files and data used by this system are deleted. |
| |

- 1. Log in to the Document Capture Pro Server AE host computer as an administrator.
- 2. Click Control Panel > Uninstall a program, and then open Programs and Features.


3. Select Document Capture Pro Server, and then click Uninstall.




- 4. Follow the on-screen instructions.
- 5. Select Authentication Subsystem, and then click Uninstall.
- 6. Follow the on-screen instructions.
- Click Remove.



8. Select whether or not to delete the system logs and system backup, and then click Next.





9. Select whether or not to delete the database, and then click **Next**.



10. Click Remove.

Uninstallation starts.





11. Click Close.

Delete Document Capture Pro Server setting data

Follow the path below and delete the DCPS folder.

 $\% System Drive \% \ Program Data \ Epson \ DCPS$

Log out from the front-end Web application

After uninstalling Document Capture Pro Server, if you want to redeploy it on the same computer, make sure that the user is logged out.

If you have not checked that the user is logged out, stop the Web site, and then wait for more than 30 minutes until entering the command to redeploy the software.

Stop the Web site for Document Capture Pro Server

- 1. Click **Administrative Tools**, **Internet Information Services (IIS) Manager** from the Start menu to run IIS Manager.
- 2. Click your computer name from the pane on the left.
- 3. Expand the **Sites** directory, right-click your Web site name, select **Manage Web Site**, and then click **Stop**. The default name is **Default Web Site**.

Delete front-end Web application from IIS

1. Run IIS Manager.

- 2. Click your computer name from the pane on the left.
- 3. Expand the **Web Sites** directory, expand your Web site name, right-click the Document Capture Pro Server folder, and then click **Remove**.
- 4. If a confirmation dialog is displayed, click Yes.

Delete front-end Web application files

- 1. Run IIS Manager.
- 2. Click your computer name from the pane on the left.
- 3. Expand the **Web Sites** directory, right-click your Web site name, and then click **Explore**. The default name is **Default Web Site**.
- 4. In the window that opens, delete the Document Capture Pro Server folder.

Uninstalling scanner drivers

- 1. Open **Programs and Features** from Control Panel.
- 2. Select **EPSON Scan Server Component**, and then click **Change/Remove**.
- 3. Follow the on-screen instructions.
- 4. Select **Epson Scan 2 Server Component**, and then click **Change/Remove**.
- 5. Follow the on-screen instructions.

Uninstalling the EPSON Scan PDF extensions module

- 1. Open Programs and Features from Control Panel.
- 2. Select **EPSON Scan PDF Extensions**, and then click **Remove**.
- 3. Follow the on-screen instructions.

Restart the Web site for Document Capture Pro Server

- 1. Click **Administrative Tools**, **Internet Information Services (IIS) Manager** from the Start menu to run IIS Manager.
- 2. Click your computer name from the pane on the left.
- 3. Expand the **Sites** directory, right-click your Web site name, select **Manage Web Site**, and then click **Start**. The default name is **Default Web Site**.

Updating the System

The product is updated to improve functions, increase quality, and so on. To update, follow the instructions provided by the updated version.

Administrator pages and user pages do not appear

Check the following.

- ☐ Cookies are enabled in your browser.
- ☐ JavaScript is enabled in your browser.
- ☐ If "A system error has occurred." is displayed, make sure the service is running normally.


Cannot Authenticate a Card or Authentication Is Slow.

Check that the proxy settings for the Document Capture Pro Server AE host computer are correct.

Repair Installation

If the system does not start-up, or operations become unstable, and so on, you may be able to fix the problem by performing a repair installation. The repair installation overwrites system files while leaving settings and registration information untouched.

- 1. Log in to the Document Capture Pro Server AE host computer as an administrator.
- 2. Click Control Panel > Uninstall a program, and then open Programs and Features.
- 3. Select Authentication Subsystem, and then click Uninstall.




4. Follow the on-screen instructions.


5. Click **Next** on the following menu.



6. Click **Repair**.



7. Click Repair.



8. Click Close.

9. Reboot the computer if necessary.

User / Groups Relation Information Is Cleared When a Scanner Job Is Restored

Did you restore only the scanner job?

You need to restore setting files and the database to relate a job and user/group. If you restore only the scanner job, user/group relation information is not restored.

Jobs are not displayed in the control panel of the device

| Check the following. |
|--|
| ☐ Is the port used by Document Capture Pro Server AE open? |
| Jobs are displayed on the operation panel by communicating job information between the device and the server on which Document Capture Pro Server AE is installed. Make sure that port 2968, which is used for job information communication, is open. |
| ☐ Is a firewall blocking communication for job information? |
| If you are using a different firewall than the server on which Document Canture Pro Server AF is installed |

If you are using a different firewall than the server on which Document Capture Pro Server AE is installed, dynamic ports may be used for responses from the server. Allow the firewall to pass through dynamic ports, or use only port 2968 configured on the server.

☐ Is a router that supports the NAT (Network Address Translation) function used?

This system does not support routers with the NAT function. Make sure that you can communicate using a route that does not go through a router.

The IP address of the server on which Document Capture Pro Server AE is installed is used to respond to job information. If communication between the device and the server goes through a router that supports the NAT function, job information cannot be acquired because the IP address of the server cannot be tracked.

It takes time for the job to be displayed on the control panel

| If the server running Document Capture Pro Server AE has multiple network interfaces, the server will not |
|---|
| respond until communication with the network interface that is not communicating has timed out. Use the |
| following method to prioritize the network interface used to communicate with the device. |

| _ | Specify the server's IP address |
|---|---------------------------------|
| | Change the network metric value |

Specify the server's IP address

This section explains how to specify the server's IP address in the configuration file so that communication is prioritized between Document Capture Pro Server AE and the device.

This method is available for Document Capture Pro Server AE version 3.0.12 and later.

Select Start menu > Windows Administrative Tools > Services, or Control Panel > System and Securities >
Administrative Tools > Services.

Services on Windows services starts.

2. Select **DCPSNWService**, right-click, and then select **Stop**.

The DCPSNWService on Windows service stops.

3. See the following example and use a text editor to create a file that specifies the server's IP address on which Document Capture Pro Server AE is running.

| Example when the IP address is "192.0.2.0" (IPv4): |
|--|
| [Server] |
| IPAddress=192.0.2.0 |
| Example when the IP address is "2001:0db8:1234:5678:90ab:cdef:0000:0000" (IPv6): |
| [Server] |
| IPAddress=2001:0db8:1234:5678:90ab:cdef:0000:0000 |
| |

- 4. Name the file EPNSMs.ini, and then save the file.
- 5. Copy EPNSMs.ini to \Program Files(x86)\Epson Software\Document Capture Server\.
- 6. Select **DCPSNWService** in **Services** on Windows services, right-click, and then select **Start**.

DCPSNWService on Windows services starts.

Change the network metric values

Change the metric value of the network interface so that communication is prioritized between Document Capture Pro Server AE and the device.

Checking network interface metric values

This section shows you how to use PowerShell to view metric values for network interfaces. This section uses Windows Server 2019 as an example.

If multiple network interfaces are enabled on the same computer, the network interface with the lower metric value is given priority for communication.

1. Right-click on the Start menu and select Windows PowerShell.

2. Type **Get-NetIPAddress** on the command line and press Return.

Information about the address of the network interface is displayed.

You can identify the network interface from the **IPAddress** and check the adapter name for that network interface from **InterfaceAlias**.

3. On the command line, type Get-NetIPInterface and press Return.

Information about the network interface is displayed.

Find the adapter from **InterfaceAlias**. The value in **InterfaceMetric** in that row is the metric value for the network interface.

Changing the network metric value (Windows)

Change the value of the network metric to change the priority of the network interface. This section uses Windows Server 2019 as an example.

- 1. From Control Panel > Network and Internet > Network and Sharing Center, click Change Adapter Settings.
- 2. Right-click the adapter icon for which you want to change the network metric and select **Properties**.
- 3. Select Internet Protocol Version 4 (TCP / IPv4) (or Internet Protocol Version 6 (TCP / IPv6) for IPv6) and click Properties.
- 4. Click **Advanced Settings**.

The TCP/IP advanced settings screen is displayed.

- 5. Uncheck the **Automatic metric** on the **IP Settings** tab (**General** tab for IPv6).
- 6. Set the metric value for the **Interface metric** in single-byte numbers, click **OK**, and then click **Close**.
- Set other network adapters in the same way.
 Set the high-priority network interface to a value smaller than the low-priority network interface.

Panel Messages

As well as errors displayed on the Web page, you may receive the following messages.

| Message | Cause | Solution | | | |
|---|---|---|--|--|--|
| Unregistered ID Card. Ask your administrator to register an ID card. (Error Code: XX) | ID card is not registered. (In case that Allow users to register authentication cards is not enabled on System Settings > Basic Settings) | Permit the card registration for users. Register the ID card from Users > User List > Basic Information. | | | |
| Invalid authentication. Try it again. (Error Code: XX) | Authentication information does not match the registered user. | Check that the User ID , Password , or ID Number is correct. | | | |

| Message | Cause | Solution |
|---|--|---|
| Cannot add a temporary ID card to registration. (Error Code: XX) | Temporary ID card is not expired. | ☐ Delete the current temporary card ID. |
| | | ☐ Wait until the current temporary card has expired. |
| A system Error has occurred on the server. Ask your administrator. (Error Code: XX) | Failure to connect or read/write to the database server. | If the error has not resolved, restore the database. If it still hasn't resolved, contact your dealer. |
| Failed to connect to server. Please check the network connection. | Connection error between the device and the server may occur. | Check that the device is connected to the network. |
| | It is also displayed when the token does not match. | Make sure the Document Capture Pro Server AE host computer is turned on, and it works correctly. |
| | | If the error is displayed on Dashboard, follow the on-screen instruction. |
| Cannot scan because of a client mode. Change to a server mode. | Mode settings for the device is set to Client Mode . | Switch to Server Mode in one of the following ways. |
| | | On device's control panel, access to Settings >Document Capture Pro. |
| | | ☐ On device's Web Config, access to Services > Document Capture Pro. |
| | | On the administrator's page for this system, select the device on the Device Management and then click Send to send the settings information to device. |
| Authentication Settings on a server is not completed. Ask your administrator. | device registration does not complete on Document Capture Pro Server AE | On the administrator's page for this system, access to Device Manage-ment and complete the settings. |

| Message | Cause | Solution |
|--|---|---|
| The address of Document Capture Pro Server is incorrect. Enter a correct one. | The address of Document Capture Pro Server AE has been changed. Or regis- tered device is deleted on this system. | Set up the address for the Document Capture Pro Server AE host computer in one of the following ways. |
| | | On device's control panel, access to Settings >Document Capture Pro. |
| | | On device's Web Config, access to Services > Document Capture Pro. |
| | | Register the device to this system from the Device Management on the administrator's page. |
| | | On the administrator's page for this system, select the device on the Device Management and then click Send to send the settings information to device. |

Appendix

Card Reader Compatible List

This list does not guarantee operations for the card readers in the list.

Yes: Supported (The ID information can be read with standard card reader settings.)

No: Not Compatible

| Maker | Model | Model | | | Authentication card | | | | Authentication card | | | | | | |
|-------------|------------------------------------|--|---------------|------------|---------------------|-------------------|---------------|-----------------|-------------------------------------|---------------|--|--|--|--|--|
| | | Num- ber | HID Global | DMZ | MIF | ARE | Feli | Ca™ | IEC/ ISO14 | | | | | | |
| | | | iClass | EM40 02 | Clas- sic | Ultra- light | Stand- ard | Lite/ Lite-S | (Type B) Com- pli- ance | | | | | | |
| RF IDEAS | pcProx Plus | RDR-80 081AK U | Yes | Yes*1 | Yes*1 | Yes*1 | No | No | No | Key- board | | | | | |
| RF IDEAS | pcProx | RDR-70 81BKU | Yes*1 | No | Yes | Yes | No | No | No | Key- board | | | | | |
| RF IDEAS | pcProx | RDR-75 81AKU | Yes | No | Yes*1 | Yes ^{*1} | No | No | No | Key- board | | | | | |
| ELATEC | TWN3 MIFARE | T3DT- MB2BE L T3DT- MB2WE L | No | No | Yes | Yes | No | No | No | Key- board | | | | | |
| ELATEC | TWN3 MIFARE NFC | T3DT- FB2BEL T3DT- FB2WE L | Yes | No | Yes | Yes | Yes | Yes | Yes | Key- board | | | | | |
| ELATEC | TWN4 MULTI- TECH | T4DT- FB2BEL -PI T4DT- FB2WE L-PI | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board | | | | | |
| ELATEC | TWN4 Multi- Tech 2 BLE-PI | T4LK- FB4BLZ -PI | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board | | | | | |

| Maker | Model | Model | Authentication card | | | | | | | Mode |
|---------------|------------------------------------|--|---------------------|------------|--------------|-----------------|---------------|-------------------|-------------------------------------|-----------------|
| | | Num- ber | HID Global | DMZ | MIF | ARE | Feli | Ca™ | IEC/ ISO14 | |
| | | | iClass | EM40 02 | Clas- sic | Ultra- light | Stand- ard | Lite/ Lite-S | (Type B) Com- pli- ance | |
| ELATEC | TWN4 Slim | T4QC- FC3B7 | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board |
| HID Global | OMNI- KEY 5427 | OMNI- KEY542 7CK OMNI- KEY542 7CK gen2 | Yes | Yes | Yes | Yes | Yes | No | Yes | Key- board*1 |
| ACS | ACR122 U | ACR122 U | No | No | Yes*2 | Yes*2 | Yes | No | Yes*2 | PC/SC |
| ACS | ACR125 2 | ACR125 2 | No | No | Yes*2 | Yes*2 | Yes | Yes | Yes*2 | PC/SC |
| Sony | PaSoRi | RC- S330/S | No | No | Yes*2 | Yes*2 | Yes*2 | Yes*2 | Yes*2 | PaSoRi |
| Sony | PaSoRi | RC- S380/P RC- S380/S | No | No | Yes*2 | Yes*2 | Yes*2 | Yes*2 | Yes*2 | PaSoRi |
| DMZ | Leitor RFID Univer- sal | DMZ00 8 | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board |
| DMZ | Leitor RFID Mul- ti-125 | DMZ08 7 | No | Yes | No | No | No | No | No | Key- board |
| DMZ | Leitor RFID Mifare | DMZ08 8 | No | No | Yes | Yes | No | No | No | Key- board |
| DMZ | Bio- metric & RFID Reader | DMZ07 3 | No | Yes | No | No | No | No | No | Key- board |
| inepro | SCR708 | SCR708 | Yes*1 | Yes*1 | Yes*1 | Yes*1 | Yes*1 | Yes ^{*1} | Yes ^{*1} | Key- board |
| Y Soft | YU0308 8 001 | MU038 8 | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board |

| Maker | Model Model | Model | | Authentication card | | | | | | | |
|--------------------------------------|------------------------------------|---------------------------------|-------------|---------------------|--------|------------|--------------|-----------------|---------------|-----------------|-------------------------------------|
| | | | Num- ber | HID Global | DMZ | MIF | ARE | Feli | Ca™ | IEC/ ISO14 | |
| | | | | | iClass | EM40 02 | Clas- sic | Ultra- light | Stand- ard | Lite/ Lite-S | (Type B) Com- pli- ance |
| Carta- dis | TCM3 Carta- dis MiFare Card Reader | ZTCM3- MIFARE | No | No | Yes | Yes | No | No | Yes | Key- board | |
| MICI Net- work Co., Ltd. | EM & Mifare Card Reader | mCR-6 00 | No | No | Yes | Yes | No | No | Yes | Key- board | |
| NT- ware | MiCard Multi- Tech4- Pl | T4DT- FB4WU F-PI | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Key- board | |
| NT- ware | MiCard Plus-2- V2 | RDR-80 081AG U- NT2-20 | Yes*1 | Yes*1 | Yes*1 | Yes*1 | No | No | No | Key- board | |
| NT- ware | MiCard V3 Mul- ti | MiCard V3 Mul- ti | Yes | Yes | Yes | Yes | Yes | Yes | No | Key- board | |

You need to change the settings of the card reader by using the proprietary software provided by the card reader maker. *1

Roles and Features to be Installed

| The exetem | inctalle the | following | Dolos and | Features on | Windows |
|------------|--------------|-----------|-----------|-------------|---------|
| The system | installs the | TOHOWING | Koles and | reatures on | windows |

☐ Roles: Web Server (IIS)

☐ Features: Desktop Experience



A Caution:

When installing Desktop Experience, restart the computer.

If you need to use data in a particular area in the card other than the standard ID of the card as an authentication ID by configuring product settings, please contact your Epson partner or local representative for more information about a way to set up the product.

Ports to be used

| Sender (Client) | Target (Server) | Protocol | Port | Usage | |
|---|---|------------------------|---------------------|--|--|
| Client Computer (Browser) | Document Capture Pro Server AE host computer | HTTP (TCP) HTTPS (TCP) | 80 ^{*1} | User, Administrator menu | |
| Document Capture Pro Server AE host computer | Device | HTTPS (TCP) | 443 | Authentication, usage history acquisition, use restriction setting | |
| Document Capture Pro Server AE host computer | Device | SNMP (UDP) | 161 | Device discovery, Device information acquisition | |
| Device | Document Capture Pro Server AE host computer | HTTPS (TCP) | 443*2 | Device panel display | |
| Document | SQL Server | SQL (TCP) | 1433 | SQL server connection | |
| Capture Pro Server AE host computer | | SQL (UDP) | 1434 | | |
| Document Capture Pro | LDAP Server | LDAP (TCP) | 389 ^{*4} | User information acquisition | |
| Server AE host computer | | | 636*3*4 | | |
| Document Capture Pro | SMTP Server | SMTP (TCP) | 25 ^{*5} | Email transmission | |
| Server AE host computer | | | 465 ^{*3*5} | | |
| Computer | | | 587 ^{*6} | | |
| Document Capture Pro Server AE host computer | Cloud services | HTTPS (TCP) | 443 | SMTP authentication | |
| Document Capture Pro | POP Server | POP (TCP) | 110 ^{*5} | POP before SMTP connection | |
| Capture Pro Server AE host computer | | | 995 ^{*3*5} | | |
| Document Capture Pro Server AE host computer | Device | Epson unique (TCP) | 1865 | Scan data and Job information | |
| Document Capture Pro Server AE host computer | Device | Epson unique (UDP) | 2968 | Computer's information acquiring response | |

| Sender (Client) | Target (Server) | Protocol | Port | Usage |
|---|---|-----------------------|------------|--|
| Device | Document Capture Pro Server AE host computer | Epson unique (UDP) | 2968 | Computer's information acquiring request |
| Document Capture Pro Server AE host computer | Device | Epson unique (TCP) | 2968 | Job information |
| Device | Document Capture Pro Server AE host computer | Epson unique (TCP) | 2968 | Job information |
| Document Capture Pro Server AE host computer | FTP/FTPS Server | FTP/FTPS (TCP) | 20 21 | Send files to Network folder |
| Document | File Server | SMB (TCP) | 445 | Send files to Network folder |
| Capture Pro Server AE host computer | | NetBIOS (UDP) | 137 138 | |
| | | NetBIOS (TCP) | 139 | |
| Document | Web DAV Server | HTTP (TCP) | 80 | Send files to Network folder |
| Capture Pro Server AE host computer | | HTTPS (TCP) | 443 | |

- *1 The default port number. The actual port number is set to the user for the URL of the authentication system.
- *2 The default port number. The actual port number is set to the control panel for the URL configuration of the authentication system.
- *3 The port number when using encryption.
- *4 The default port number. If you want to change the port number, set the number that is used by the LDAP server configuration of the authentication system.
- *5 The default port number. If you want to change the port number, set the number that is used by the SMTP server configuration of the authentication system.
- *6 Used when you are using the Exchange Online service.

Windows Services and Executable Files

Document Capture Pro Server AE starts the following Windows services and executable files.

Windows services

| Classification | Name | Startup Type | Log On As |
|-------------------------------|---|-------------------|-----------------|
| DCPS service | Document Capture Pro Application Service | Automatic startup | Network Service |
| | DCPSNWService | Automatic startup | Network Service |
| Authentication system service | Authentication Sub System Device Service | Automatic startup | Local System |
| | Authentication Sub System Notification Receiver Serv- ice | Automatic startup | Local System |
| | Authentication Sub System Scheduler Service | Automatic startup | Local System |
| | Authentication Sub System Dcps Receiver Service | Automatic startup | Local System |

Executable files

| Classification | Name |
|----------------------|-------------------|
| Executed during scan | JobRunner.exe |
| operations | ProjectRunner.exe |

Document Capture Pro Server AE Work Folder

The following is the work folder for Document Capture Pro Server AE. If operations slows down due to anti-virus software scans, you may be able to improve the situation by excluding the following folders.

| Folders | Description |
|--|---|
| C:\ProgramData\EPSON\DCPS\ | Data storage destination, temporary work area, log storage area |
| C:\Windows\ServiceProfiles\NetworkService\AppData\Roaming\Epson\Documen t Capture\ | Temporary work area |
| C:\Windows\ServiceProfiles\NetworkService\AppData\Roaming\Epson\Epson Scan 2\ | Data storage area for scanner driver (Epson Scan 2) |
| C:\Windows\ServiceProfiles\NetworkService\AppData\Local\Temp\ES2WorkTemp | Temporary work area for scanner driver (Epson Scan 2) |
| C:\Windows\ServiceProfiles\NetworkService\AppData\Roaming\Epson\ESCNDV\ | Data storage area for scanner driver (Epson Scan) |
| C:\Windows\ServiceProfiles\NetworkService\AppData\Local\Temp\EPSONWorkTe mp\ | Temporary work area for scanner driver (Epson Scan) |

Trademarks

| ☐ Microsoft, Microsoft Edge, Windows, and Windows Server are trademarks of the Microsoft group of companies. |
|---|
| ☐ Apple and Safari are trademarks of Apple Inc., registered in the U.S. and other countries. |
| ☐ Android, Chrome, and Google Chrome are trademarks of Google LLC. |
| ☐ JavaScript is registered trademarks of Oracle and/or its affiliates. |
| ☐ Firefox is a trademark of the Mozilla Foundation in the U.S. and other countries. |
| ☐ All other trademarks are the property of their respective owners and used for identification purposes only. |
| ©2016-2025 Seiko Epson Corporation |
| |
| Caution |
| ☐ Unauthorized reproduction of a part or all of this guide is strictly prohibited. |
| ☐ The contents of this guide are subject to change without prior notice. |
| ☐ Contact our company if you have any questions, find a mistake, encounter a missing description, and so on it the contents of this guide. |
| ☐ Regardless of the previous point, we will under no conditions be liable for any damages or losses resulting from the operation of this product. |
| ☐ We will under no conditions be liable for any damages or losses resulting from operation of this product in a |

way other than described in this manual, inappropriate use of this product, or modifications performed by a

third party other than our company or our suppliers.