

User's Guide

Copyright and Trademarks

Copyright and Trademarks

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information herein. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other products.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation and its affiliates shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark, and EPSON EXCEED YOUR VISION or EXCEED YOUR VISION is a trademark of Seiko Epson Corporation.

SDXC Logo is a trademark of SD-3C, LLC.



Memory Stick Duo, Memory Stick PRO Duo, Memory Stick PRO-HG Duo, Memory Stick Micro, and MagicGate Memory Stick Duo are trademarks of Sony Corporation.



Intel® is a registered trademark of Intel Corporation.

PowerPC® is a registered trademark of International Business Machines Corporation.

Epson Scan software is based in part on the work of the Independent JPEG Group.

libtiff

Copyright © 1988-1997 Sam Leffler
Copyright © 1991-1997 Silicon Graphics, Inc.

Copyright and Trademarks

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation, and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Microsoft®, Windows®, and Windows Vista® are registered trademarks of Microsoft Corporation.

Apple, Macintosh, Mac OS, and OS X are trademarks of Apple Inc., registered in the U.S. and other countries.

AirPrint is a trademark of Apple Inc.

Google Cloud Print™ is a registered trademark of Google Inc.

Adobe, Adobe Reader, Acrobat, and Photoshop are trademarks of Adobe systems Incorporated, which may be registered in certain jurisdictions.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

© 2013 Seiko Epson Corporation. All rights reserved.

The contents of this manual and the specifications of this product are subject to change without notice.

Contents

Copyright and Trademarks

Copyright and Trademarks.	2
-----------------------------------	---

Introduction

Where to Find Information.	8
Available Features.	8
Caution, Important and Note.	9
Operating System Versions.	9
Using Epson Connect Service.	10

Important Instructions

Safety Instructions.	11
Product Advisories and Warnings.	12
Setting up/using the product.	12
Using the product with a wireless connection	
.	14
Using memory cards.	14
Using the LCD screen.	14
Handling ink cartridges.	14
Restrictions on Copying.	14
Protecting Your Personal Information.	15

Getting to Know Your Product

Product Parts.	16
WF-7610 Series/WF-7620 Series.	16
WF-3620 Series/WF-3640 Series.	19
Guide to the Control Panel.	21
Status icons.	23
Icons for each mode.	24
Status Menu.	25
Icons on the Software Keyboard for the LCD	
Screen.	25

Paper and Media Handling

Introduction to Using, Loading, and Storing	
Media.	27
Storing paper.	27
Selecting Paper.	27
Paper type settings on the LCD screen.	31
Paper type settings from the printer driver.	32

Loading Paper into the Paper Cassette.	33
Loading Envelopes into the Paper Cassette.	36
Loading Paper and Envelopes into the Rear Paper	
Feed Slot.	39
Placing Originals.	42
Automatic Document Feeder (ADF).	42
Scanner glass.	44
Inserting a Memory Card.	44

Copying

Copying Documents.	47
Basic copying.	47
Copy Mode Menu List.	47

Printing

Printing from the Control Panel.	48
Printing a JPEG file.	48
Printing a TIFF file.	49
Printing from Your Computer.	49
Printer Driver and Status Monitor.	49
Basic Operations.	51
Basic printing.	51
Canceling printing.	55
Other Options.	57
Printing photos the easy way.	57
Product presets (For Windows Only).	58
2-sided printing.	58
Fit to page printing.	60
Pages per Sheet printing.	61
Anti-Copy Pattern printing (for Windows	
Only).	62
Watermark printing (For Windows Only).	63
Header/Footer printing (For Windows Only)	
.	64
Administrator Settings for Printer Driver (for	
Windows Only).	65

Scanning

Scanning from the Control Panel.	67
Scanning to a memory device.	67
Scanning to a folder.	68
Scanning to an email.	68
Scanning to a computer.	69
Scan mode menu list.	70

Contents

Scanning from Your Computer.	70
Scanning in Office Mode.	70
Scanning in Professional Mode.	72
Image Adjustment Features.	74
Previewing and Adjusting the Scan Area.	77
Software Information.	79
Starting Epson Scan Driver.	79
Starting Other Scanning Software.	79

Faxing

Connecting to a Phone Line.	81
Compatible telephone lines and phone cables	81
Connecting the product to the phone line.	81
Connecting a phone device.	82
Setting Up for Faxing.	83
Basic settings.	83
Advanced settings.	87
Sending Faxes.	88
Basic operations.	88
Other options.	90
Receiving Faxes.	94
Setting up the receive mode.	94
Saving and Forwarding Received Faxes.	95
Receiving a fax by polling.	100
Receiving a fax manually.	101
Checking Fax Job Status and History.	102
Notification of unprocessed received faxes (For the WF-7610 Series/WF-7620 Series only).	102
Using the status menu.	103
Printing a fax report.	104
Fax Mode Menu List.	105

Making Contact List Settings

Creating a Contact.	106
Creating a Group.	107

Menu List of Control Panel

Copy Mode.	109
Memory Device Mode.	110
Fax Mode.	111
Scan Mode.	111
Setup Mode.	114
System Administration Settings.	115
Contacts.	120

Presets.	120
Status Menu.	121

Ink Cartridge and Consumable Information

Ink Cartridges.	122
Maintenance Box	122

Replacing Ink Cartridges

Ink Cartridge Safety Instructions, Precautions, and Specifications.	124
Safety instructions.	124
Precautions on ink cartridge replacement.	125
Ink Cartridge Specifications.	126
Checking the Ink Cartridge Status.	126
For Windows.	126
For Mac OS X.	127
Using the control panel.	128
Temporary Printing with Black Ink When Color Ink Cartridges are Expended.	129
For Windows.	129
For Mac OS X.	131
Conserving Black Ink When the Cartridge Is Low (For Windows Only).	132
Replacing an ink cartridge.	133

Maintaining Your Product and Software

Checking the Print Head Nozzles.	137
Using the Nozzle Check utility for Windows	137
Using the Nozzle Check utility for Mac OS X	137
Using the control panel.	138
Cleaning the Print Head.	138
Using the Head Cleaning utility for Windows	139
Using the Head Cleaning utility for Mac OS X	139
Using the control panel.	140
Aligning the Print Head.	140
Using the Print Head Alignment utility for Windows.	140
Using the Print Head Alignment utility for Mac OS X.	141
Using the control panel.	141
Making Network Service Settings.	142

Contents

Web Config.	142
Email Server Settings.	143
Sharing the Product for Printing.	145
Cleaning the Product.	145
Cleaning the exterior of the product.	145
Cleaning the interior of the product.	146
Replacing Maintenance Box.	147
Checking the maintenance box status.	147
Precautions on the maintenance box.	147
Replacing a maintenance box.	147
Transporting the Product.	149
Checking and Installing Your Software.	151
Checking the software installed on your computer.	151
Installing the software.	152
Uninstalling Your Software.	152
For Windows.	152
For Mac OS X.	153

Transferring Data Using an External Storage Device

Precautions on Storage Devices.	155
Copying Files Between a Storage Device and Your Computer.	155
Copying files to your computer.	155
Saving files to a storage device.	156

Error Indicators

Error Messages on the Control Panel.	158
Error Code on the Status Menu.	159

Troubleshooting for Printing/Copying

Diagnosing the Problem.	162
Checking product status.	163
Paper Jams.	165
Removing jammed paper from the rear cover	166
Removing jammed paper from inside the product.	171
Removing jammed paper from the paper cassette.	173
Removing jammed paper from the Automatic Document Feeder (ADF).	175
Preventing paper jams.	177
Reprinting after a paper jam (for Windows only).	177
Print Quality Help.	178

Horizontal banding.	179
Vertical banding or misalignment.	179
Incorrect or missing colors.	180
Blurry or smeared print.	180
Miscellaneous Printout Problems.	181
Incorrect or garbled characters.	181
Incorrect margins.	182
Printout has a slight slant.	182
Size or position of copied image is incorrect.	182
Inverted image.	183
Blank pages print.	183
Printed side is smeared or scuffed.	183
Printing is too slow.	183
Paper Does Not Feed Correctly.	184
Paper does not feed.	184
Multiple pages feed.	184
Paper is improperly loaded.	185
Paper is not ejected fully or is wrinkled.	185
The Product Does Not Print.	185
All lights are off.	185
Lights came on and then went out.	185
The control panel or lights are on.	185
An ink error is indicated after you replace the cartridge.	186
Other Problem.	187
Printing plain papers quietly.	187
The external memory device is not recognized	187
Rear paper feed slot is removed (Only for WF-7610 Series/WF-7620 Series).	188
Power Turns Off Automatically.	188

Troubleshooting for Scanning

Problems Indicated by Messages on the LCD	
Screen or Status Light.	189
Problems When Starting a Scan.	189
How to unblock Epson Event Manager.	189
Using the Automatic Document Feeder (ADF)	190
Using scanning software other than Epson Scan driver.	190
Problems When Feeding Paper.	191
The paper gets dirty.	191
Multiple sheets of paper are fed.	191
The paper jams in the Automatic Document Feeder (ADF)	191
Problems With Scanning Time.	191
Problems With Scanned Images.	191
Scan quality is unsatisfactory.	191

Contents

The scanning area or direction is unsatisfactory.	192
Other Problems.	194
Scanning quietly.	194
Cannot send the scanned image by email.	194
Problems Remain After Trying All Solutions.	194

Troubleshooting for Faxing

Cannot send and receive fax.	195
“No dial tone detected.” error occurs.	196
Memory full error occurs.	196
Quality problems.	196
In sent faxes.	196
In received faxes.	196
Other problems.	197
Answering machine cannot answer voice calls	197
The time and date of sent or received fax jobs is incorrect.	197
Cannot store received faxes in an external storage device.	197
Faxes are sent at the wrong size.	197
Cannot forward received faxes by email.	197

Product Information

System Requirements.	198
For Windows.	198
For Mac OS X.	198
Technical Specifications.	198
Printer specifications.	198
Scanner specifications.	201
Automatic Document Feeder (ADF) specifications.	201
Fax specifications.	202
Network interface specification.	202
Memory card.	203
Mechanical.	204
Electrical.	205
Environmental.	207
Standards and approvals.	207
Interface.	208
External USB device.	208

Where To Get Help

Technical Support Web Site.	209
Contacting Epson Support.	209
Before Contacting Epson.	209
Help for Users in Europe.	209

Help for Users in Taiwan.	210
Help for Users in Australia.	210
Help for Users in Singapore.	211
Help for Users in Thailand.	211
Help for Users in Vietnam.	212
Help for Users in Indonesia.	212
Help for Users in Hong Kong.	214
Help for Users in Malaysia.	214
Help for Users in the Philippines.	215

Index

Introduction

Where to Find Information

The latest version of the following manuals are available on the Epson support website.

<http://www.epson.eu/Support> (Europe)

<http://support.epson.net/> (outside Europe)

☐ **Start Here (paper):**

Provides you with an introduction to the product and services.

☐ **Basic Guide (paper):**

Provides you with basic information when you are using the product without a computer. This manual may not be included depending on model and region.

☐ **Important Safety Instructions (paper):**

Provides you with instructions to ensure the safe use of this product. This manual may not be included depending on model and region.

☐ **User's Guide (PDF):**

Provides you with detailed operating, safety, and troubleshooting instructions. See this guide when using this product with a computer, or when using advanced features such as 2 sided copying.

☐ **Network Guide (PDF):**

Provides instructions on network settings for your computer, smartphone or product, and solving problems.

☐ **Administrator's Guide (PDF):**

Provides the system administrator with information on security management and product settings.

Available Features

Check what is available for your product.

	WF-7610	WF-7611	WF-7620	WF-7621	WF-3620	WF-3621	WF-3640
Print	✓	✓	✓	✓	✓	✓	✓
Copy	✓	✓	✓	✓	✓	✓	✓
Fax	✓	✓	✓	✓	✓	✓	✓
Scan to a computer	✓	✓	✓	✓	✓	✓	✓
Scan to a memory device	✓	✓	✓	✓	✓	✓	✓

Introduction

	WF-7610	WF-7611	WF-7620	WF-7621	WF-3620	WF-3621	WF-3640
Scan to a network folder							
Scan to an email							
Forward fax to a network folder	✓	✓	✓	✓	Australia and New Zealand only	✓	Australia and New Zealand only
Forward fax to an email							
LDAP*	✓	✓	✓	✓	-	-	-
Paper cassette 2	-	-	✓	✓	-	-	✓

* For more details, see the online Administrator's Guide.

Caution, Important and Note

Caution, Important, and Note in this manual are indicated as below and have the following meaning.



Caution

must be followed carefully to avoid bodily injury.



Important

must be observed to avoid damage to your equipment.

Note

contain useful tips and restrictions on product operation.

Operating System Versions

In this manual, the following abbreviations are used.

- ❑ Windows 8 refers to Windows 8, Windows 8 Pro, Windows 8 Enterprise.
- ❑ Windows 7 refers to Windows 7 Home Basic, Windows 7 Home Premium, Windows 7 Professional, and Windows 7 Ultimate.
- ❑ Windows Vista refers to Windows Vista Home Basic Edition, Windows Vista Home Premium Edition, Windows Vista Business Edition, Windows Vista Enterprise Edition, and Windows Vista Ultimate Edition.
- ❑ Windows XP refers to Windows XP Home Edition, Windows XP Professional x64 Edition, and Windows XP Professional.
- ❑ Windows Server 2012 refers to Windows Server 2012 Essentials Edition, Server 2012 standard Edition.
- ❑ Windows Server 2008 refers to Windows Server 2008 Standard Edition, Windows Server 2008 Enterprise Edition, Windows Server 2008 x64 Standard Edition, and Windows Server 2008 x64 Enterprise Edition.

Introduction

- ❑ Windows Server 2008 R2 refers to Windows Server 2008 R2 Standard Edition and Windows Server 2008 R2 Enterprise Edition.
- ❑ Windows Server 2003 refers to Windows Server 2003 Standard Edition and Windows Server 2003 Enterprise Edition, Windows Server 2003 x64 Standard Edition and Windows Server 2003 x64 Enterprise Edition.
- ❑ Mac OS X refers to Mac OS X 10.5.8, 10.6.x, 10.7.x, 10.8.x.

Using Epson Connect Service

Using Epson Connect and other companies' services, you can easily print directly from your smartphone, tablet PC or laptop, anytime and practically anywhere even across the globe! For more information about the printing and other services, visit the following URL;

<https://www.epsonconnect.com/> (Epson Connect portal site)

<http://www.epsonconnect.eu> (Europe only)



Note:

You can make network service settings using a Web browser on your computer, smartphone, tablet PC, or laptop that is connected to the same network as the product.

➡ [“Making Network Service Settings” on page 142](#)

Important Instructions

Safety Instructions

Read and follow these instructions to ensure safe use of this product. Make sure you keep this guide for future reference. Also, be sure to follow all warnings and instructions marked on the product.

- ❑ Some of the symbols used on your printer are to ensure safety and proper use of the printer. Visit the following Web site to learn the meaning of the symbols.
<http://support.epson.net/symbols>
- ❑ Use only the power cord supplied with the product and do not use the cord with any other equipment. Use of other cords with this product or the use of the supplied power cord with other equipment may result in fire or electric shock.
- ❑ Be sure your AC power cord meets the relevant local safety standard.
- ❑ Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the product's guides.
- ❑ Unplug the product and refer servicing to qualified service personnel under the following conditions:
The power cord or plug is damaged; liquid has entered the product; the product has been dropped or the casing damaged; the product does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions.
- ❑ Place the product near a wall outlet where the plug can be easily unplugged.
- ❑ Do not place or store the product outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity.
- ❑ Take care not to spill liquid on the product and not to handle the product with wet hands.
- ❑ Keep this product at least 22 cm away from cardiac pacemakers. Radio waves from this product may adversely affect the operation of cardiac pacemakers.
- ❑ If the LCD screen is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.
- ❑ Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning.
- ❑ Do not use a telephone to report a gas leak in the vicinity of the leak.

Important Instructions

- ❑ For WF-7610 Series/WF-7620 Series: The product is heavy and should not be lifted or carried by fewer than two persons. When lifting the product, the two persons should assume the correct positions (see below).



Note:

The following provides safety instructions for ink cartridges.

➔ [“Replacing Ink Cartridges” on page 124](#)

Product Advisories and Warnings

Read and follow these instructions to avoid damaging the product or your property. Make sure you keep this guide for future reference.

Setting up/using the product

- ❑ Do not block or cover the vents and openings in the product.
- ❑ Use only the type of power source indicated on the product's label.
- ❑ Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- ❑ Avoid electrical outlets controlled by wall switches or automatic timers.
- ❑ Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- ❑ The power-supply cords should be placed to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place objects on top of the power-supply cords and do not allow the power-supply cords to be stepped on or run over. Be particularly careful to keep all the power-supply cords straight at the ends and the points where they enter and leave the transformer.

Important Instructions

- ❑ If you use an extension cord with the product, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- ❑ If you plan to use the product in Germany, the building installation must be protected by a 10 or 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for the product.
- ❑ When connecting the product to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable.
- ❑ Place the product on a flat, stable surface that extends beyond the base of the product in all directions. The product will not operate properly if it is tilted at an angle.
- ❑ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.
- ❑ Allow spaces behind the product for the cables, and space above the product so that you can fully raise the document cover.
- ❑ Leave enough space in front of the product for the paper to be fully ejected.
- ❑ Avoid places subject to rapid changes in temperature and humidity. Also, keep the product away from direct sunlight, strong light, or heat sources.
- ❑ Do not insert objects through the slots in the product.
- ❑ Do not put your hand inside the product or touch the ink cartridges during printing.
- ❑ Do not touch the white flat cable inside the product.
- ❑ Do not use aerosol products that contain flammable gases inside or around the product. Doing so may cause fire.
- ❑ Do not move the ink cartridge holder by hand; otherwise, you may damage the product.
- ❑ Always turn the product off using the ⏻ button. Do not unplug the product or turn off the power at the outlet until the LCD screen has turned off completely.
- ❑ Before transporting the product, make sure that the print head is in the home (far right) position and the ink cartridges are in place.
- ❑ Be careful not to trap your fingers when closing the scanner unit.
- ❑ If you are not going to use the product for a long period, be sure to unplug the power cord from the electrical outlet.
- ❑ Do not press too hard on the scanner glass when placing the originals.

Important Instructions

Using the product with a wireless connection

- ❑ Radio waves from this product may negatively affect the operation of medical electronic equipment, causing them to malfunction. When using this product inside medical facilities or near medical equipment, follow directions from the authorized personnel representing the medical facilities, and follow all posted warnings and directions on the medical equipment.
- ❑ Radio waves from this product may negatively affect the operation of automatically controlled devices such as automatic doors or fire alarms, and could lead to accidents due to malfunction. When using this product near automatically controlled devices, follow all posted warnings and directions on these devices.

Using memory cards

- ❑ Do not remove a memory card or turn off the product while the memory card light is flashing.
- ❑ The methods for using memory cards vary according to card type. Be sure to refer to the documentation packaged with your memory card for details.
- ❑ Use only memory cards compatible with the product.
 - ➔ [“Memory card” on page 203](#)

Using the LCD screen

- ❑ The LCD screen may contain a few small bright or dark spots, and because of its features it may have an uneven brightness. These are normal and do not indicate that it is damaged in any way.
- ❑ Only use a dry, soft cloth to clean the LCD screen or touchscreen. Do not use liquid or chemical cleaners.
- ❑ The exterior cover of the LCD screen could break if it receives a heavy impact. Contact your dealer if the panel surface chips or cracks, and do not touch or attempt to remove the broken pieces.
- ❑ Press the touchscreen gently with your finger. Do not press force or operate with your nails.
- ❑ Do not operate by a sharp edge thing such as a ball point pen, sharp pencil, stylus pen and so on.
- ❑ Condensation inside the panel due to abrupt changes in temperature or humidity may cause performance to deteriorate.

Handling ink cartridges

We will provide ink-related safety instructions and product advice/warnings in the linked section (before “Replacing Ink Cartridges” section).

➔ [“Replacing Ink Cartridges” on page 124](#)

Restrictions on Copying

Observe the following restrictions in order to ensure the responsible and legal use of the product.

Important Instructions

Copying of the following items is prohibited by law:

- ☐ Bank bills, coins, government-issued marketable securities, government bond securities, and municipal securities
- ☐ Unused postage stamps, pre-stamped postcards, and other official postal items bearing valid postage
- ☐ Government-issued revenue stamps, and securities issued according to legal procedure

Exercise caution when copying the following items:

- ☐ Private marketable securities (stock certificates, negotiable notes, checks, etc.), monthly passes, concession tickets, etc.
- ☐ Passports, driver's licenses, warrants of fitness, road passes, food stamps, tickets, etc.

Note:

Copying these items may also be prohibited by law.

Responsible use of copyrighted materials:

- ☐ Products can be misused by improperly copying copyrighted materials. Unless acting on the advice of a knowledgeable attorney, be responsible and respectful by obtaining the permission of the copyright holder before copying published material.

Protecting Your Personal Information

This product allows you to store names and telephone numbers in its memory even when the power is turned off.

Use the following menu to erase the memory if you give the product to someone else or dispose of it.


Setup > System Administration > Restore Default Settings > Clear All Data and Settings

Getting to Know Your Product

Note:
The illustrations in this manual are from a similar product model. Although they may differ from your actual product, the method of operation is the same.

Product Parts


WF-7610 Series/WF-7620 Series




a.	ADF cover
b.	ADF lever
c.	Automatic Document Feeder (ADF)
d.	Edge guide
e.	ADF input tray (place your originals here to be copied)
f.	ADF output tray (your originals are ejected here as they are copied)
g.	Paper cassette 1
h.	Paper cassette 2 *

* Paper cassette 2 is only available for the WF-7620 Series.

Getting to Know Your Product




a.	Edge guides
b.	Rear paper feed slot
c.	Output tray
d.	Output tray extension
e.	Stopper
f.	Edge guides
g.	Paper cassette
h.	Paper cassette cover




a.	Document cover
b.	Scanner glass
c.	Control panel
d.	Memory card slot
e.	Memory card light
f.	External interface USB port

Getting to Know Your Product




a.	Scanner unit
b.	Ink cartridge cover
c.	Ink cartridge holder
d.	Print head (under the ink cartridge holder)



a.	Maintenance box
b.	Rear cover 1
c.	Rear cover 2 (Auto Duplexer)
d.	AC inlet
e.	LINE port
f.	EXT. port
g.	LAN port
h.	USB connector


Getting to Know Your Product

WF-3620 Series/WF-3640 Series




a.	ADF cover
b.	Automatic Document Feeder (ADF)
c.	Edge guide
d.	ADF input tray (place your originals here to be copied)
e.	ADF output tray (your originals are ejected here as they are copied)
f.	Paper cassette 1
g.	Paper cassette 2 *

* Paper cassette 2 is only available for the WF-3640 Series.




a.	Edge guides
b.	Rear paper feed slot
c.	Output tray
d.	Output tray extension
e.	Stopper
f.	Edge guides
g.	Paper cassette

Getting to Know Your Product




a.	Document cover
b.	Scanner glass
c.	Control panel
d.	Memory card slot
e.	Memory card light
f.	External interface USB port



a.	Scanner unit
b.	Ink cartridge cover
c.	Ink cartridge holder
d.	Print head (under the ink cartridge holder)

Getting to Know Your Product




a.	Maintenance box
b.	Rear cover (Auto Duplexer)
c.	AC inlet
d.	LINE port
e.	EXT. port
f.	LAN port
g.	USB connector

Guide to the Control Panel


- Note:**
- ❑ Control panel design varies depending on location.
 - ❑ Although the control panel design and what displayed on the LCD screen such as menu names and option names may differ from your actual product, the method of operation is the same.

WF-7610 Series/WF-7620 Series



Getting to Know Your Product

WF-3620 Series/WF-3640 Series



	Buttons/Lights	Function
a		Turns the product on or off. The power light turns on when the product is on. Flashes when the product is printing/copying/scanning/faxing, replacing an ink cartridge, charging ink, or cleaning the print head.
b		Returns to the top menu. When on the top menu, switches between the modes.
c	*1	Interrupts the current print or copy job and allows you to perform a different print or copy job. Press this button again to restart the job that has been paused.
d		Resets your settings to user default settings. If user default settings have not been made, resets to the factory default.
e		Stops the current operation.
f	-	LCD screen displays menus. If your product has a touch panel, you can scroll the screen by swiping the LCD screen. Try swiping a little harder if the touch panel is slow to respond. Returns to the Home screen if no operations are made for a few minutes.
g		Cancels/returns to the previous menu.
h		Shows the Status Menu. ➔ "Status Menu" on page 25 The orange light on the left turns on or flashes when an error occurs. You can check the error from the Status Menu. The blue light on the right flashes while the product is processing data. It stays on when there are print/scan/fax jobs waiting to be processed.
i	0 - 9 *, #	Specifies the date/time or the number of copies, as well as fax numbers. Enters alphanumeric characters and switches between uppercase, lowercase, and numbers each time it is pressed. It may be easier to use the software keypad to enter text instead of using these buttons.
j	c	Clears the number of copies and fax number.
k		Starts printing/copying/scanning/faxing in black and white.
l		Starts printing/copying/scanning/faxing in color.
m	*2	Scrolls the screen.

Getting to Know Your Product











	Buttons/Lights	Function
n	★*2	Shows a list of the preset settings you registered.

*1 This button is only available for the WF-7610 Series/WF-7620 Series.








*2 These buttons are only available for the WF-3620 Series.

Status icons





The following icons are displayed on the control panel depending on the product's status. Press the Wi-Fi icon or network status icon to check the current network settings and make Wi-Fi settings.

Icons	Description
	Displays a help which provides you instructions such as loading paper and placing a document.
	A document is placed on the Automatic Document Feeder (ADF).
	One or more ink cartridges are running low on ink or the maintenance box is nearly full. Press i to open the Status Menu, select Printer Information, and then check the status of the consumables.
	Indicates that one or more ink cartridges are expended or the maintenance box is full. Press i to open the Status Menu, select Printer Information, and then check the status of the consumables.
	Indicates that unread or unprinted fax data is stored in the product. When you have made settings to save received faxes on a computer or external storage device, this icon also indicates that received faxes have not been saved on the computer or the storage device.
	Indicates that the printer is receiving or sending faxes.
	Indicates the fax memory usage.
	Indicates the fax memory is full.
	Indicates that a Wi-Fi or an Ethernet connection is being processed.
	Indicates that there is no Ethernet connection.







Getting to Know Your Product

Icons	Description
	Indicates that an Ethernet connection has been established.
	Indicates that there is no Wi-Fi connection.
	Indicates that a Wi-Fi network error has occurred or the product is searching for a connection.
	Indicates that a Wi-Fi connection has been established. The number of bars indicates the connection's signal strength.
	Indicates that an Ad Hoc connection has been established.
	Indicates that a Wi-Fi Direct mode connection has been established.
	Indicates that Simple AP mode connection has been established.

Icons for each mode

Icons	Description
	Enters Copy mode. ➔ "Copying" on page 47
	Enters Scan mode. ➔ "Scanning from the Control Panel" on page 67
 	<p>Enters Fax mode. ➔ "Faxing" on page 81</p> <p>For the WF-7610 Series/WF-7620 Series, the number displayed on the fax mode icon indicates the number of unprocessed received faxes. "10+" is displayed when the number of unprocessed jobs is more than 10. For more details, see the section that describes the display when a received fax has not been processed.</p> <p>➔ "Notification of unprocessed received faxes (For the WF-7610 Series/WF-7620 Series only)" on page 102</p>

Getting to Know Your Product

Icons	Description
 *1	Opens Presets screen.
	Enters Memory Device mode.
 *2	Shows the registered contact list for scanning and faxing. ➔ "Making Contact List Settings" on page 106
	Shows the status of Epson Connect service. ➔ "Using Epson Connect Service" on page 10
	Opens Eco Mode settings screen. ➔ "System Administration Settings" on page 115
	Enters Setup mode. ➔ "Setup Mode" on page 114

*1 This icon is only available for the WF-7610 Series/WF-7620 Series/WF-3640 Series.

*2 This icon is only available for the WF-7610 Series/WF-7620 Series.

Status Menu

The Status Menu displays the current status of the product and jobs. Press **i** on the control panel.

Function	Description
Printer Information	Displays the status of the consumables and any errors that have occurred in the product. To resolve an error, select the error from the list to display the error message.
Job Monitor	Displays a list of ongoing jobs and jobs waiting to be processed.
Job History	Displays the job history. If a job fails, an error code is shown in the history. You can check the error code and the solution for the error in the following section. ➔ "Error Code on the Status Menu" on page 159
Job Storage	Select Inbox to display the received faxes stored in the product's memory.










Icons on the Software Keyboard for the LCD Screen

You can enter characters and symbols from the software keyboard to register a contact, make network settings, and so on. The following icons are displayed on the software keyboard screen.

Note:

Available icons vary depending on the setting item.

Getting to Know Your Product

Icons	Description
	Switches between upper case and lower case letters.
  	<p>Switches the character type.</p> <p>123#: Allows you to enter numbers and symbols.</p> <p>ABC: Allows you to enter the alphabet.</p> <p>ÄÄÄ: Allows you to enter special characters such as umlauts and accents.</p>
	Changes the keyboard layout.
	Enters a space.
	Deletes the character to the left.
	Confirms the entered characters.
	Enters a hyphen (-) on the fax number entry screen. One hyphen causes the product to pause for three seconds when dialing.

Paper and Media Handling

Introduction to Using, Loading, and Storing Media

You can achieve good results with most types of plain paper. However, coated papers provide superior prints because they absorb less ink.

Epson provides special papers that are formulated for the ink used in Epson ink jet products, and recommends these papers to ensure high-quality results.

When loading special paper distributed by Epson, read the instruction sheets packed with the paper first and keep the following points in mind.

Note:

- ❑ Load the paper into the paper cassette printable side down. The printable side is usually whiter or glossier. See the instruction sheets packed with the paper for more information. Some types of paper have cut corners to help identify the correct loading direction.
- ❑ If the paper is curled, flatten it or curl it slightly in the opposite direction before loading. Printing on curled paper may cause ink to smear on your prints.



Storing paper

Return unused paper to the original package as soon as you finish printing. When handling special media, Epson recommends storing your prints in a resealable plastic bag. Keep unused paper and prints away from high temperature, humidity, and direct sunlight.

Selecting Paper

The following table shows supported paper types. The loading capacity, paper source, and availability of borderless printing vary by paper as shown below.

Paper and Media Handling

WF-7610 Series/WF-7620 Series

Media Type	Size	Loading capacity (sheets or height)			Borderless printing	2-sided printing
		paper cassette 1	paper cassette 2*1	rear paper feed slot		
Plain paper*2	A3	27.5 mm*3	27.5 mm*3	1	-	✓
	B4	27.5 mm*3	27.5 mm*3	1	-	✓
	Legal	27.5 mm*3	27.5 mm*3	1	-	✓
	Letter	27.5 mm*3	27.5 mm*3	1	-	✓
	A4	27.5 mm*3	27.5 mm*3	1	-	✓
	B5	27.5 mm*3	27.5 mm*3	1	-	✓
	A5	27.5 mm*3	-	1	-	✓
	A6	27.5 mm*3	-	1	-	-
	User defined	1	1	1	-	✓
Thick paper*4	A3	-	-	1	-	-
	B4	-	-	1	-	-
	Legal	-	-	1	-	-
	Letter	-	-	1	-	-
	A4	-	-	1	-	-
	B5	-	-	1	-	-
	A5	-	-	1	-	-
	A6	-	-	1	-	-
	User defined	-	-	1	-	-
Envelope	#10	10	-	1	-	-
	DL	10	-	1	-	-
	C6	10	-	1	-	-
	C4	10	-	1	-	-
Epson Bright White Ink Jet Paper	A4	200*3	200*3	1	-	✓
Epson Photo Quality Ink Jet Paper	A3+	80	-	1	-	-
	A3	80	-	1	-	-
	A4	80	-	1	-	-

Paper and Media Handling

Media Type	Size	Loading capacity (sheets or height)			Borderless printing	2-sided printing
		paper cassette 1	paper cassette 2*1	rear paper feed slot		
Epson Matte Paper - Heavyweight	A3+	20	-	1	✓	-
	A3	20	-	1	✓	-
	A4	20	-	1	✓	-
Epson Premium Glossy Photo Paper	A3+	20	-	1	✓	-
	A3	20	-	1	✓	-
	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	1	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	1	✓	-
	16:9 wide size (102 × 181 mm)	20	-	1	✓	-
Epson Premium Semigloss Photo Paper	A3+	20	-	1	✓	-
	A3	20	-	1	✓	-
	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	1	✓	-
Epson Ultra Glossy Photo Paper	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	1	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	1	✓	-
Epson Photo Paper, Glossy	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	1	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	1	✓	-

*1 Paper cassette 2 may not be available depending on the product.

*2 Plain paper is defined as paper with a weight of 64 g/m² (17 lb) to 90 g/m² (24 lb).

This includes preprinted paper, letterhead, colored paper, and recycled paper.

Make sure you are using long-grain paper. If you are not sure what type of paper you are using, consult the paper packaging or the manufacturer to check the paper specifications.

*3 The loading capacity for manual 2-sided printing is 30 sheets.

*4 Thick paper is defined as paper with a weight of 91 g/m² (25 lb) to 256 g/m² (68 lb).

Paper and Media Handling

WF-3620 Series/WF-3640 Series

Media Type	Size	Loading capacity (sheets or height)			Borderless printing	2-sided printing
		paper cassette 1	paper cassette 2*1	rear paper feed slot		
Plain Paper*2	Legal	30*3	30*3	1	-	✓*5
	Letter	27.5 mm*4	27.5 mm*4	1	-	✓
	A4	27.5 mm*4	27.5 mm*4	1	-	✓
	B5	27.5 mm*4	27.5 mm*4	1	-	✓
	A5	27.5 mm*4	-	1	-	✓*5
	A6	27.5 mm*4	-	-	-	-
	User defined	1	1	1	-	✓
Thick paper*6	Legal	-	-	1	-	-
	Letter	-	-	1	-	-
	A4	-	-	1	-	-
	B5	-	-	1	-	-
	A5	-	-	1	-	-
	User defined	-	-	1	-	-
Envelope	#10	10	-	1	-	-
	DL	10	-	1	-	-
	C6	10	-	-	-	-
	C4	-	-	1	-	-
Epson Bright White Ink Jet Paper	A4	200*4	200*4	1	-	✓
Epson Photo Quality Ink Jet Paper	A4	80	-	1	-	-
Epson Matte Paper - Heavyweight	A4	20	-	1	✓	-
Epson Premium Glossy Photo Paper	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	-	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	-	✓	-
	16:9 wide size (102 × 181 mm)	20	-	-	✓	-

Paper and Media Handling

Media Type	Size	Loading capacity (sheets or height)			Borderless printing	2-sided printing
		paper cassette 1	paper cassette 2*1	rear paper feed slot		
Epson Premium Semigloss Photo Paper	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	-	✓	-
Epson Ultra Glossy Photo Paper	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	-	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	-	✓	-
Epson Photo Paper, Glossy	A4	20	-	1	✓	-
	10 × 15 cm (4 × 6 in.)	20	-	-	✓	-
	13 × 18 cm (5 × 7 in.)	20	-	-	✓	-

*1 Paper cassette 2 may not be available depending on the product.

*2 Plain paper is defined as paper with a weight of 64 g/m² (17 lb) to 90 g/m² (24 lb). This includes preprinted paper, letterhead, colored paper, and recycled paper.

*3 The loading capacity for manual 2-sided printing is 1 sheet.

*4 The loading capacity for manual 2-sided printing is 30 sheets.

*5 Legal and A5 size paper are not available for automatic 2-sided printing. These sizes are for manual 2-sided printing only.

*6 Thick paper is defined as paper with a weight of 91 g/m² (25 lb) to 256 g/m² (68 lb).

Note:

- ☐ The availability of paper varies by location.
- ☐ When printing on genuine Epson paper at a user defined size, only Standard or Normal print quality settings are available. Although some printer drivers allow you to select a better print quality, the printouts are printed using Standard or Normal.

Paper type settings on the LCD screen

The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

For this paper	LCD paper type
Plain paper*1	plain papers
Preprinted paper *1	Preprinted
Letterhead*1	Letterhead

Paper and Media Handling

For this paper	LCD paper type
Colored paper* ¹	Color
Recycled paper* ¹	Recycled
Thick paper	Thick-Paper
Epson Bright White Ink Jet Paper* ¹	plain papers
Epson Ultra Glossy Photo Paper	Ultra Glossy
Epson Premium Glossy Photo Paper	Prem. Glossy
Epson Premium Semigloss Photo Paper	Prem. Semigloss
Epson Photo Paper, Glossy	Glossy
Epson Matte Paper – Heavyweight	Matte
Epson Photo Quality Ink Jet Paper	Matte
Envelopes	Envelope

*¹ You can perform 2-sided printing with this paper.

Paper type settings from the printer driver

The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

For this paper	Printer driver paper type
Plain paper	plain papers
Epson Bright White Ink Jet Paper	plain papers
Preprinted paper	Preprinted
Letterhead	Letterhead
Colored paper	Color
Recycled paper	Recycled
Epson Ultra Glossy Photo Paper	Epson Ultra Glossy
Epson Premium Glossy Photo Paper	Epson Premium Glossy
Epson Premium Semigloss Photo Paper	Epson Premium Semigloss
Epson Photo Paper, Glossy	Photo Paper Glossy
Epson Matte Paper – Heavyweight	Epson Matte
Thick paper	Thick-Paper
Epson Photo Quality Ink Jet Paper	Epson Matte
Envelopes	Envelope

Note:


The availability of special media varies by location. For the latest information on media available in your area, contact Epson support.

➔ [“Technical Support Web Site” on page 209](#)


Loading Paper into the Paper Cassette

Follow these steps to load paper:


- 1 Pull the paper cassette all the way out.



- 2 For WF-7610 Series/WF-7620 Series: Remove the cover.




- 3 Pinch and slide the edge guides to the sides of the paper cassette.



Paper and Media Handling


Note:

When using paper larger than A4, extend the paper cassette to the symbol on the cassette.



4

Slide the edge guide to adjust to the paper size you will use.




Note:

Paper larger than Legal size is only available for the WF-7610 Series/WF-7620 Series.

5

Load paper toward the edge guide with printable side face down, and check that the paper is not sticking out from the end of the cassette.




Paper and Media Handling

Note:

- ❑ Paper cassette 2 supports paper B5 or larger only.
- ❑ Fan and align the edges of the paper before loading.

6

Slide the edge guides to the edges of the paper.



Note:

For plain paper, do not load paper above the ▼ arrow mark inside the edge guide.
 For Epson special media, make sure the number of sheets is less than the limit specified for the media.

➡ [“Selecting Paper” on page 27](#)

7


For WF-7610 Series/WF-7620 Series: Put the paper cassette cover back on.



Paper and Media Handling

8


Keep the cassette flat and slowly and carefully reinsert it all the way into the product.

**Note:**

When you insert the paper cassette, the screen for making paper size and paper type settings is automatically displayed. Make sure the paper settings match the paper you have loaded.

9

Slide out the output tray and raise the stopper.

**Note:**


- ☐ If you want to print on commercially available pre-punched paper, see [“Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39](#).
- ☐ Leave enough space in front of the product for the paper to be fully ejected.
- ☐ Do not remove or insert the paper cassette while the product is operating.

Loading Envelopes into the Paper Cassette


Follow these steps to load envelopes:

Paper and Media Handling


- 1 Pull the paper cassette 1 all the way out.




- 2 For WF-7610 Series/WF-7620 Series: Remove the cover.



- 3 Pinch and slide the edge guides to the sides of the paper cassette.



- 4 Load envelopes lengthwise with the flap facing up and to the right.




Note:
Make sure the number of envelopes does not exceed the limit.

➡ [“Selecting Paper” on page 27](#)

Paper and Media Handling


- 5** Slide the edge guides to the edges of the envelopes and check that the envelopes are not sticking out from the end of the cassette.




Note:

Even if you do not feel a click, slide the edge guides to the edges of the envelopes.

- 6** For WF-7610 Series/WF-7620 Series: Put the paper cassette cover back on.



- 7** Keep the cassette flat and slowly and carefully reinsert it all the way into the product.




Paper and Media Handling

Note:


When you insert the paper cassette, the screen for making paper size and paper type settings is automatically displayed. Make sure the paper settings match the paper you have loaded.

8

Slide out the output tray and raise the stopper.


Note:

- ☐ The thickness of envelopes and their ability to fold vary widely. If the total thickness of the stack of envelopes exceeds 10mm, press down on the envelopes to flatten them before loading. If print quality declines when a stack of envelopes is loaded, load one envelope at a time.
- ☐ Do not use envelopes that are curled or folded.
- ☐ Flatten the envelope and the flaps before loading.



- ☐ Flatten the leading edge of the envelope before loading.
- ☐ Avoid using envelopes that are too thin, as they may curl during printing.
- ☐ Align the edges of the envelopes before loading.

Loading Paper and Envelopes into the Rear Paper Feed Slot


Follow the steps below to load paper and envelopes into the rear paper feed slot:

Note:


- ☐ Send your job before loading paper into the rear paper feed slot.
- ☐ Load paper in the rear paper feed slot when the product is not operating.

Paper and Media Handling


- 1** Slide out the output tray, and raise the stopper.



- 2** Open the rear paper feed slot.




- 3** While holding only one sheet of paper with the printable side face-up at the center of the rear paper feed slot, slide the edge guides until they are flush with the edges of the paper.



Note:
The printable side is often whiter or brighter than the other side.


- 4** Insert the paper into the rear paper feed slot. The paper is automatically fed.




Paper and Media Handling

Note:

- ❑ When loading envelopes, load the short edge first with the flap facing down.




- ❑ Do not use envelopes that are curled or folded.
- ❑ Flatten the envelope and the flaps before loading.



- ❑ Flatten the leading edge of the envelope before loading.
- ❑ Avoid using envelopes that are too thin, as they may curl during printing.

Note for paper with binding holes:

- ❑ You can use pre-punched paper with binding holes on one of the long edges. Do not load the paper with the binding holes along the top or the bottom.



- ❑ Available sizes are A3*, B4*, A4, B5, A5, A6*, Letter and Legal.
(* A3, B4, and A6 size paper are supported only for WF-7610 Series/WF-7620 Series.)
- ❑ Automatic 2-sided printing is not available.
- ❑ Make sure you adjust the print position of your file to avoid printing over the binder holes.

Placing Originals

Automatic Document Feeder (ADF)

You can load your original documents in the Automatic Document Feeder (ADF) to copy, scan, or fax multiple pages quickly. The ADF can scan both sides of your documents. You can use the following originals in the ADF.

Size	B5, A5* ¹ , A4, Letter, Legal* ¹ , B4* ² , A3* ²
Type	Plain paper
Weight	64 g/m ² to 95 g/m ²
Capacity	35 sheets or 3.5 mm or less* ³

*1 For the WF-3620 Series/WF-3640 Series, you cannot automatically scan both sides of A5 and Legal size paper.

*2 B4 and A3 documents are only available for the WF-7610 Series/WF-7620 Series.

*3 For the WF-3620 Series/WF-3640 Series, the loading capacity of Legal size is 10 sheets.




Important:

To prevent paper jams, avoid the following documents. For these types, use the scanner glass.

- ☐ Documents held together with paper clips, staples, etc.
- ☐ Documents that have tape or paper stuck to them.
- ☐ Photos, OHPs, or thermal transfer paper.
- ☐ Paper that is torn, wrinkled, or has holes.


1

Tap the originals on a flat surface to even the edges.



2

Slide the edge guide on the Automatic Document Feeder.



Paper and Media Handling


- 3 Insert the originals face-up and short edge first into the Automatic Document Feeder.



Note:


Do not load documents above the ▼ arrow mark inside the edge guide.

- 4 Slide the edge guide until it is flush with the originals.




Note:

For 2-up Copy layout, place the original as shown. Make sure the orientation of the original matches the Document Orientation settings.




Scanner glass

- 1 Open the document cover and place your original face-down on the scanner glass.



- 2 Slide the original to the corner.

**Note:**

See the following sections if any problems occur with the scanning area or the scanning direction when using EPSON Scan.

- ➔ [“The edges of your original are not scanned” on page 192](#)
- ➔ [“Multiple documents are scanned into a single file” on page 193](#)

- 3 Close the cover gently.

Note:

When there is a document in the Automatic Document Feeder (ADF) and on the scanner glass, priority is given to the document in the Automatic Document Feeder (ADF).

Inserting a Memory Card

You can print photos that are stored on a memory card, or save scanned data on a memory card. The following memory cards are supported.


SD, miniSD, microSD, SDHC, miniSDHC, microSDHC, SDXC, microSDXC, Memory Stick Duo, Memory Stick PRO Duo, Memory Stick PRO-HG Duo, Memory Stick Micro, MagicGate Memory Stick Duo

Paper and Media Handling



Important:

The following memory cards require an adapter. Attach it before inserting the card into the slot, otherwise the card may get stuck.


- ❑ miniSD, microSD, miniSDHC, microSDHC, microSDXC




- ❑ Memory Stick Micro


1

Insert one card at a time.


2

Check the light stays on.



— = on, ▴▴▴ = flashing


Important:

- ❑ Do not try to force the card all the way into the slot. It should not be fully inserted.
- ❑ Do not remove the memory card while the light is flashing. The data in the memory card may be lost.

Paper and Media Handling

Note:

If the Memory Device Interface settings are set to Disable, the memory card is not recognized.

Copying

Copying Documents

Basic copying

Follow the steps below to copy documents.

- 1 Load paper in the paper cassette.
➔ [“Loading Paper into the Paper Cassette” on page 33](#)

Note:

To copy on a single sheet of thick paper or paper with binding holes, load the paper into the rear paper feed slot after sending the job in step 7. Make sure to change the Paper Source setting to Rear Paper Feed Slot.

➔ [“Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39](#)


- 2 Place original.
➔ [“Placing Originals” on page 42](#)
- 3 Enter **Copy** mode from the Home menu.
- 4 Enter the number of copies by using the numeric keypad on the control panel.
- 5 Select **Layout**, and then select the appropriate layout such as 2-up copying.
- 6 Make the necessary copy settings. Select **Settings** to make more detailed settings.

Note:

☐ Press **Preview** to preview the copy results before you start copying.

☐ You can save your copy settings as a preset.

➔ [“Presets” on page 120](#)

- 7 Press one of the  buttons to set the color mode, and then start copying.

Copy Mode Menu List

Refer to the section below for the Copy mode menu list.

➔ [“Copy Mode” on page 109](#)

Printing

Printing from the Control Panel

Follow the steps below to print from the control panel without using a computer. You can print data from a memory card or an external USB device.

Printing a JPEG file


- 1 Load paper.
 - ➔ “Loading Paper into the Paper Cassette” on page 33
 - ➔ “Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39
- 2 Insert a memory device.
 - ➔ “Inserting a Memory Card” on page 44
- 3 Select **Memory Device** from the Home menu.
- 4 Select **JPEG**.


Note:

- ☐ If you have more than 999 images on your memory device, images are automatically divided into groups and the group selection screen is displayed. Select the group that contains the image you want to print. Images are sorted by the date they were taken.
- ☐ To select another group, select the menu as shown below.
Memory Device > JPEG > Options > Select Group.

- 5 Select the image you want to print.
- 6 Enter the number of prints by using the numeric keypad on the control panel.
- 7 Press **Settings** to make print settings or press **Adjustments** to make color adjustment settings.


Note:

- ☐ For more information on detailed settings, see the Memory Device mode menu list.
 - ➔ “Memory Device Mode” on page 110
- ☐ To select more images, press  and then repeat steps 5 to 6 or swipe horizontally to change the image.

- 8 Press one of the  buttons to set the color mode, and then start printing.

Printing a TIFF file

- 1 Load paper.
 - ➔ “Loading Paper into the Paper Cassette” on page 33
 - ➔ “Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39
- 2 Insert a memory device.
 - ➔ “Inserting a Memory Card” on page 44
- 3 Select **Memory Device** from the Home menu.
- 4 Select **TIFF**.
- 5 Select the file you want to print.
- 6 Check the file information, and then press **Proceed**.
- 7 Enter the number of prints by using the numeric keypad on the control panel.
- 8 Press **Settings** to make the print settings.

Note:
For detailed settings items, refer to the Memory Device mode menu list.
➔ “Memory Device Mode” on page 110
- 9 Press **Proceed**, then confirm the print settings.
- 10 Press one of the  buttons to set the color mode, and then start printing.

Printing from Your Computer

Printer Driver and Status Monitor

The printer driver lets you choose from a wide variety of settings to get the best printing results. The status monitor and the printer utilities help you check the product and keep it in top operating condition.

Printing

Note for Windows users:

- ❑ Your printer driver automatically finds and installs the latest version of the printer driver from Epson's Web site. Click the **Software Update** button in your printer driver's **Maintenance** window, and then follow the on-screen instructions. If the button does not appear in the **Maintenance** window, point at **All Programs** or **Programs** in the Windows Start menu, and check in the **EPSON** folder.*
* For Windows 8:
If the button does not appear in the **Maintenance** window, right-click on the **Start** screen, or swipe from the bottom or top edge of the **Start** screen and select **All apps**, then select **Software Update** from **EPSON** category.
- ❑ If you want to change the language of the driver, select the language you want to use from the **Language** setting in your printer driver's **Maintenance** window. Depending on the location, this function may not be available.

Accessing the printer driver for Windows

You can access the printer driver from most Windows applications, the desktop or the taskbar.

To make settings that apply only to the application you are using, access the printer driver from that application.

To make settings that apply to all of your Windows applications, access the printer driver from the desktop or the taskbar.

Refer to the following sections to access the printer driver.

Note:

Screen shots of the printer driver windows in this User's Guide are from Windows 7.

From Windows applications

- 1 Click **Print** or **Print Setup** on the File menu.
- 2 In the window that appears, click **Printer**, **Setup**, **Options**, **Preferences**, or **Properties**. (Depending on your application, you may need to click one or a combination of these buttons.)

From the desktop

- ❑ **Windows 8 and Server 2012**
Select **Desktop**, **Settings** charm, and **Control Panel**. Then select **Devices and Printers** from the **Hardware and Sound** category. Right-click on the product, or press and hold the product and select **Printing preferences**.
- ❑ **Windows 7 and Server 2008 R2:**
Click the start button, select **Devices and Printers**. Then right-click the product and select **Printing preferences**.
- ❑ **Windows Vista and Server 2008:**
Click the start button, select **Control Panel**, and then select **Printer** from the **Hardware and Sound** category. Then select the product and then click **Select printing preferences**.
- ❑ **Windows XP and Server 2003:**
Click **Start**, **Control Panel**, (**Printers and Other Hardware**), then **Printers and Faxes**. Select the product, then click **Printing Preferences** on the File menu.

Printing


From the shortcut icon on the taskbar

Right-click the product icon on the taskbar, then select **Printer Settings**.

To add a shortcut icon to the Windows taskbar, first access the printer driver from the desktop as described above. Next, click the **Maintenance** tab, and then the **Monitoring Preferences** button. In the Monitoring Preferences window, select the **Register the shortcut icon to the task bar** check box.

Getting information through online help

In the printer driver window, try one of the following procedures.

- ☐ Right-click the item, then click **Help**.
- ☐ Click the  button at the top right of the window, then click the item (for Windows XP only).

Accessing the printer driver for Mac OS X

The table below describes how to access the printer driver dialog.

Dialog Box	How to Access It
Page Setup	Click Page Setup on the File menu of your application. <i>Note:</i> <i>Depending on your application, the Page Setup menu may not appear in the File menu.</i>
Print	Click Print on the File menu of your application.
Epson Printer Utility 4	For Mac OS X 10.8 or 10.7, click System Preferences on the Apple menu and then click Print & Scan . Select your product from the Printers list box, click Options & Supplies, Utility , and then click Open Printer Utility . For Mac OS X 10.6, click System Preferences on the Apple menu and then click Print & Fax . Select your product from the Printers list box, click Options & Supplies, Utility , and then click Open Printer Utility . For Mac OS X 10.5, click System Preferences on the Apple menu and then click Print & Fax . Select your product from the Printers list box, click Open Print Queue and then click Utility button.

Basic Operations

Basic printing

Follow the steps below to print from your computer.

If you cannot change some of the printer driver settings, they may have been locked by the administrator. Contact your administrator or a power user for assistance.


Printing

Note:

- ❑ The screen shots in this manual may vary depending on the model.
- ❑ Before you print, load paper properly.
 - ➔ [“Loading Paper into the Paper Cassette” on page 33](#)
 - ➔ [“Loading Envelopes into the Paper Cassette” on page 36](#)
 - ➔ [“Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39](#)
- ❑ Refer to the section below for the printable area.
 - ➔ [“Printable area” on page 200](#)
- ❑ After completing the settings, print one test copy and examine the results before printing an entire job.

Basic product settings for Windows

- 1 Open the file you want to print.
- 2 Access the printer settings.
 - ➔ [“Accessing the printer driver for Windows” on page 50](#)



- 3 Click the **Main** tab.
- 4 Select the appropriate Paper Source setting.
- 5 Select the appropriate Document Size setting. You can also define a custom paper size. For details, see the online help.

Printing

- 6** Check **Borderless** to print borderless photos.
➔ “[Selecting Paper](#)” on page 27

If you want to control the amount of the image that extends beyond the edges of the paper, click the **Settings** button, select **Auto Expand** as the Method of Enlargement, and then adjust the **Amount of Enlargement** slider.

- 7** Select **Portrait** (tall) or **Landscape** (wide) to change the orientation of your print.

Note:
Select **Landscape** when printing on envelopes.

- 8** Select the appropriate Paper Type setting.
➔ “[Paper type settings from the printer driver](#)” on page 32

Note:
Print quality is automatically adjusted for the selected Paper Type.

- 9** Select the appropriate Quality setting.

Note:
If you are printing high-density data on plain paper, letterhead, or preprinted paper, select Standard-Vivid to make your printout vivid.

- 10** Click **OK** to close the printer settings window.

Note:
To make changes to advanced settings, refer to the relevant section.

- 11** Print your file.


Basic product settings for Mac OS X

- Note:**
- ☐ Screen shots of the printer driver windows in this manual are from Mac OS X 10.7.
 - ☐ When printing envelopes, use the application to rotate the data 180 degrees.

- 1** Open the file you want to print.

Printing

- 2 Access the Print dialog box.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)



Note:

If the simplified dialog box is displayed, click the **Show Details** button (for Mac OS X 10.8 or 10.7) or the ▼ button (for Mac OS X 10.6 or 10.5.8) to extend this dialog box.

- 3 Select the product you are using as the Printer setting.

Note:

Depending on your application, you may not be able to select some of the items in this dialog box. If so, click **Page Setup** on the File menu of your application, and then make suitable settings.

- 4 Select the appropriate Paper Size setting.

Note:

Select **XXX (Borderless)** as the Paper Size if you want to print borderless photos.

➔ [“Selecting Paper” on page 27](#)


- 5 Select the appropriate Orientation setting.

Note:

Select landscape orientation when printing envelopes.

Printing

- 6** Select **Print Settings** from the pop-up menu.



- 7** Select the appropriate **Paper Source** setting.
- 8** Select the appropriate Media Type setting.
➔ [“Paper type settings from the printer driver” on page 32](#)
- 9** Select the appropriate Print Quality setting.

Note:


If you are printing high-density data on plain paper, letterhead, or preprinted paper, select Standard-Vivid to make your printout vivid.

- 10** Select the appropriate Expansion setting during borderless printing to control the amount of the image that extends beyond the edges of the paper.
- 11** Click **Print** to start printing.

Canceling printing

If you need to cancel printing, follow the instructions in the appropriate section below.

Using the product button

Press  to cancel a print job in progress.

Printing

Using the product's status menu

You can cancel a print job in progress on the product's Status Menu.

- 1 Press **i** to display the Status Menu.
- 2 Select **Job Monitor**, then **Print Job**. Ongoing jobs and jobs that are standing by are shown in the list.
- 3 Select the job that you want to cancel.
- 4 Press **Cancel**.

For Windows

Note:


You cannot cancel a print job that has been completely sent to the product. In this case, cancel the print job by using the product.

- 1 Access the EPSON Status Monitor 3.
➡ [“For Windows” on page 163](#)
- 2 Click the **Print Queue** button. The Windows Spooler appears.
- 3 Right-click on the job you want to cancel and then select **Cancel**.

For Mac OS X

Follow the steps below to cancel a print job.


Note:

If you have sent a print job from a Mac OS X 10.6 or 10.5.8 through the network, you may not be able to cancel printing from the computer. Press  on the product's control panel to cancel a print job. To solve this problem, see the online Network Guide.


- 1 Click your product icon in the Dock.
- 2 In the Document Name list, select the document which is printing.


Printing

- 3** Click the **Delete** button to cancel the print job.



For Mac OS X 10.8:

Click the  button to cancel the print job.



Other Options

Printing photos the easy way



Epson Easy Photo Print lets you lay out and print digital images on various types of paper. The step-by-step instructions in the window let you preview the printed images and get the effects you want without having to make any difficult settings.

Using the Quick Print function, you can perform one-click printing with the settings you make.

Starting Epson Easy Photo Print

Note:

You can download Epson Easy Photo Print from the following Epson website.

<http://support.epson.net/>

<http://www.epson.eu/Support> (Europe)

For Windows

❑ Double-click the **Epson Easy Photo Print** icon on the desktop.

❑ **For Windows 8:**

Enter "**Epson Easy Photo Print**" at the search charm, and select the software.

For Windows 7 and Vista:

Click the start button, point to **All Programs**, click **Epson Software**, and then click **Easy Photo Print**.

For Windows XP:

Click **Start**, point to **All Programs**, point to **Epson Software**, then click **Easy Photo Print**.

For Mac OS X

Double-click the **Applications** folder on your Mac OS X hard drive, then double-click in turn on the **Epson Software** and **Easy Photo Print** folders and finally double-click the **Easy Photo Print** icon.

Product presets (For Windows Only)


Printer driver presets make printing a snap. You can also create presets of your own.

Product settings for Windows

- 1** Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 2** Select a Printing Presets in the Main tab. Product settings are automatically set to the values displayed in the pop-up window.

2-sided printing

Use the printer driver to print on both sides of the paper.



Printing

Note:

- ❑ This feature may not be available at some settings.
- ❑ The loading capacity differs during 2-sided printing.
➔ [“Selecting Paper” on page 27](#)
- ❑ Only use papers that are suitable for 2-sided printing. Otherwise, the printout quality may deteriorate.
➔ [“Selecting Paper” on page 27](#)
- ❑ Manual 2-sided printing may not be available when the product is accessed over a network or is used as a shared printer.
- ❑ If the ink runs low during automatic 2-sided printing, the product stops printing and the ink needs to be replaced. When ink replacement is complete, the product starts printing again, but there may be some missing parts in your print. If this happens, print again the page that has missing parts.
- ❑ Depending on the paper and the amount of ink used to print text and images, ink may bleed through to the other side of the paper.
- ❑ The surface of the paper may be smeared during 2-sided printing.

Note for Windows:

- ❑ Four types of 2-sided printing are available: automatic standard, automatic folded booklet, manual standard and manual folded booklet.
- ❑ Manual 2-sided printing is available only when EPSON Status Monitor 3 is enabled. To enable the status monitor, access the printer driver and click the **Maintenance** tab followed by the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.
- ❑ When automatic 2-sided printing is performed, printing may be slow depending on the combination of options selected for Select Document Type in the Print Density Adjustment window and for Quality in the Main window.

Note for Mac OS X:

- ❑ Mac OS X supports automatic standard 2-sided printing only.
- ❑ When automatic 2-sided printing is performed, printing may be slow depending on the Document Type setting in Two-sided Printing Settings

Product settings for Windows

- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)

- 2 Select the appropriate 2-Sided Printing setting.

Note:

Depending on the driver version, the 2-Sided Printing setting may become available when you select the check box. When using automatic printing, make sure the **Auto** check box is checked.

- 3 Click **Settings**, and make the appropriate settings.

Note:

If you want to print a folded booklet, select **Booklet**.

Printing

- 4 Check the other settings and print.

Note:

- ❑ When printing automatically, and if you are printing high-density data such as photos or graphs, we recommend making the settings in the Print Density Adjustment window.
- ❑ The actual binding margin may be different from the specified settings depending on your application. Experiment with a few sheets to examine actual results before printing the entire job.
- ❑ Manual 2-sided printing allows you to print the even-numbered pages first. When you print odd-numbered pages, a blank sheet of paper is output at the end of the print job.
- ❑ When you are printing manually, make sure that the ink is completely dry before reloading the paper.

Product settings for Mac OS X


- 1 Access the Print dialog box.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 2 Make the appropriate settings in the Two-sided Printing Settings pane.
- 3 Check the other settings and print.

Note:

If you are printing high-density data such as photos or graphs, we recommend adjusting Print Density and Increased Ink Drying Time settings manually.

Fit to page printing

Lets you automatically enlarge or reduce the size of your document to fit the paper size selected in the printer driver.



Note:

This feature may not be available at some settings.

Printing

Product settings for Windows

- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 2 Select **Reduce/Enlarge Document** and **Fit to Page** in the More Options tab, and then select the size of the paper you are using from Output Paper.

Note:

*If you want to print a reduced image with centering, select **Center**.*


- 3 Check the other settings and print.

Product settings for Mac OS X

- 1 Access the Print dialog box.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 2 Choose **Scale to fit paper size** for Destination Paper Size in the Paper Handling pane and select the desired paper size from the pop-up menu.
- 3 Check the other settings and print.

Pages per Sheet printing

Lets you use the printer driver to print two or four pages on a single sheet of paper.

**Note:**

This feature may not be available at some settings.

Printing

Product settings for Windows


- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 2 Select **2-Up** or **4-Up** as Multi-Page in the Main tab.
- 3 Click **Page Order**, and make the appropriate settings.
- 4 Check the other settings and print.

Product settings for Mac OS X

- 1 Access the Print dialog box.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 2 Select the desired number of Pages per Sheet and the Layout Direction (page order) in the Layout pane.
- 3 Check the other settings and print.

Anti-Copy Pattern printing (for Windows Only)

This function allows you to print a document as a copy-protected document. When you try to copy a copy-protected document, the string that you added as the anti-copy pattern is printed several times on the document.

**Note:**

This feature may not be available at some settings.

- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)

Printing

- 2 Click **Watermark Features** on the More Options tab, and then select an Anti-Copy Pattern from the Anti-Copy Pattern list.

Note:

- ☐ *This feature is available only with the following settings selected.*

Paper Type: plain papers

Quality: Standard

Auto 2-Sided Printing: Off

Borderless: Off

Color Correction: Automatic

Short Grain Paper: Off

- ☐ *If you want to create your own watermark, click **Add/Delete**. For more details about each setting, see the online help.*

- 3 Click **Settings**, and make the appropriate settings.

Note:

Anti-Copy Pattern are printed in monochrome only.

- 4 Click **OK** to return to the More Options window.

- 5 Click **OK** to close the printer settings window and print.

Watermark printing (For Windows Only)

This function allows you to print a text-based or image-based watermark on your document.



Note:

This feature may not be available at some settings.

- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)

Printing

- 2 Click **Watermark Features** on the More Options tab, and then select a watermark from the Watermark list.

Note:

- ☐ If you want to create your own watermark, click **Add/Delete**. For more details about each setting, see the online help.
- ☐ Saved watermarks can only be used with the printer driver in which you saved the settings. Even if multiple printer names are set for a printer driver, the settings are only available for the printer name in which you saved the settings.
- ☐ When sharing the printer on a network, you cannot create a user defined watermark as a client.


- 3 Click **Settings**, and then make the appropriate settings.

- 4 Click **OK** to return to the More Options window.

- 5 Click **OK** to close the printer settings window and print.

Header/Footer printing (For Windows Only)

This function allows you to print user name, computer name, date, time, or collate number, at the top or bottom of each page in a document.



- 1 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 2 Click **Watermark Features** on the More Options tab, select **Header/Footer**, and then click **Settings**.
- 3 Select the necessary items from the drop-down list in the Header Footer Settings window.

Note:

If you select Collate Number, the number of copies is printed.

- 4 Click **OK** to return to the More Options window.
- 5 Click **OK** to close the printer settings window and print.

Administrator Settings for Printer Driver (for Windows Only)

Administrators can lock the following printer driver settings for each user to prevent unintended changes of the settings.

- ☐ Anti-Copy Pattern
- ☐ Watermark
- ☐ Header/Footer
- ☐ Color
- ☐ 2-sided printing
- ☐ Multi-Page

Note:

You need to logon as an administrator in Windows.

- 1 Windows 8 and Server 2012:
Select **Desktop, Settings, charm, Control Panel**, and then select **Devices and Printers** from the Hardware and Sound category.

Windows 7 and Server 2008 R2:
Click the start button, and then select **Devices and Printers**.

Windows Vista and Server 2008:
Click the start button, select **Control Panel**, and then select **Printer** from the Hardware and Sound category.

Windows XP and Server 2003:
Click **Start**, select **Control Panel**, and then select **Printers and Faxes** from the Printers and Other Hardware category.

- 2 Windows 8, 7, Server 2008, and Server 2012:
Right-click on the product, or press and hold the product, select **Printer properties, Optional Settings**, and then select the **Driver Settings** button.

Windows Vista and Server 2008:
Right-click the icon for your product, click **Optional Settings**, and then click the **Driver Settings** button.

Windows XP and Server 2003:
Right-click the icon for your product, click **Optional Settings**, and then click the **Driver Settings** button.

Printing

- 3** Make the appropriate settings. For more details about each setting, see the online help.
- 4** Click **OK**.

Scanning

Scanning from the Control Panel

You can scan documents and send the scanned image from the product to a connected computer, a memory device, a network folder, and send the scanned image by attaching to an email.

Note:


- ❑ Depending on the product, Scan to Network Folder/FTP and Scan to Email functions may not be supported.
 - ➔ [“Available Features” on page 8](#)
- ❑ You can save your scan settings as a preset.
 - ➔ [“Presets” on page 120](#)

Scanning to a memory device

- 1** Insert a memory card or an external USB device.
 - ➔ [“Inserting a Memory Card” on page 44](#)
- 2** Place original.
 - ➔ [“Placing Originals” on page 42](#)
- 3** Enter **Scan** mode from the Home menu.
- 4** Select **Memory Device**.
- 5** Press **Format**, and then select the file format you want to use to save scanned data to the memory device.
- 6** Press **Settings**, and then make the appropriate scan settings.

Note:

When PDF is selected as the file format, security settings become available allowing you to create a password protected PDF. Select **PDF Settings**.

- 7** Press one of the  buttons to set the color mode, and then start scanning.
Your scanned image is saved.

Scanning to a folder


The Scan to Network Folder/FTP function allows you to save scanned images to a folder on a server. You can specify a saved folder by entering a folder path directly, but it may be easier if you register a saved folder and configure the folder settings in Contacts first before you use this function.

➔ [“Making Contact List Settings” on page 106](#)

- 1 Place original.
➔ [“Placing Originals” on page 42](#)
- 2 Enter **Scan** mode from the Home menu.
- 3 Select **Network Folder/FTP**.
- 4 Press **Contacts** to display a list of registered folders.

Note:

You can also specify the folder by entering the folder path directly. After step 3, press the **Enter Location** field. Select **Communication Mode**, enter the folder path using the numeric keypad and other buttons on the control panel, and then configure the folder settings.

- 5 Press the check box on the list to select the folder, and then press **Proceed**.
 - 6 Press **Menu**. Make the appropriate scan settings.
 - 7 Press one of the  buttons to set the color mode, and then start scanning.
- Your scanned image is saved.

Scanning to an email

The Scan to Email function allows you to send scanned image files by email directly from the product through a preconfigured email server.

Note:

- ☐ Before using this function, make sure you have configured the Email Server Settings and that the Date/Time and Time Difference in Date/Time Settings have been set correctly. Otherwise, time stamps on your emails may not be displayed correctly on the recipient's computer.
➔ [“Email Server Settings” on page 143](#)
➔ [“System Administration Settings” on page 115](#)
- ☐ By using the Scan to PC function instead of this function, you can send an email by entering the address on a computer connected to this product. When using Scan to PC, make sure the computer is turned on.
➔ [“Scanning to a computer” on page 69](#)

- 1 Place original.
➔ [“Placing Originals” on page 42](#)

Scanning

- 2 Enter **Scan** mode from the Home menu.
- 3 Select **Email**.
- 4 If you want to specify email addresses directly, press the **Enter Email Address** field, and then enter an email address.
- 5 If you want to specify email addresses from Contacts, press **Contacts** to display the list, and then select a contact by pressing the check box on the list. Then press **Proceed**.

Note:

You can send an email up to 10 individual email addresses and group.

- 6 Press **Format** and select the file format.
- 7 Press **Menu**.
- 8 Select **Email Settings**. You can specify a name for the scanned image file in Filename Prefix and specify the subject of the email to which you want to attach the scanned file in Subject.


Note:

A predetermined message, "Attached Scan Data", is automatically entered as the body of the email.

- 9 Select **Basic Settings**. Make the appropriate scan settings.

Note:

- ☐ You can specify the maximum size for files that can be attached to an email in Attached File Max Size. Select a larger size if you often send large files.
- ☐ When PDF is selected as the file format, security settings become available allowing you to create a password protected PDF. Select **PDF Settings**.

- 10 Press one of the  buttons to set the color mode, and then start scanning.
Your scanned image is sent by email.

Scanning to a computer

Note:

Make sure you have installed the Epson Event Manager before using this function.

➔ ["Installing the software" on page 152](#)

- 1 Place original.
➔ ["Placing Originals" on page 42](#)

Scanning

2 Enter **Scan** mode from the Home menu.

3 Select **Computer** or **Computer (WSD)**.

4 Select a computer.

Note:


When you select Computer, go to the next step. When you select Computer(WSD), go to the step 7.

5 Press **Format** and select the file format to save the scanned image.

Note:

When Email is selected, you can attach the scanned image to an email.

6 Make the appropriate scan settings.

7 Press one of the  buttons, and then start scanning.

Your scanned image is saved.

Scan mode menu list

Refer to the section below for the Scan mode menu list.

➔ [“Scan Mode” on page 111](#)

Scanning from Your Computer

Scanning in Office Mode

Office Mode lets you quickly scan text documents without previewing your image.

Note:

- ☐ *If you install Epson Scan in Windows Server 2012, Server 2008 and Server 2003, you must have been done install to Desktop Experience.*
- ☐ *See the Help for more details on Epson Scan.*

1 Place your original(s).


➔ [“Placing Originals” on page 42](#)

2 Start Epson Scan.

➔ [“Starting Epson Scan Driver” on page 79](#)

Scanning

- 3 Select Office Mode from the Mode list.



- 4 Select the Document Source setting.
- 5 Select the size of your original as the Size setting.
- 6 Select the Image Type setting.
- 7 Select an appropriate resolution for your original(s) as the Resolution setting.
- 8 Click **Scan**.
- 9 In the File Save Settings window, select the Type setting and then click **OK**.

Note:

- ❑ If the **Show this dialog box before next scan** check box is cleared, Epson Scan starts scanning immediately without displaying the File Save Settings window.
- ❑ You can create a password protected PDF file. Select the Security tab in PDF Plug-in Settings. See the Help for more details on Epson Scan.
- ❑ When you select Skip Blank Page, any blank pages in the document are not scanned.

Scanning

Your scanned image is saved.

Scanning in Professional Mode

Professional Mode gives you total control of your scanning settings and lets you check the changes you have made in a preview image. This mode is recommended for advanced users.

Note:

- ☐ *If you want to install Epson Scan on Windows Server 2012, Server 2008, or Server 2003, you have to install Desktop Experience first.*
- ☐ *See the Help for more details on Epson Scan.*

1

Place your original(s).

➡ [“Placing Originals” on page 42](#)


2

Start Epson Scan.

➡ [“Starting Epson Scan Driver” on page 79](#)

Scanning

- 3 Select **Professional Mode** from the Mode list.



- 4 Select the Document Source setting.

- 5 Select **Photo** or **Document** as the Auto Exposure Type setting.

- 6 Select the Image Type setting.


Scanning

7 Select an appropriate resolution for your original(s) as the Resolution setting.

8 Click **Preview** to preview your image(s). The Preview window opens and displays your image(s).
➔ [“Previewing and Adjusting the Scan Area” on page 77](#)

Note for the Automatic Document Feeder (ADF):

- ☐ The ADF loads your first document page, and then Epson Scan prescans it and displays it in the Preview window. The ADF then ejects your first page. Place your first document page on top of the rest of the pages, and then load the entire document into the ADF.
- ☐ The document page ejected by the ADF has not been scanned yet. Reload the entire document into the ADF.



9 Select the size of the scanned image(s) as the Target Size setting if necessary. You can scan your images at their original size, or you can reduce or enlarge their size by selecting Target Size.

10 Adjust the image quality if necessary.
➔ [“Image Adjustment Features” on page 74](#)

11 Click **Scan**.

12 In the File Save Settings window, select the Type setting and then click **OK**.

Note:

- ☐ If the **Show this dialog box before next scan** check box is cleared, Epson Scan starts scanning immediately without displaying the File Save Settings window.
- ☐ You can create a password protected PDF file. Select the Security tab in PDF Plug-in Settings. See the Help for more details on Epson Scan.






Your scanned image is saved.

Image Adjustment Features







Epson Scan offers a variety of settings for improving color, sharpness, contrast, and other aspects affecting image quality.

See the Help for more details on Epson Scan.


Scanning

Histogram Adjustment	<p>Provides a graphical interface for adjusting highlight, shadow, and gamma levels individually.</p>  <p>The image shows a close-up of pink flowers. The 'before' image on the left has a slightly darker and less vibrant appearance. A blue arrow points to the 'after' image on the right, which is brighter and has more saturated colors.</p>
Tone Correction	<p>Provides a graphical interface for adjusting tone levels individually.</p>  <p>The image shows a pink flower against green foliage. The 'before' image on the left has a slightly washed-out or less contrasted appearance. A blue arrow points to the 'after' image on the right, which has more defined tones and contrast.</p>
Image Adjustment	<p>Adjusts brightness and contrast and the balance of red, green, and blue colors in the overall image.</p>  <p>The image shows a bunch of colorful fruits (possibly tomatoes or peppers) hanging from a branch. The 'before' image on the left has a slightly muted color palette. A blue arrow points to the 'after' image on the right, which has more vibrant and balanced colors.</p>
Color Palette	<p>Provides a graphical interface for adjusting mid-tone levels, such as skin tones, without affecting the highlight and shadow areas of the image.</p>  <p>The image shows red maple leaves against a blue sky. The 'before' image on the left has a slightly less vibrant red in the leaves. A blue arrow points to the 'after' image on the right, where the red is more saturated and the blue is more vibrant.</p>
Unsharp Mask	<p>Sharpens the edges of image areas for an overall clearer image.</p>  <p>The image shows red maple leaves. The 'before' image on the left has slightly softer edges. A blue arrow points to the 'after' image on the right, where the edges of the leaves are sharper and more defined.</p>

Scanning

Descreening	<p>Removes rippled patterns (known as moiré) that can appear in subtly shaded image areas such as skin tones.</p>  <p>The image shows a landscape with a tall, thin tree against a sunset sky. The 'before' image on the left has a visible moiré pattern (rippled lines) across the entire scene. A blue arrow points to the 'after' image on the right, which is clear and free of the moiré pattern.</p>
Color Restoration	<p>Restores the colors in faded photos automatically.</p>  <p>The image shows two men in a shop. The 'before' image on the left is faded and has muted colors. A blue arrow points to the 'after' image on the right, which has vibrant, restored colors.</p>
Backlight Correction	<p>Removes shadows from photos that have too much background light.</p>  <p>The image shows a dog lying on a white surface. The 'before' image on the left has a dark shadow on the dog's face due to backlighting. A blue arrow points to the 'after' image on the right, where the shadow has been removed, and the dog's features are more clearly visible.</p>
Dust Removal	<p>Removes dust marks from your originals automatically.</p>  <p>The image shows a landscape with a green hill and a blue sky with clouds. The 'before' image on the left has several small white dust specks visible. A blue arrow points to the 'after' image on the right, where the dust has been removed.</p>
Text Enhancement	<p>Enhances text recognition when scanning text documents.</p>  <p>The image shows a document with text. The 'before' image on the left has blurry and low-contrast text. A blue arrow points to the 'after' image on the right, where the text is sharper and more legible.</p>
Auto Area Segmentation	<p>Makes Black&White images clearer and text recognition more accurate by separating the text from the graphics.</p>  <p>The image shows a document with text and a photo of a cat. The 'before' image on the left is a mixed-color scan. A blue arrow points to the 'after' image on the right, which is a black and white segmented image where the text and the cat photo are clearly separated from the background.</p>

Scanning

Color Enhance	<p>Enhance a certain color. You can select from red, blue, or green.</p> 
---------------	---

Previewing and Adjusting the Scan Area

Selecting a preview mode

Once you have selected your basic settings and resolution, you can preview your image and select or adjust the image area in a Preview window. There are two types of preview.

- ☐ Normal preview displays your previewed image(s) in their entirety. You can select the scan area and make any image quality adjustments manually.
- ☐ Thumbnail preview displays your previewed image(s) as thumbnail(s). Epson Scan automatically locates the edges of your scan area, applies automatic exposure settings to the image(s), and rotates the image(s) if necessary.

Note:

- ☐ Some of the settings that you change after previewing an image are reset if you change the preview mode.
- ☐ Depending on your document type and the Epson Scan mode you are using, you may not be able to change the preview type.
- ☐ If you preview image(s) without the Preview dialog displayed, image(s) are displayed in the default preview mode. If you preview with the Preview dialog displayed, image(s) are displayed in the preview mode that was displayed just before previewing.
- ☐ To resize the Preview window, click and drag the corner of the Preview window.
- ☐ See the Help for more details on Epson Scan.

Creating a marquee


A marquee is a moving dotted line that appears on the edges of your preview image to indicate the scan area.

Do one of the following to draw a marquee.

Scanning






- ❑ To draw the marquee manually, position the pointer in the area where you want to place the corner of your marquee and click. Drag the cross-hairs over the image to the opposite corner of the desired scan area.



- ❑ To draw the marquee automatically, click the  auto locate icon. You can only use this icon when you are viewing a normal preview and you only have one document on the scanner glass.
- ❑ To draw the marquee at a specified size, type in a new width and height in the Document Size setting.
- ❑ For best results and image exposure, make sure all sides of the marquee are located inside the preview image. Do not include any areas around the preview image in the marquee.

Adjusting a marquee

You can move the marquee and adjust its size. If you are viewing a normal preview, you can create multiple marquees (up to 50) on each image to scan different image areas as separate scan files.

	To move the marquee, position your cursor inside the marquee. The pointer becomes a hand. Click and drag the marquee to the desired location.
	To resize the marquee, position your cursor over the edge or corner of the marquee. The pointer becomes a straight or angled double-arrow. Click and drag the edge or corner to the desired size.
	To create additional marquees of the same size, click this icon.
	To delete a marquee, click inside the marquee and click this icon.
	To activate all marquees, click this icon.

Note:

- ❑ To restrict the movement of the marquee to vertical or horizontal only, hold down the **Shift** key as you move the marquee.
- ❑ To restrict the size of the marquee to the current proportions, hold down the **Shift** key as you resize the marquee.
- ❑ If you draw multiple marquees, make sure you click **All** in the Preview window before you scan. Otherwise, only the area inside the last marquee you drew will be scanned.

Software Information

Starting Epson Scan Driver

This software lets you control all aspects of scanning. You can use this as a standalone scanning program or use it with another TWAIN-compliant scanning program.

How to start

- ❑ Windows 8 and Server 2012:
Select the **EPSON Scan** icon on the desktop.
Or, select **EPSON Scan** from the **Start** screen.
- ❑ Windows 7, Vista, XP, Server 2008 and Server 2003:
Double-click the **EPSON Scan** icon on the desktop.
Or, select the start button icon or **Start** > **All Programs** or **Programs** > **EPSON** > **EPSON Scan** > **EPSON Scan**.
- ❑ Mac OS X:
Select **Applications** > **Epson Software** > **EPSON Scan**.

How to access the help

Click the **Help** button on the Epson Scan driver.

Starting Other Scanning Software

Note:

Some scanning software may not be included in some countries.

Epson Event Manager

Epson Event Manager allows you to assign any of the product's buttons to open a scanning program. You can also save frequently used scanning settings, which can speed up your scanning projects.

You can download this software from the following Epson website.

<http://support.epson.net/>


<http://www.epson.eu/Support> (Europe)

How to start

- ❑ Windows 8:
Right-click on the **Start** screen, or swipe from the bottom or top edge on the **Start** screen, and select **All apps** > **Epson Software** > **Event Manager**.
- ❑ Windows 7, Vista and XP:
Select the start button or **Start** > **All Programs** or **Programs** > **Epson Software** > **Event Manager**.
- ❑ Mac OS X:
Select **Applications** > **Epson Software**, and then double-click the **Event Manager** icon.

Scanning

How to access the help

- ❑ Windows:
Click the  icon in the upper right corner of the screen.
- ❑ Mac OS X:
Click **menu** > **Help** > **Epson Event Manager Help**.

Presto! PageManager

This software lets you scan, manage, and share your photos or documents.

Note:

The Presto! PageManager software CD may be supplied with your product.

How to start

- ❑ Windows 8:
Right-click on the **Start** screen, or swipe from the bottom or top edge on the **Start** screen, and select **All apps** > **Epson Software** > **Presto! PageManager**.

Windows 7, Vista and XP:
Select the start button or **Start** > **All Programs** or **Programs** > **Presto! PageManager** folder > **Presto! PageManager**.
- ❑ Mac OS X:
Select **Application** > **Presto! PageManager**, and then double-click the **Presto! PageManager** icon.

Faxing

Connecting to a Phone Line

Compatible telephone lines and phone cables

Phone line

This product's fax features are designed to work over standard analogue telephone lines (PSTN = Public Switched Telephone Network) and PBX (Private Branch Exchange) telephone systems. (Depending on the environment, some PBX telephone systems may not be supported.) Epson cannot guarantee compatibility with all digital phone environments, especially under the following conditions.

- ☐ When using VoIP
- ☐ When using fiber-optic digital services
- ☐ When adapters such as terminal adapters, VoIP adapters, splitters, or DSL router are connected between the telephone wall jack and the product.

Phone cable

Use a phone cable with the following interface specification.


- ☐ RJ-11 Phone Line
- ☐ RJ-11 Telephone set connection

Depending on the area, a phone cable may be included with the product. If so, use that cable. You may need to connect the phone cable to an adapter provided for your country or region.

Connecting the product to the phone line

Standard phone line (PSTN) or PBX

Connect a phone cable from the telephone wall jack or PBX port to the **LINE** port on the back of the product.




Faxing


Important:

- ❑ If you have a PBX console in the room, connect from the console to the **LINE** port.
- ❑ Do not remove the cap from the **EXT** port of the product when you are not connecting your phone.

DSL or ISDN

Connect a phone cable from your DSL modem, terminal adapter, or ISDN router to the **LINE** port on the back of the product. For more information, consult the documentation that came with your modem, adapter, or router.


Important:

When connecting to a DSL line, you may need to use a separate DSL filter. When using a DSL filter, connect a phone cable from the DSL filter to the product's **LINE** port.


Connecting a phone device

After you connect the product to the phone line, follow the procedure below to connect your telephone or answering machine.

Single phone line


1

Remove the cap from the **EXT** port on the product.



Faxing

- 2** Connect a second phone cable to your telephone or answering machine and to the **EXT** port.




Important:

- ❑ When sharing a single phone line with the phone and the product, make sure you connect the phone to the product's **EXT** port. Otherwise, the phone and product may not work properly.
- ❑ When connecting an answering machine, you may need to change the product's Rings to Answer setting.
➔ ["Setting the number of rings to answer" on page 86](#)

Two phone lines (example of ISDN)

Connect a second phone cable to your telephone or answering machine and to the port on the terminal adapter or ISDN router.



Setting Up for Faxing

Basic settings

This section describes the minimum settings required for using the fax features.

Note:

The Lock Setting function in the Admin Settings menu allows an administrator to password protect the settings from being changed.

➔ ["System Administration Settings" on page 115](#)

Using the Fax Setting Wizard

The product's Fax Setting Wizard menu guides you through setting up the basic fax features. The wizard is automatically displayed when the product is turned on for the first time. If you have already configured the settings, skip this section unless you need to change the settings.



Important:

Before starting the wizard, make sure you have connected the product and your phone device to the phone line correctly.

➔ *["Connecting to a Phone Line" on page 81](#)*

1 Enter **Setup** mode from the Home menu.

2 Select **System Administration**.

3 Select **Fax Settings**.

4 Select **Fax Setting Wizard**.

The Fax Setting Wizard screen is displayed. Press **Start** to continue.

5 On the Fax Header screen, enter the sender's name (up to 40 characters).

6 On the Your Phone Number screen, enter your phone number (up to 20 digits).

Note:

- ☐ *You should enter your name and phone number in the fax header before sending faxes so that recipients can identify the origin of the fax.*
- ☐ *You can change the header information later. Access the menu as shown below.
Setup > System Administration > Fax Settings > Basic Settings > Header*

7 If you have subscribed to a distinctive ring service from your telephone company, select **Proceed** in the DRD Setting screen. Select the ring pattern to be used for incoming faxes (or select **On**), and then go to Step 10. If you do not need to set this option, select **Skip**, and then go to the next step.

Note:

- ☐ *Distinctive ring services, offered by many telephone companies (the service name differs by company), allows you to have several phone numbers on one phone line. Each number is assigned a different ring pattern. You can use one number for voice calls and another for fax calls. Select the ring pattern assigned to fax calls in DRD Setting.*
- ☐ *Depending on the region, **On** and **Off** are displayed as the DRD Setting options. Select **On** to use the distinctive ring feature.*
- ☐ *If you select **On** or one of the ring patterns other than All, Receive Mode is automatically set to Auto.*
- ☐ *You can change the DRD Setting later. Access the menu as shown below.
Setup > System Administration > Fax Settings > Receive Settings > DRD*

Faxing

- 8** On the Receive Mode Setting screen, select **Yes** if you have connected an external telephone or answering machine to the product, and then go to the next step. If you select **No**, Receive Mode is automatically set to Auto. Go to Step 10.



Important:

When no external telephone is connected to the product, Receive Mode must be set to Auto; otherwise you cannot receive faxes.

- 9** On the next Receive Mode Setting screen, select **Yes** to receive faxes automatically. Select **No** to receive faxes manually.

Note:

- ☐ When you have connected an external answering machine and select to receive faxes automatically, make sure the *Rings to Answer* setting is correct.
➔ [“Setting the number of rings to answer” on page 86](#)
- ☐ If you select to receive faxes manually, you need to answer every call and operate the product's control panel or your phone to receive faxes.
➔ [“Receiving a fax manually” on page 101](#)
- ☐ You can change the Receive Mode setting later. Access the menu as shown below.
Setup > System Administration > Fax Settings > Receive Settings > Receive Mode

- 10** On the Confirm Settings screen, check the settings you made, and then select **Proceed**. Press **↵** to correct or change the settings.

- 11** Follow the on-screen instructions to run **Check Fax Connection** and print a report of the check result. If there are any errors reported, try the solutions on the report, and then run the check again.

Note:

- ☐ If the *Select Line Type* screen is displayed, see the following section.
➔ [“Setting the line type” on page 85](#)
- ☐ If the *Select Dial Tone Detection* screen is displayed, select **Disable**.
However, disabling the dial tone detection function may drop the first digit of a fax number and send the fax to the wrong number.
- ☐ To run the check again after closing the wizard, access the menu as shown below.
Setup > System Administration > Fax Settings > Check Fax Connection

Setting the line type

If you are connecting the product to a PBX phone system or terminal adapter, change the Line Type setting as described below.

Note:

PBX (Private Branch Exchange) is used in office environments where an external access code such as “9” must be dialed to call an outside line. The default Line Type setting is PSTN (Public Switched Telephone Network), which is a standard phone line, similar to the one in your home.

- 1** Enter **Setup** mode from the Home menu.

Faxing

- 2 Select **System Administration**.
- 3 Select **Fax Settings**.
- 4 Select **Basic Settings**.
- 5 Select **Line Type**.
- 6 Select **PBX**.
- 7 Select **Use** or **Do Not Use** on the Access Code screen. If you select **Use**, go to the next step.
- 8 Enter an external access code in the Access Code field.

Note:

When connecting to a PBX phone system, we recommend making the access code setting first. After you have made the setting, enter # (hash) instead of the actual external access code when entering an outside fax number or storing it in the contact list. The product automatically replaces the # with the set code when dialing. Compared to entering an actual code, using # may help avoid connection problems.

Setting the number of rings to answer

If you have connected an external answering machine and selected to receive faxes automatically, make sure the Rings to Answer setting is correct.

**Important:**

The Rings to Answer setting indicates the number of rings that must occur before the product automatically receives a fax. If the connected answering machine is set to pick up on the fourth ring, you should set the product to pick up on the fifth ring or later. Otherwise the answering machine cannot receive voice calls. Depending on the region, this setting may not be displayed.

- 1 Enter **Setup** mode from the Home menu.
- 2 Select **System Administration**.
- 3 Select **Fax Settings**.
- 4 Select **Receive Settings**.
- 5 Select **Rings to Answer**.

Faxing

6

Select the number of rings, which is at least one ring greater than that of the answering machine.

Note:

The answering machine picks up every call faster than the product, but the product can detect fax tones and start receiving faxes. If you answer the phone and you hear a fax tone, check that the product has started receiving the fax, and then hang up the phone.

Advanced settings

This section introduces advanced fax settings. Access the menus as indicated under each topic. See the menu list for an explanation about each menu and option.

➔ [“System Administration Settings” on page 115](#)

Settings for sending faxes

- ❑ Changing the fax communication speed.
 - ➔ Setup > System Administration > Fax Settings > Basic Settings > Fax Speed

Note:

The fax speed selected here is also applied when receiving faxes.

- ❑ Creating a contact list for faxing.
 - ➔ [“Creating a Contact” on page 106](#)
- ❑ Changing the default settings for sending faxes such as the resolution and the document size.
 - ➔ Setup > System Administration > Fax Settings > User Default Settings

Settings for receiving faxes

- ❑ Changing received fax output settings.

By default, the product prints every fax received. You can change the settings to save received faxes in the product's memory, on a computer, or to an external memory device.

 - ➔ [“Saving and Forwarding Received Faxes” on page 95](#)
- ❑ Selecting paper cassettes for printing faxes and fax reports.

If your product has more than one paper cassette, you can select which cassette to use for printing faxes and fax reports.

 - ➔ Setup > System Administration > Printer Settings > Paper Source Settings > Auto Select Settings > Fax

Note:

When more than one cassette is selected from the menu above, the most suitable cassette is automatically selected according to the paper size setting for each cassette and the size of received faxes or fax reports.

- ❑ Changing settings for printing faxes and fax reports.
 - ➔ Setup > System Administration > Fax Settings > Output Settings

Faxing

Installing FAX Utility for faxing from a computer

Epson FAX Utility allows you to send a fax from a computer and save received faxes in a specified folder. Follow the procedure below to install FAX Utility. PC-FAX Driver is installed at the same time. This is necessary for sending faxes.

**Important:**

Install the printer driver before installing FAX Utility.

Windows

Insert the software disc that came with your product, and then click setup.exe in the following folder.
\\Apps\\FaxUtility\\setup.exe

**Important:**

Select the same port used for the printer driver.

Mac OS X

Download FAX Utility from the following Epson website.

<http://support.epson.net/setupnavi/>

After installing FAX Utility, follow the procedure below to add the fax driver.

1

Select **Apple - System Preference - Print & Fax** to display the printer list.

2

Click the + add button.

3

Click **Default** when the add printer screen is displayed.

4

When the PC-FAX Driver is displayed in the list, select it and then click **Add**.

Note:

- ☐ *It may take a while before the PC-FAX Driver is displayed.*
- ☐ *The PC-FAX Driver name starts with "FAX" followed by the product name and connection method in parentheses such as (USB).*

5

Select **Quit System Preferences** from the System Preferences menu.

Sending Faxes

Basic operations

Follow the steps below to send a monochrome (B&W) or color fax. When sending a monochrome fax, the scanned document is temporarily stored in the product's memory and you can preview it on the LCD screen before sending.

Faxing

Note:

The product can accept up to 50 monochrome fax jobs. You can check or cancel the reserved fax job using Status Menu.

➔ [“Checking fax jobs that are ongoing or waiting” on page 103](#)

1 Place original. You can send up to 100 pages in one transmission.

➔ [“Placing Originals” on page 42](#)

2 Enter **Fax** mode from the Home menu.

Note:

To fax a double-sided document, place your document in the ADF. Press **Menu**, select **Fax Send Settings**, **ADF 2-Sided**, and then **On**. You cannot fax double-sided documents in color.

3 Specify the fax recipients using one or a combination of the following methods. You can send a monochrome fax to up to 200 recipients (WF-7610 Series/WF-7620) or 100 recipients (WF-3620 Series/WF-3640 Series).

Manually entering a fax number	Press the Enter a Fax Number field and enter the fax number (up to 64 digits). Press the fax number field again to add another fax number.
Selecting from the contact list	Press Contacts to display the contact list screen. Select one or more recipients from the list by selecting the check boxes (press the boxes again to deselect). Press the Search box to search for recipients by name, index name, or entry number. After selecting recipients, press Proceed .
Selecting from the sent fax history	Press History to display the sent fax history. Select a recipient from the list, press Menu on the Details screen, and then select Send to this number .

Note:

- ☐ To delete entered recipients, press the “fax number entry” field and select the recipient you want to delete from the destination list. Then press **Delete from the List**.
 - ☐ When the Direct Dialing Restrictions option in Security Settings is enabled, you can only select fax recipients from the contact list or the sent fax history. You cannot manually enter a fax number.
 - ☐ You cannot send a color fax to more than one recipient at a time.
 - ☐ If your phone system is PBX and you need an external access code such as “9” to get an outside line, enter the access code at the beginning of the fax number. If the access code has been set in the Line Type setting, enter # (hash) instead of the actual access code.
- ➔ [“Setting the line type” on page 85](#)

4 Press **Menu**, and then select **Fax Send Settings** to change the fax transmission settings, such as the resolution, if necessary.

See the menu list for an explanation of each of the settings.

➔ [“Fax Mode” on page 111](#)

Note:

You can save your fax settings as a preset. For more information, see the following section.

➔ [“Presets” on page 120](#)

Faxing

- 5** Go to Step 6 if you do not want to preview before sending. To preview the fax (monochrome fax only), press **Preview** on the fax top screen.

The product starts scanning the documents and displays the scanned image on the LCD screen. To start sending the fax, go to Step 6.

Note:

- ☐ You cannot preview images when the **Direct Send** option from the Fax Send Settings menu is enabled.
- ☐ When the preview screen is left untouched for 20 seconds, the fax is sent automatically.
- ☐ When you want to rescan the document, press **Retry** on the preview screen. Reset the document or change the send settings as necessary, and then repeat this step.

- 6** Press **Color** or **B&W** to start sending the fax.
To cancel sending the fax, press **Stop**. You can also cancel the job, or check the job status/result on the Job Monitor or Job History screen.

For more details on checking the job status/result, see the following section.

➔ [“Using the status menu” on page 103](#)

Note:

If the **Save Failure Data** option is enabled, faxes that failed to be sent are stored. You can resend these stored faxes from the Status Menu screen.

➔ **Setup > System Administration > Fax Settings > Send Settings > Save Failure Data**

Other options

Using handy fax features

This section describes how to use other handy fax features to improve your productivity.

Note:

The **Lock Setting** function in the Admin Settings menu allows an administrator to password protect the settings from being changed.

➔ [“System Administration Settings” on page 115](#)

- ☐ Sending a large volume of monochrome documents (**Direct Send**)

When sending a monochrome fax, the scanned document is temporarily stored in the product's memory. If a large volume of documents is scanned, the product may run out of memory and stop scanning halfway. You can prevent this by using the **Direct Send** option from the Fax Send Settings menu. The product starts scanning after the connection is made and then scans and sends simultaneously without saving the scanned image to its memory. Even when the memory is already full, you can send a monochrome fax using this option. Note that you cannot use this option when sending faxes to more than one recipient.

- ☐ Prioritizing urgent faxes (**Priority Send**)

When you want to send an urgent fax, and there are already multiple faxes waiting to be sent, you can send the urgent fax as soon as an ongoing fax job is finished. To do this, enable **Priority Send** in the Fax Send Settings menu.

Faxing

before you press **Color** or **B&W**.

Note that a fax job sent from a computer is given priority over Priority Send fax jobs.

☐ Saving on connection times and fees by using batch operations (**Batch Send**)

When the Batch Send option is enabled (disabled by default), the product checks all of the faxes waiting to be sent in its memory, and then groups faxes for the same recipient together to send them as a batch. Up to 5 files and/or up to 100 pages in total can be sent using the batch operation. Access the menu as shown below.

➔ Setup > System Administration > Fax Settings > Send Settings > Batch Send

Note:

- ☐ This function only works when the recipient information is identical. If the same recipient is found in two fax jobs, but one of the jobs contains another recipient, the product does not group them together.
- ☐ Even if the recipient information matches, scheduled faxes are not grouped together unless the time to send the fax matches.
- ☐ This function is not applied to faxes sent from a computer, or faxes sent with the Priority Send or Direct Send option enabled.

☐ Sending different-sized documents using the ADF (**Continuous Scan from ADF**)

If you place different-sized documents in the ADF at the same time, they may not be sent at their original sizes. To send different-sized documents using the ADF, first enable Continuous Scan from ADF option from the Fax Send Settings menu. The product will then ask you if you want to scan another page each time you finish scanning documents in the ADF before starting transmission. Using this feature, you can sort and scan documents by size. This is also useful when faxing a large volume of documents, which cannot be loaded in the ADF at the same time.

☐ Using the **On Hook** function (WF-7610 Series/WF-7620 Series only)

The On Hook function allows you to hear tones and voices from the product's internal speaker while leaving the connected phone on the hook. Press **On Hook** on the fax top screen, and then enter the fax number on the control panel. You can use this feature when you want to get a specific document from an on demand fax service by following the service's audio guidance.

Sending a fax at a specified time

You can set to send a fax at a specified time. You cannot send color faxes when using this function.


Note:

Make sure the product's date and time setting is correct.

➔ Setup > System Administration > Common Settings > Date/Time Settings

- 1** Follow Steps 1 to 4 in [“Basic operations” on page 88](#).
- 2** On the fax top screen, press **Menu**, and then select **Send Fax Later**.
- 3** Select **On**, and then enter the time you want to send the fax. When you have finished, press **OK**.


Faxing

- 4 Press  (B&W) to start scanning the fax.

The scanned image is sent at the specified time. If the product is powered off at the specified time, the fax is sent when the product is turned on.

Sending a fax on demand (fax polling)

The Polling Send function allows you to store one scanned document (up to 100 pages in monochrome) to be sent automatically upon request from another fax machine. Your customers or business partners can receive the document just by calling your fax number using the polling receive function on their fax machines.

- 1 Place original.
➔ [“Placing Originals” on page 42](#)
- 2 Enter **Fax** mode from the Home menu.
- 3 Press **Menu**, select **Polling Send**, and then **On**.
- 4 Press **Menu**, and then select **Fax Send Settings** to change the fax transmission settings, such as the resolution, if necessary. See the menu list for an explanation of each of the settings.
➔ [“Fax Mode” on page 111](#)
- 5 Press  (B&W) to start scanning the document.
The scanned document is stored until you delete it. To delete the stored document, access it from Status Menu.
➔ [“Checking fax jobs that are ongoing or waiting” on page 103](#)

Note:

Because only one document can be stored, you will be asked if you want to overwrite when one document has already been stored.

Sending a stored fax

You can store one scanned document (up to 100 pages in monochrome) in the product's memory so that you can send it to anyone at anytime. This feature is handy for documents that you are frequently asked to send by your customers or business partners.

- 1 Place original.
➔ [“Placing Originals” on page 42](#)
- 2 Enter **Fax** mode from the Home menu.
- 3 Press **Menu**, and select **Store Fax Data**, then **On**.
- 4 Press **Menu**, and then select **Fax Send Settings** to change the fax transmission settings, such as the resolution, if necessary. See the menu list for an explanation of each of the settings.
➔ [“Fax Mode” on page 111](#)

Faxing

- 5 Press \diamond (B&W) to start scanning the document.
The scanned document is stored until you delete it. To send the stored document, access it from the Status Menu.
➔ [“Checking fax jobs that are ongoing or waiting” on page 103](#)


Note:

Because only one document can be stored, you will be asked if you want to overwrite when one document has already been stored.

Sending a fax from a connected phone

If the phone number and fax number of the recipient is the same, you can send a fax after talking over the phone with the recipient.

- 1 Place original.
➔ [“Placing Originals” on page 42](#)
- 2 Dial the number from the phone connected to the product. You can talk over the phone with the recipient if needed.



- 3 Press **Start Fax** on the LCD screen of the product.
- 4 Select **Send**.
- 5 When you hear a fax tone, press \diamond (Color) or \diamond (B&W) to start sending the fax.
- 6 Hang up the phone.

Sending a fax from a computer

Using Epson FAX Utility, you can fax documents created using an application such as a word processing or spreadsheet application directly from your computer. For information on how to install FAX Utility, see the following section.

➔ [“Installing FAX Utility for faxing from a computer” on page 88](#)

Note:

The following explanation uses Microsoft Word as an example for Windows OS, and Text Edit for Mac OS X. The actual operations may differ depending on the application you use. For more details, see the application's help.

Faxing

- 1 Open the file you want to fax.
- 2 Select the Print menu from your application's File menu. The application's print setting screen is displayed.
- 3 Windows: Select your printer (FAX) from the printer selection box, and then change the print settings as needed.
Mac OS X: Select your printer (FAX) from the printer selection box, click ▼, and then change the print settings as needed.
- 4 Windows: Click **Properties**, change the fax transmission settings as needed, and then click **OK**.
Mac OS X: Select **Fax Settings**, and then change the fax transmission settings as needed.
- 5 Windows: Click **OK**. The Recipient Settings screen is displayed. Select one or more recipients and then click **Next**.
Mac OS X: Select **Recipient Settings**, and then select one or more recipients.
- 6 Specify the content of the cover sheet as needed. (For Mac OS X, skip this step.)
- 7 Click **Send** or **Fax** to send the fax. The fax job is sent to the product.

Note:

Windows FAX Utility allows you to save up to 1000 contacts (PC-FAX Phone Book). In addition, both Windows and Mac FAX Utility allow you to edit the product's contact list. For more details, see the FAX Utility Help.

Receiving Faxes

Setting up the receive mode

The product is initially set to receive faxes automatically (**Receive Mode - Auto**). You can change it to **Manual** if you connect an external telephone to the product.

In automatic receive mode, the product automatically receives every fax and outputs them according to the Fax Output setting.

➔ [“Saving and Forwarding Received Faxes” on page 95](#)

In manual receive mode, you need to answer every call and operate the product's control panel or your phone to receive faxes. The received fax is output according to the Fax Output settings.

➔ [“Receiving a fax manually” on page 101](#)

When setting up the fax features for the first time, or when you need to change the settings due to a change in your phone system or for any other reason, use the Fax Setting Wizard to set up the product correctly.

➔ [“Using the Fax Setting Wizard” on page 84](#)

Saving and Forwarding Received Faxes

The product provides the following features to save and forward received faxes.

- ❑ Saving in the product's **Inbox**
 - ➔ [“Saving Received Faxes in the Inbox” on page 95](#)
- ❑ Saving in an external memory device
 - ➔ [“Saving Received Faxes in an External Memory Device” on page 97](#)
- ❑ Saving on a computer
 - ➔ [“Saving Received Faxes on a Computer” on page 97](#)
- ❑ Forwarding to another fax machine
 - ➔ [“Forwarding Received Faxes” on page 99](#)
- ❑ Forwarding to an email address, or to a shared folder on a network
 - ➔ [“Forwarding Received Faxes” on page 99](#)

Note:

- ❑ *Depending on the product, forwarding received faxes to an email address or to a folder may not be supported.*
 - ➔ [“Available Features” on page 8](#)
- ❑ *The above features can be used at the same time. If you do use them all at the same time, received documents are saved to the **Inbox**, to an external memory device, on a computer, and forwarded to the specified destination.*
- ❑ *For WF-7610 Series/WF-7620 Series, when there are received documents that have not been read, saved or forwarded yet, the number of the unprocessed jobs is displayed on the fax mode icon.*
 - ➔ [“Notification of unprocessed received faxes \(For the WF-7610 Series/WF-7620 Series only\)” on page 102](#)

Saving Received Faxes in the Inbox

You can set to save received faxes in the product's **Inbox**. Up to 100 documents can be saved. If you use this feature, received documents are not automatically printed. You can view them on the product's LCD screen and print only when needed.

Note:

Saving 100 documents may not be possible depending on the usage conditions such as the file size of saved documents, and using of multiple fax saving features at a time.

Setting to save received faxes in the Inbox

- 1** Enter **Setup** from the Home menu.
- 2** Select **System Administration > Fax Settings > Output Settings > Fax Output**.

Faxing

- 3 Check the current settings displayed on the screen, and press **Settings**.
- 4 Select **Save to Inbox > Yes**.
- 5 For WF-7610 Series/WF-7620 Series, select the option to use when the **Inbox** is full.
 - ☐ **Receive and print faxes:** The product prints all received documents that cannot be saved in the **Inbox**.
 - ☐ **Reject incoming faxes:** The product does not answer incoming fax calls.

Checking the received faxes on the LCD screen











- 1 Enter **Fax** from the Home menu.

Note for WF-7610 Series/WF-7620 Series:

When there are received faxes that have not been read, the number of unread documents is displayed on the fax mode icon on the home screen.

➔ [“Notification of unprocessed received faxes \(For the WF-7610 Series/WF-7620 Series only\)” on page 102](#)

- 2 Select **Open Inbox**.
- 3 If the **Inbox** has been password protected, enter the **Inbox** password or the administrator password.
- 4 Select the fax to view from the list.
The contents of the fax are displayed.

- ☐ : Rotates the image to the right by 90 degrees.
- ☐    : Moves the screen in the direction of the arrows.
- ☐  : Reduces or enlarges.
- ☐  : Moves to the previous or the next page.
- ☐ **View:** Displays or hides the operation icons.
- ☐ *: Deletes the previewed documents.

*: This icon is only displayed for the WF-7610 Series/WF-7620 Series.

- 5 Press **Menu**, select whether to print or delete the document you have viewed, and then follow the on-screen instructions.



Important:

If the product runs out of memory, receiving and sending faxes may be disabled. Delete documents that you have already read or printed.

Saving Received Faxes in an External Memory Device

You can set to convert received documents into PDF format and save them in an external memory device connected to the product. You can also set to automatically print the documents while saving them in the memory device.



Important:

Keep the memory device connected to the product as long as possible. If you leave the device disconnected, the product temporarily saves received documents and may result in a memory full error that disables sending and receiving faxes. For the WF-7610 Series/WF-7620 Series, while the product is temporarily saving documents, the number of unsaved jobs is displayed on the fax mode icon on the home screen.

➔ [“Notification of unprocessed received faxes \(For the WF-7610 Series/WF-7620 Series only\)” on page 102](#)

- 1 Insert an external USB device.
- 2 Enter **Setup** from the Home menu.
- 3 Select **System Administration > Fax Settings > Output Settings > Fax Output**.
- 4 Check the current settings displayed on the screen, and press **Settings**.
- 5 Select **Other Settings > Create Folder to Save**.
- 6 Check the message on the screen and then press **Create**.
A folder to save received documents is created in the memory device.
- 7 Press **3** to return to the **Fax Output** screen.
- 8 Select **Save to Memory Device > Yes**. To print the documents automatically while saving them in the memory device, select **Yes and Print**.

Saving Received Faxes on a Computer

You can set to convert received documents into PDF format and save them on a computer connected to the product. You can also set to automatically print the documents while saving them on the computer.

First, you need to use FAX Utility to make the setting. Install FAX Utility on the computer.



Important:

- ☐ Set the product's receive mode to **Auto**.
➔ [“Setting up the receive mode” on page 94](#)
- ☐ Try not to let your computer enter sleep mode. If the computer is left in sleep mode or if it is turned off, the product temporarily saves received documents and may result in a memory full error that disables sending and receiving faxes. For the WF-7610 Series/WF-7620 Series, while the product is temporarily saving documents, the number of unsaved jobs is displayed on the fax mode icon on the home screen.
➔ [“Notification of unprocessed received faxes \(For the WF-7610 Series/WF-7620 Series only\)” on page 102](#)

Faxing

- 1 Start FAX Utility on the computer connected to the product.

Windows:

Click the start button (Windows 7 and Vista) or click Start (Windows XP), point to All Programs, select Epson Software, and then click FAX Utility.

For Windows 8, right-click on the Start screen, or swipe from the bottom or top edge on the Start screen, and select All apps > Epson Software > FAX Utility. (Server OS is not supported.)

Mac OS X:

Click System Preference, click Print & Fax or Print & Scan, and then select FAX (your product) from Printer. Then click as follows;

Mac OS X 10.6.x, 10.7.x, 10.8.x: Option & Supplies - Utility - Open Printer Utility

Mac OS X 10.5.8: Open Print Queue - Utility

- 2 Open the setting screen of FAX Utility.

Windows:

Select **Fax Settings for Printer > Received Fax Output Settings**.

Mac OS X:

Click **Fax Receive Monitor**, select the product, and then click **Received Fax Output Settings**.

- 3 Click **Save faxes on this computer**, and specify the folder to save received documents.

- 4 Make the other settings as necessary, and then send the setting to the product.

Note:

For details on the setting items and the procedure, see the help of FAX Utility.

- 5 On the product's control panel, enter **Setup**.

- 6 Select **System Administration > Fax Settings > Output Settings > Fax Output**.

- 7 The current setting is displayed. Check that the product is set to save faxes on a computer (**Save to Computer**). If you want to automatically print received documents while saving them on the computer, press **Settings** and go to the next step.

- 8 Select **Save to Computer > Yes and Print**.

Note:

*To stop saving received document on the computer, set **Save to Computer** to **No** on the product. You can also use FAX Utility to change the setting, however, changing from FAX Utility is not allowed while there are received faxes that have not been saved on the computer.*

Forwarding Received Faxes

You can set to forward received documents to another fax machine, or convert the documents into PDF format and forward them to a shared folder on a network or to an email address. Forwarded documents are deleted from the product. First register the forwarding destinations to the contacts list.

➔ [“Making Contact List Settings” on page 106](#)

Note on forwarding received faxes to another fax machine:

Color documents cannot be forwarded to another fax machine. They are processed as documents that failed to be forwarded.

Notes on forwarding received faxes to an email address or to a network folder:

- ☐ Color documents cannot be forwarded to another fax machine. They are processed as documents that failed to be forwarded.
- ☐ Depending on the product, forwarding received faxes to an email address or to a folder may not be supported.
➔ [“Available Features” on page 8](#)
- ☐ Before you use this feature, make sure you have configured the following settings.
 - Configure the email server settings.
➔ [“Email Server Settings” on page 143](#)
 - Enter the correct Date/Time and Time Difference settings. Access the menus from **Setup > System Administration > Common Settings** from the Home menu.

- 1** Enter **Setup** from the Home menu.
- 2** Select **System Administration > Fax Settings > Output Settings > Fax Output**.
- 3** Check the current settings displayed on the screen, and press **Settings**.
- 4** Select **Forward > Yes**.

Note:

To print the documents automatically while forwarding them, select **Yes and Print**.

- 5** Select **Other Settings > Where to Forward**.
- 6** Select forwarding destinations from the contacts list.

Note:

- ☐ Press **View** to sort the contacts by product's feature.
- ☐ You can specify up to five forwarding destinations. Press the check box to select the destination. Press the box again to cancel the selection.

- 7** When finished selecting forwarding destinations, press **Proceed**.

Faxing

- 8 Check that the forwarding destinations you selected are correct, then press **Close**.
- 9 Select **Options When Forwarding Failed**.
- 10 Select whether to print received documents or save them in the product's **Inbox** when forwarding them is failed.



Important:

When you set to save documents that failed to be forwarded in the **Inbox**, you should delete the documents from the **Inbox** once they have been checked. For the WF-7610 Series/WF-7620 Series, while there are documents waiting or that have failed to be forwarded, the number of unfinished jobs is displayed on the fax mode icon on the home screen.

- ➔ [“Checking the received faxes on the LCD screen” on page 96](#)
- ➔ [“Notification of unprocessed received faxes \(For the WF-7610 Series/WF-7620 Series only\)” on page 102](#)

- 11 When forwarding to an email address, you can specify a subject for the email. Select **Email Subject to Forward**, and enter the subject.

Note:

- ☐ If you have selected a shared folder on a network or an email address as the forwarding destination, we recommend that you test if you can send a scanned image to the destination in the scan mode. Select **Scan** > **Email**, or **Scan** > **Network Folder/FTP** from the Home menu, select the destination, and then start scanning.
 - ➔ [“Scanning to a folder” on page 68](#)
 - ➔ [“Scanning to an email” on page 68](#)
- ☐ You can set to receive a new fax notification on a Windows computer when received documents are saved to a shared folder on a network. Use FAX Utility to make the settings. For details, see the help of FAX Utility.

Receiving a fax by polling

This allows you to receive a fax from the fax information service you have called.

- 1 Load paper. Skip this step if you have set the product not to print received faxes in the Fax Output setting.
 - ➔ [“Loading Paper into the Paper Cassette” on page 33](#)
- 2 Enter **Fax** mode from the Home menu.
- 3 Press **Menu**, and then select **Polling Receive**.
- 4 Select **On**.
- 5 Enter the fax number.
- 6 Press (Color) or (B&W) to start receiving the fax.

Receiving a fax manually

If your phone is connected to the product, and the Receive Mode has been set to Manual, you can receive fax data after the connection is made.

1 Load paper. Skip this step if you have set the product not to print the received faxes in the Fax Output setting.
➡ [“Loading Paper into the Paper Cassette” on page 33](#)

2 When the telephone rings, lift the phone connected to the product.



3 When you hear a fax tone, press **Start Fax** on the LCD screen of the product.

4 Select **Receive**.

5 Press **Color** or **B&W** to receive the fax, and then put the phone back on the hook.

Note:

The Remote Receive function allows you to start receiving faxes using your phone instead of operating the product. Enable this function and set a Start Code. If you are in another room with a cordless handset, you can start receiving the fax just by entering the code using the handset.

➡ *Setup > System Administration > Fax Settings > Receive Settings > Remote Receive*

Checking Fax Job Status and History

Notification of unprocessed received faxes (For the WF-7610 Series/ WF-7620 Series only)

When there are unprocessed received documents, the number of unprocessed jobs is displayed on the fax mode icon on the home screen. See the table below for a definition of the "unprocessed".



Note:

If you are using more than one of the fax output settings, the number of unprocessed jobs may be displayed as "2" or "3" even if only one fax has been received. For example, if you have set to save faxes in the **Inbox** and on a computer and one fax is received, the number of unprocessed jobs is displayed as "2" if the fax has not been saved to the **Inbox** and on a computer.

Received Fax Output Setting	Unprocessed Status
Printing ^{*1}	Received documents are waiting to be printed or printing is in progress.
Saving in the Inbox	There are unread received documents in the Inbox . ➔ "Saving Received Faxes in the Inbox" on page 95
Saving in an external memory device	There are received documents that have not been saved in the device because there is no device containing a folder specifically created to save received documents connected to the product or for other reasons. ➔ "Saving Received Faxes in an External Memory Device" on page 97 ➔ "Checking the received faxes on the LCD screen" on page 96
Saving on a computer	There are received documents that have not been saved on the computer because the computer is in sleep mode or for other reasons. ➔ "Saving Received Faxes on a Computer" on page 97 ➔ "Checking fax jobs that are ongoing or waiting" on page 103
Forwarding	There are received documents that have not been forwarded or failed to be forwarded ^{*2} . ➔ "Forwarding Received Faxes" on page 99

^{*1} When you have set none of the fax output settings, or when you have set to print received documents while saving them in an external memory device or a computer.

^{*2} When you have set to save documents that could not be forwarded in the **Inbox**, there are unread documents that failed to be forwarded in the **Inbox**. When you have set to print documents that failed to be forwarded, printing is not complete.

Using the status menu

Checking fax jobs that are ongoing or waiting

You can perform the following operations from the Job Monitor menu.

- ☐ Check and cancel fax jobs that are ongoing or waiting to be sent.
- ☐ Send or delete a scanned document using the Store Fax Data function.
- ☐ Delete a scanned document for polling services.
- ☐ Resend or delete faxes that failed to be sent if you have enabled the Save Failure Data option.
- ☐ Check if there are received faxes that have been temporarily saved in the printer's memory and not yet saved to an external memory device or computer.

Follow the steps below to access the menu.

- 1** Press **i** on the control panel.
- 2** Select **Job Monitor**, and then select **Communication Job List** or **Print Job**.
- 3** Select a target job from the list.
A detailed information screen is displayed showing the available actions.

Checking sent/received fax jobs

You can check the history of sent or received fax jobs. You can also reprint received faxes. When the limit is reached, the oldest history entry is deleted first. Follow the steps below to access the menu.

- 1** Press **i** on the control panel.
- 2** Select **Job History**, and then select **Receive Job List** or **Send Job List**.
- 3** Select a target job from the list.
A detailed information screen is displayed showing the available actions.

Checking received faxes in the Inbox

You can view received faxes saved in the product's memory (**Inbox**). Press **i** on the control panel, select **Job Storage**, and then select **Inbox**.

You can also access the Inbox from the Fax mode.

➔ [“Checking the received faxes on the LCD screen” on page 96](#)

Printing a fax report

Printing a fax log automatically

You can set to print fax log report automatically.

- 1** Enter **Setup** mode from the Home menu.
- 2** Select **System Administration**.
- 3** Select **Fax Settings**.
- 4** Select **Output Settings**.
- 5** Select **Fax Log Auto Print**.
- 6** Select one of the two options for automatic printing.
 - ☐ **Off**
The report is not printed automatically.
 - ☐ **On(Every 30)**
The report is automatically printed every time 30 sent/received fax jobs are completed.
 - ☐ **On(Time)**
You can specify when to print the report automatically.

Printing a fax report manually

You can print a variety of fax report when you want.

- 1** Enter **Fax** mode from the Home menu.
- 2** Press **Menu**, select **Fax Report**, and then select one of the following items you want to print.
 - ☐ **Fax Settings List**
Prints the current fax communication settings.
 - ☐ **Fax Log**
Displays or prints a history of sent and received fax jobs.
 - ☐ **Last Transmission**
Prints a report for the previous fax that was sent or received through polling.
 - ☐ **Stored Fax Documents**
Prints a list of the fax jobs currently stored in the product's memory.

Faxing

☐ **Protocol Trace**

Prints a detailed report for the previous fax that was sent or received.

Fax Mode Menu List

For more information on the Fax mode menu list, see the following section.

➔ [“Fax Mode” on page 111](#)

Making Contact List Settings

Creating a Contact

You can register frequently used fax numbers, email addresses, and network folders in the contact list. This function allows you to select destination(s) quickly when faxing and scanning.

Note for the WF-7610 Series/WF-7620 Series:

You can register destinations using an LDAP server. For details, see the online Administrator's Guide.

Note:

Before registering an email address to the contact list, make sure you have configured the email server settings.

➔ ["Email Server Settings" on page 143](#)

- 1 Open the contacts list from the Home menu, Scan mode, or Fax mode.

Note for the WF-3620 Series/WF-3640 Series:

You can access Contacts from Scan mode or Fax mode.

- 2 Press **Menu**.

- 3 Select **Add Entry**.

- 4 Select the function you want to use to register a contact.

Note:

This screen is displayed when you open the contact list from the Home menu.

- 5 Select the entry number that you want to register.

Note:

You can register the following number of entries including individual entries and group entries.

WF-7610 Series/WF-7620 Series: Up to 200 entries

WF-3620/WF-3640 Series: Up to 100 entries

- 6 Enter a name to identify the entry in Name. You can enter up to 30 characters.

- 7 Enter a word to identify the entry in Index Word. You can enter up to 30 characters. This index word can be useful when searching for an entry from the contact list.

Making Contact List Settings

- 8** Enter the other settings according to the function you selected.

Note for fax numbers:

- ☐ You must enter a fax number. You can enter up to 64 digits.
- ☐ If your phone system is PBX and you need an external access code such as "9" to get an outside line, enter the access code at the beginning of the fax number. If the access code has been set in the Line Type setting, enter # (hash) instead of the actual access code.
- ☐ To pause the product for a few seconds when dialing, enter a hyphen.

- 9** Press **Save** to finish registering.

Note:

To edit or delete an entry, press the information icon on the right of the target entry, and then press **Edit** or **Delete**.

Note for the WF-7610 Series/WF-7620 Series:

You can register an address that is registered in the LDAP server in the local contacts list of the product. Display an entry, and then press **Save**.

Creating a Group

By adding contacts to a group list, you can send a fax or a scanned image by email to multiple destinations at the same time.

- 1** Open the contacts list from the Home menu, Scan mode, or Fax mode.

Note for the WF-3620 Series/WF-3640 Series:

You can access Contacts from Scan mode or Fax mode.

- 2** Press **Menu**.

- 3** Select **Add Group**.

- 4** Select the function you want to use to register the group entry.

Note:

This screen is displayed when you open the contact list from the Home menu.

Making Contact List Settings

- 5** Select the entry number that you want to register.

Note:

You can register the following number of entries including individual entries and group entries.

WF-7610 Series/WF-7620 Series: Up to 200 entries

WF-3620/WF-3640 Series: Up to 100 entries

- 6** Enter a name to identify the group entry in Name. You can enter up to 30 characters.

- 7** Enter a word to identify the entry in Index Word. You can enter up to 30 characters. This index word can be useful when searching for an entry from the contact list.

- 8** Press **Proceed**.

- 9** Select an entry that you want to register in the group list.

- 10** Press **Save** to finish registering.

Note:

*To delete or edit an existing entry, press the name section of the target entry on the contact list screen, and then select **Delete** or **Edit**.*

Menu List of Control Panel

You can use this product as a printer, copier, scanner, and fax. When using one of these functions, except the printer function, select your desired function by pressing the corresponding Mode button on the control panel. Each mode's main screen appears as you select the mode.

Copy Mode

Note:

- ❑ *Setting items vary depending on the Layout or other settings you selected.*
- ❑ *The menu hierarchy may vary depending on the product.*

Menu	Settings and Description	
Layout	With Border	Copies a document with a border.
	Borderless	Copies a document without a border. Your image is slightly enlarged and cropped to fill the sheet of paper. Print quality may decline in the top and bottom areas of the printout, or the area may be smeared when printing.
	2-up	Copies multiple page documents onto one sheet. After selecting either one of the options, press Settings and select an appropriate setting in Document Orientation and Layout Order.
	4-up	
	ID Card	Copies both sides of an ID card at the same time.
	Split Pages*	Copies two facing pages of a book on separate sheets of paper. After selecting this function, press Settings , and then select an appropriate setting in Scan Order.
Document Size	Select the document size to be copied.	
Zoom	Select the amount of enlargement or reduction.	
Paper Source	Select the paper source that you want to use. When you select Auto, paper is fed automatically according to the paper settings that are required each time you load paper in the paper cassette.	
2-Sided	Select double-sided layout. When you select 1>2-Sided or 2>1-Sided, press Advanced and select the binding edge.	
Document Orientation	Select the document orientation.	
Quality	Select the document type.	
Density	Set the density.	
Expansion	Select the amount of expansion when Borderless is selected as the Layout setting.	
Remove Shadow	Select On to erase the shadows that appear in the center of a document when copying a book or that appear around a document when copying thick paper.	
Remove Punch Holes	Select On to erase the binding holes on a document.	
Collate Copy	Select On to print multiple copies of multi-page document in order and sort them into sets.	

Menu List of Control Panel

Menu	Settings and Description
Dry Time	Select the drying time when copying on both sides of paper.

* This function is only supported by the WF-7610 Series/WF-7620 Series.

Memory Device Mode

Note:

Setting item may varies depending on the print format.

Format

Menu	Settings and Description
JPEG	Select the file format.
TIFF	

Advanced Settings

Menu	Settings and Description	
Settings	Paper Source	Select the paper source that you want to use.
	Borderless	Select whether to print an image with or without a border (Borderless). When you select Borderless or On, your image is slightly enlarged and cropped to fill the sheet of paper. Print quality may decline in the top and bottom areas of the printout, or the area may be smeared when printing.
	Layout	
	Quality	Select the print quality.
	Expansion	Select the amount of expansion when you selected Borderless layout.
	Date	Select the format of the date on the prints.
	Fit Frame	Select On to fit the image to the paper size.
	Bidirectional	Select On to perform bidirectional printing.
	Print Order	Select Last Page on Top to print from the last page of a document. Select First Page on Top to print from the first page of a document.
Image Adjustments	Fix Photo	Select the image fixing method.
	Fix Red-Eye*	Select On to fix a red-eye photo automatically.
Options	Select Images	Select this to select all photos on the external memory device.
	Select Group	Select this to select another group on the external memory device.

* This setting does not change your original image. It only affects your printout. Depending on the type of photo, parts of the image other than the eyes may be corrected.

Menu List of Control Panel

Fax Mode

Menu	Settings and Options		
Menu	Fax Send Settings	Resolution	Select the resolution of the outgoing fax. Select Photo for documents that contains a lot of images.
		Density	Select the density of the outgoing fax. When sending text-based monochrome documents, select Auto .
		Document Size (Glass)	Select the size and orientation of the document you placed on the scanner glass.
		ADF 2-Sided	Select On to scan both sides of the documents placed in the ADF. The Direct Send option and color faxing are disabled when this is set to On .
		Direct Send	Select On to let the product send a monochrome fax as soon as the connection is made without saving the scanned image in its memory. ➔ "Using handy fax features" on page 90
		Priority Send	Select On to send your fax before the other faxes waiting to be sent. ➔ "Using handy fax features" on page 90
		Continuous Scan from ADF	Select On to let the product ask you if you want to scan another page each time scanning the documents in the ADF is finished. ➔ "Using handy fax features" on page 90
		Transmission Report	Select whether or not to print a report each time after sending a fax is finished. By default, the product prints a report only when an error occurs.
	Send Fax Later	➔ "Sending a fax at a specified time" on page 91	
	Polling Receive	➔ "Receiving a fax by polling" on page 100	
	Polling Send	➔ "Sending a fax on demand (fax polling)" on page 92	
	Store Fax Data	➔ "Sending a stored fax" on page 92	
	Fax Report	➔ "Printing a fax report manually" on page 104	

Scan Mode

Note:

- ❑ Depending on the product, the Scan to Network Folder/FTP and Scan to Email functions may not be supported. See the following section for more details.
➔ ["Available Features" on page 8](#)
- ❑ Setting item may varies depending on the menu.

Menu List of Control Panel

Scan to Memory Device

Menu	Settings and Description
Format	Select the file format for the scanned image. When you select TIFF (Multi Page), the image is scanned in monochrome.
Settings	See the Scan to Email menu list.

Scan to Network Folder/FTP

Menu	Settings and Description	
Location	Communication Mode	Select the communication mode.
	Location	Specify the folder path for saving the scanned data.
	User Name	Enter a user name for the specified folder.
	Password	Enter a password for the specified folder.
	Connection Mode	Select the connection mode.
	Port Number	Enter a port number.
Format	Select the file format for the scanned image. When you select TIFF (Multi Page), the image is scanned in monochrome.	
Menu	File Settings	Enter the prefix for the file name in Filename Prefix.
	Basic Settings	See the Scan to Email menu list.
	Scan Report	Prints up to 30 reports of folder logs that contain the scanning date, location, and scanning result.

Scan to Email

Menu	Settings and Description
Format	Select the file format for the scanned image. When you select TIFF (Single Page) or TIFF (Multi Page), the image is scanned in monochrome.

Menu List of Control Panel

Menu	Settings and Description		
Menu	Email Settings	Subject	Enter the subject for the email to which you want to attach the scanned file.
		Filename Prefix	Enter the prefix for the file name.
	Basic Settings	Resolution	Select the scanning resolution.
		Scan Area	Select the scan area.
		2-Sided	Select On when you want to scan a double-sided document.
		Document Type	Select the document type.
		Density	Select the density.
		Document Orientation	Select the document orientation.
		Compression Ratio	Select the compression ratio of scanned data.
		PDF Settings	Make settings for password protected PDFs. Document Open Password creates a PDF that requires a password to open. Permissions Password creates a PDF that requires a password when printing or editing the PDF.
		Attached File Max Size	Select the maximum size of the attached file. Select a larger size if you often send large files.
	Scan Report	Prints up to 250 reports of email logs that contain the scanning date, address, and scanning result.	

Scan to Computer

Menu	Settings and Description
Format	Select the file format for the scanned image. Select Email to attach the scanned data to an email on the computer.
2-Sided	Select On when you want to scan a double-sided document.
Scan Area*	Select the scan area.

* This function is only supported by the WF-7610 Series/WF-7620 Series.

Scan to Computer (WSD)

Available for computers running Windows 8/7/Vista.

Scan to Cloud

For instructions on using Scan to Cloud, visit the Epson Connect portal site.

➡ [“Using Epson Connect Service” on page 10](#)

Menu List of Control Panel

Setup Mode

Menu	Settings and Description		
Ink Levels	Checks the status of ink cartridges and the maintenance box.		
Maintenance	Print Head Nozzle Check	Prints a pattern to check if the print head nozzles are clogged.	
	Print Head Cleaning	Cleans the print head to clear clogged nozzles.	
	Ink Cartridge(s) Replacement	Starts the ink cartridge replacement procedure.	
	Print Head Alignment	Vertical Alignment	Corrects vertical gaps in a printout.
		Horizontal Alignment	Corrects horizontal gaps in a printout.
	Thick Paper	Select On when printing on thick paper to avoid smearing.	
	Paper Guide Cleaning	Perform this function to clean the inside of the product.	
Remove Paper*	Perform this function if there are still some torn pieces of paper inside the product even after clearing the paper jam.		
Paper Setup	Select the paper size and paper type you loaded in each paper source. This menu is displayed each time you load paper in the paper cassette.		
Print Status Sheet	Configuration Status Sheet	Prints a sheet showing the current printer settings.	
	Supply Status Sheet	Prints a sheet showing information about consumables.	
	Usage History Sheet	Prints a sheet showing the history of the printer’s usage.	
Network Status	Wi-Fi/Network Status	You can see the current network settings and print a network status sheet.	
	Wi-Fi Direct Status		
	Email Server Status	You can see the current email server settings.	
	Epson Connect Status	You can check whether your printer is registered or connected to Epson Connect or Google Cloud Print service. ➡ “Using Epson Connect Service” on page 10	
	Google Cloud Print Status		
Admin Settings	Admin Password	You can register, change or reset the password to lock the control panel to prevent unintended changes made by using the control panel.	
	Lock Setting	Select On to lock the control panel using the password registered in Admin Password.	
System Administration	➡ “System Administration Settings” on page 115		

* This function is only supported by the WF-7610 Series/WF-7620 Series.

Menu List of Control Panel

System Administration Settings

The administrator can lock the control panel to prevent unintended changes from being made. To lock the control panel, select the menus shown as below, then enter the password.

Setup > Admin Settings > Lock Setting

The password is required when using the following functions.

- ☐ Entering the System Administration settings in Setup mode
- ☐ Entering the Eco Mode from the Home menu.
- ☐ Adding, deleting, and editing the Preset settings and the contact list

The password set in Lock Setting is also necessary when making settings in Epson WebConfig or EpsonNet Config.

Note:

If you forget your password, contact your dealer.

Menu	Settings and Description			
Printer Settings	Paper Source Settings	A4/Letter Auto Switching		Make the paper settings for A4 and Letter. When A4 or Letter size paper is selected for printing and there is no paper source set for the selected paper size, the printout is output using an alternate paper size (Letter for A4, or A4 for Letter).
		Auto Select Settings		Select On to feed from the paper source containing paper that matches your paper settings. (Only for products with two paper cassettes.)
		Error Notice	Paper Size Notice	Select On to display an error message when the paper size and type settings made for each cassette and the copy/print settings made in each mode do not match.
			Paper Type Notice	
	Auto Error Solver	Select On to automatically clear product errors.		
	Memory Device Interface	Memory Device	Select Disable to disable a memory device. If Disable is selected, the product does not recognize the inserted memory device.	
		File Sharing	Select which type of computer you want to give write access to the memory device. You can select a USB-connected or a network-connected computer.	
	PC Connection via USB	Select whether to enable or disable the USB interface. If Disable is selected, the computer does not recognize the product even if it is connected using a USB cable.		

Menu List of Control Panel

Menu	Settings and Description	
Common Settings	LCD Brightness	Adjusts the brightness of the LCD panel.
	Sound	Adjust the sound settings.
	Sleep Timer	Specify the length of the time until the LCD panel turns black.
	Power Off Settings	Your product may have this feature or the Power Off Timer feature depending on the production date and the location of purchase.
		Power Off If Inactive You can adjust the time before power management is applied. Any increase will affect the product's energy efficiency. Please consider the environment before making any change.
		Power Off If Disconnected Turns the printer off after 30 minutes when all network ports including the LINE port are disconnected.
	Power Off Timer	Specify the length of the time until the power turns off automatically. You can adjust the time before power management is applied. Any increase will affect the product's energy efficiency. Please consider the environment before making any change.
	Date/Time Settings	Date/Time Enter the current date and time.
		Daylight Saving Time Select On to set summer time.
		Time Difference Enter the time difference between UTC and the current time zone.
	Country/Region	Select the current country/region.
	Language	Select the display language.
	Operation Time Out	Select On to return to the Home menu after three minutes of inactivity.

Menu List of Control Panel

Menu	Settings and Description		
Wi-Fi/Network Settings	Wi-Fi/Network Status		You can see the current network settings and print a networks status sheet.
	Wi-Fi Setup	Wi-Fi Setup Wizard	For details on the setting items, see the online Network Guide.
		Push Button Setup (WPS)	
		PIN Code Setup (WPS)	
		Wi-Fi Auto Connect	
		Disable Wi-Fi	Network problems may be resolved by disabling or initializing the Wi-Fi settings, and then making the settings again. For details, see the online Network Guide.
		Wi-Fi Direct Setup	For details on the setting items, see the online Network Guide.
	Connection Check		You can check the network connection status, and print the report. If there is any problem with the connection, the report helps you find the solution.
	Advanced Setup		For details on the setting items, see the online Network Guide.
Epson Connect Services	For instructions on use, see the Epson Connect guide. ➔ "Using Epson Connect Service" on page 10		
Google Cloud Print Services			
Copy Settings	Make the User Default Settings. The settings made in this menu are displayed as the default settings in each mode. For details on the settings items, see the menu list for each mode. ➔ "Copy Mode" on page 109 ➔ "Scan Mode" on page 111		
Scan Settings			
Fax Settings	User Default Settings	You can change the default settings for sending a fax. For more information on the menus, see the following section. ➔ "Fax Mode" on page 111	
	Send Settings	Auto Rotation *	Select On to rotate scanned documents 90 degrees when an A4 or Letter size document has been loaded long edge first into the ADF so that the document is sent at A4 or Letter size. If this option is disabled, the document is sent at A3 size. If the recipient's fax machine does not support A3 size, the document is automatically reduced in size. This setting is not applied to color faxes and monochrome faxes sent using the Direct Send function.
		Batch Send	Select On to sort faxes waiting to be sent in the memory by recipient, and then send them as a batch. ➔ "Using handy fax features" on page 90
		Save Failure Data	Select On to save faxes that failed to be sent in the product's memory. You can resend the faxes from Status Menu. ➔ "Using the status menu" on page 103

Menu List of Control Panel

Menu	Settings and Description		
	Receive Settings	Receive Mode	➡ "Setting up the receive mode" on page 94
		DRD	See Step 7 in the following section. ➡ "Using the Fax Setting Wizard" on page 84
		Rings to Answer	➡ "Setting the number of rings to answer" on page 86
		Remote Receive	See the Note in the following section. ➡ "Receiving a fax manually" on page 101
	Output Settings	Fax Output	➡ "Saving and Forwarding Received Faxes" on page 95
		Auto Reduction	Select whether large received faxes are reduced in size to fit on the paper size in the selected paper cassette, or printed at their original size on multiple sheets.
		Auto Rotation	Select On to rotate a landscape-oriented incoming fax (A5, B5, or A4 size) so that it is printed on the correct paper size if you have loaded the following paper sizes in the paper cassettes. For products with one cassette: A5 For products with two cassettes: A4 and A5, B4 and B5*, or A3 and A4* *These combinations are only available for the WF-7620 Series.
		Collation Stack	Select On to print received faxes from the last page (print in descending order) so that the printed documents are stacked in the correct page order. When the product is running low on memory, this option may not be available.
		Print Suspend Time	Select a time period to stop automatic printing of faxes or reports during that time. Received faxes are saved in the product's memory. Make sure there is enough free memory before using this function.
		Forwarding Report	Select whether to print a report each time after a received fax is forwarded. By default, the product only prints a report when an error occurs.
		Attach Image to Report	Select On(Large Image) or On(Small Image) to print the Transmission Report with an image of the first page of the document. Images of color faxes or monochrome faxes sent using the Direct Send option are not printed.
		Fax Log Auto Print	➡ "Printing a fax log automatically" on page 104
		Report Format	Select a format for fax reports other than Protocol Trace. Select Detail to print with error codes.

Menu List of Control Panel

Menu	Settings and Description		
	Basic Settings	Fax Speed	Indicates the speed at which you transmit and receive faxes.
		ECM	Indicates whether or not to use Error Correction Mode to automatically correct fax data sent/received with errors due to the line or any other problems. Color faxes cannot be sent/received when ECM is off.
		Dial Tone Detection	When this is set to On , the product starts dialing after it detects a dial tone. It may not be able to detect a dial tone when a PBX (Private Branch Exchange) or a TA (Terminal Adapter) is connected. In such case, first change the Line Type setting to PBX . If it does not work, set this option to Off . However, doing so may drop the first digit of a fax number and send the fax to the wrong number.
		Dial Mode	Indicates the type of phone system to which you have connected the product. Depending on the region, this setting may not be displayed. When this is set to Pulse, you can temporarily switch the dialing mode from pulse to tone by pressing * ("T" is entered) while entering a number on the Fax top screen.
		Line Type	➔ "Setting the line type" on page 85
		Header	See Step 5 and 6 of the following section. ➔ "Using the Fax Setting Wizard" on page 84
	Security Settings	Direct Dialing Restrictions	Select On to disable the manual entry of recipient's fax numbers allowing the operator to select recipients only from the Contacts List or sent history. Select Enter Twice to require the operator to enter the fax number twice to prevent a mistake.
		Confirm Address List	Select On to display a recipient confirmation screen before the transmission is started.
		Inbox Password Settings	Select to password protect the Inbox to restrict users from viewing received faxes. To change the password, select Change . To delete the password and cancel password protection, select Reset .
		Backup Data Auto Clear	Select On to automatically erase sent or received faxes that are stored in the product's non-volatile memory.
		Clear Backup Data	Completely erases sent or received faxes that are stored in the product's non-volatile memory. If you give the product to someone else or dispose of it, run this function in advance.
	Check Fax Connection		Checks the status of your fax connection. See Step 11 in the following section. ➔ "Using the Fax Setting Wizard" on page 84
	Fax Setting Wizard		➔ "Using the Fax Setting Wizard" on page 84

Menu List of Control Panel

Menu	Settings and Description		
Universal Print Settings	These settings are available when printing data without the printer driver.		
	Top Offset	Adjusts the top or left margin.	
	Left Offset		
	Top Offset in Back	Adjusts the top or left margin for the back of the page when performing double-sided printing.	
	Left Offset in Back		
	Check Paper Width	Select On to check the paper width before printing. This prevents printing beyond the edges of the paper when the paper size settings are wrong, but may reduce the printing speed.	
	Dry Time	Select the drying time when performing double-sided printing.	
	Skip Blank Page	Select On to skip blank pages automatically.	
Eco Mode	On	You can adjust the time before power management is applied. Any increase will affect the product's energy efficiency. Please consider the environment before making any change. Select On to enable all of the following Eco Mode functions.	
	Off		
	Configure	Sleep Timer	Specify the length of the time until the LCD panel turns black.
		LCD Brightness	Adjusts the brightness of the LCD panel.
		2-Sided (Copy)	Select On to make double-sided copying the default setting.
Restore Default Settings	Resets the selected settings to their defaults.		

* This function is only supported by the WF-7610 Series/WF-7620 Series.

Contacts

➔ [“Making Contact List Settings” on page 106](#)

Presets

You can save frequently used copy, scan, and fax settings as a preset. Destination information selected from the contact list, such as email addresses, network folders, and fax numbers, is also included in the preset.

Follow the steps below to create a preset.

Press **Presets** on the Home screen (for the WF-3620 Series, press ★), select **Add New**, and then select a function. The top screen of the selected function is displayed. Make your preferred settings, and then press **Save** (for the WF-3620 Series, press ★). Enter a name to identify the preset, and then press **Save**.

Menu List of Control Panel

Note:

*You can also create presets in each function mode by pressing **Preset** on the top screen of the selected function (for the WF-3620 Series, press ★).*

To call up the preset, press **Presets** on the Home screen (for the WF-3620 Series, press ★), and then select the preset you want to use from the preset list.


Status Menu

➔ [“Status Menu” on page 25](#)

Ink Cartridge and Consumable Information

Ink Cartridges

You can use the following ink cartridges with this product:

Product	Icon	Black	Cyan	Magenta	Yellow
WF-7610 WF-7620 WF-3620 WF-3640	Alarm Clock 	27 27XL 27XXL	27 27XL	27 27XL	27 27XL

* For users in Europe, visit the following website for information on Epson's ink cartridge yields.

<http://www.epson.eu/pageyield>

Product	Black	Cyan	Magenta	Yellow
For Australia/New Zealand WF-7610 WF-7620	252 252XL 254XL	252 252XL	252 252XL	252 252XL
For Australia/New Zealand WF-3620 WF-3640	252 252XL	252 252XL	252 252XL	252 252XL
WF-7611 WF-7621 WF-3621	188	188	188	188

Note:

Not all cartridges are available in all regions.

Color	Black, Cyan, Magenta, Yellow
Cartridge life	For best results, use up ink cartridge within six months of opening the package.
Temperature	Storage: -20 to 40 °C (-4 to 104 °F) 1 month at 40 °C (104 °F) Freezing: * -12 °C (10.4 °F)

* Ink thaws and is usable after approximately 3 hours at 25 °C (77 °F).

Maintenance Box

You can use the following maintenance box with this product.

Ink Cartridge and Consumable Information

	Part number
Maintenance Box	T6711

Replacing Ink Cartridges

Ink Cartridge Safety Instructions, Precautions, and Specifications


Safety instructions

Observe the following when handling the ink cartridges:

- ☐ Keep ink cartridges out of the reach of children.
- ☐ Be careful when you handle used ink cartridges, as there may be some ink around the ink supply port.
If ink gets on your skin, wash the area thoroughly with soap and water.
If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems continue after a thorough flushing, see a doctor immediately.
If ink gets into your mouth, spit it out immediately and see a doctor right away.
- ☐ Do not remove or tear the label on the cartridge; this can cause leakage.




- ☐ Do not remove the transparent seal from the bottom of the cartridge; otherwise, the cartridge may become unusable.



- ☐ Do not disassemble or remodel the ink cartridge, otherwise you may not be able to print normally.

Replacing Ink Cartridges

- ❑ Do not touch the green chip or the small window on the side of the cartridge. Doing so may prevent normal operation and printing.



- ❑ Do not leave the product with the ink cartridges removed or do not turn off the product during cartridge replacement. Otherwise, ink remaining in the print head nozzles will dry out and you may not be able to print.

Precautions on ink cartridge replacement

Read all of the instructions in this section before replacing the ink cartridges.

- ❑ Epson recommends the use of genuine Epson ink cartridges. Epson cannot guarantee the quality or reliability of non-genuine ink. The use of non-genuine ink may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic product behavior. Information about non-genuine ink levels may not be displayed.
- ❑ Gently shake all ink cartridges four or five times before opening the package.
- ❑ Do not shake ink cartridges too vigorously; otherwise ink may leak from the cartridge.
- ❑ This product uses ink cartridges equipped with an IC chip that monitors information such as the amount of remaining ink for each cartridge. This means that even if the cartridge is removed from the product before it is expended, you can still use the cartridge after reinserting it back into the product. However, when reinserting a cartridge, some ink may be consumed to guarantee product performance.
- ❑ To maintain optimum print head performance, some ink is consumed from some cartridges not only during printing but also during maintenance operations such as ink cartridge replacement and print head cleaning.
- ❑ If you need to remove an ink cartridge temporarily, be sure to protect the ink supply area from dirt and dust. Store the ink cartridge in the same environment as the product. When storing the cartridge, be sure that its label identifying the color of the ink cartridge is facing upward. Do not store ink cartridges upside down.
- ❑ The ink supply port is equipped with a valve designed to contain the release of excess ink; there is no need to supply your own covers or plugs. However, careful handling is recommended. Do not touch the supply port of the ink cartridge or its surrounding area.
- ❑ For maximum ink efficiency, only remove an ink cartridge when you are ready to replace it. Ink cartridges with low ink status may not be used when reinserted.
- ❑ Do not open the ink cartridge package until you are ready to install it in the product. The cartridge is vacuum packed to maintain its reliability. If you leave a cartridge unpacked for a long time before using it, normal printing may not be possible.
- ❑ Install all ink cartridges; otherwise, you cannot print.

Replacing Ink Cartridges

- ❑ When color ink is expended and black ink still remains, you can continue printing temporarily with black ink only. For more information refer to [“Temporary Printing with Black Ink When Color Ink Cartridges are Expended” on page 129](#).
- ❑ If an ink cartridge is running low, prepare a new ink cartridge.
- ❑ Be careful not to break the hooks on the side of the ink cartridge when you remove it from the package.
- ❑ You must remove the yellow tape from the cartridge before installing it; otherwise, print quality may decline or you may not be able to print.
- ❑ After bringing an ink cartridge inside from a cold storage site, allow it to warm up at room temperature for at least three hours before using it.
- ❑ Store ink cartridges in a cool, dark place.
- ❑ Store ink cartridges with their labels facing upward. Do not store cartridges upside down.
- ❑ You cannot use the cartridges that came with your product for the replacement.

Ink Cartridge Specifications

- ❑ Epson recommends using the ink cartridge before the date printed on the package.
- ❑ The ink cartridges packaged with your product are partly used during initial setup. In order to produce high quality printouts, the print head in your product will be fully charged with ink. This one-off process consumes a quantity of ink and therefore these cartridges may print fewer pages compared to subsequent ink cartridges.
- ❑ Quoted yields may vary depending on the images that you are printing, the paper type that you are using, the frequency of your prints and environmental conditions such as temperature.
- ❑ To ensure you receive premium print quality and to help protect your print head, a variable ink safety reserve remains in the cartridge when your product indicates to replace the cartridge. The yields quoted for you do not include this reserve.
- ❑ Although the ink cartridges may contain recycled materials, this does not affect product function or performance.
- ❑ When printing in monochrome or grayscale, color inks instead of black ink may be used depending on the paper type or print quality settings. This is because a mixture of color inks is used to create black.

Checking the Ink Cartridge Status

For Windows

Note:

When an ink cartridge is running low, the Low Ink Reminder screen automatically appears. You can also check the ink cartridge status from this screen. If you do not want to display this screen, first access the printer driver and then click the **Maintenance** tab, and then **Monitoring Preferences**. On the Monitoring Preferences screen, clear the **See Low Ink Reminder alerts** check box.

Replacing Ink Cartridges

To check the ink cartridge status, do one of the following:

- ☐ Open the printer driver, click the **Main** tab, and then click the **Ink Levels** button.
- ☐ Double-click the product shortcut icon on your Windows taskbar. To add a shortcut icon to the taskbar, see the following section:
➔ [“From the shortcut icon on the taskbar” on page 51](#)
- ☐ Open the printer driver, click the **Maintenance** tab, then click the **EPSON Status Monitor 3** button. A graphic displays the ink cartridge status.



Note:

- ☐ If EPSON Status Monitor 3 does not appear, access the printer driver and click the **Maintenance** tab and then the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.
- ☐ Depending on current settings, the simplified status monitor may be displayed. Click the **Details** button to display the window above.
- ☐ The ink levels displayed are an approximate indication.

For Mac OS X

You can check the ink cartridge status using EPSON Status Monitor. Follow the steps below.

- 1** Access the Epson Printer Utility 4.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)

Replacing Ink Cartridges

- 2 Click the **EPSON Status Monitor** icon. The EPSON Status Monitor appears.



Note:

- ☐ The graphic displays the ink cartridge status when EPSON Status Monitor was first opened. To update the ink cartridge status, click **Update**.
- ☐ The ink levels displayed are an approximate indication.

Using the control panel

- 1 Press **i** on the control panel.
- 2 Select **Printer Information**.

Note:

- ☐ The ink levels displayed are an approximate indication.
- ☐ The status icon on the right of the LCD screen indicates the status of the maintenance box.

Temporary Printing with Black Ink When Color Ink Cartridges are Expended

When color ink is expended and black ink still remains, you can continue printing for a short time using only black ink. However, you should replace the expended ink cartridge(s) as soon as possible. See the following section to continue printing temporarily with black ink.

Note:

The actual amount of time will vary depending on the usage conditions, images printed, print settings, and frequency of use.

For Windows



Note for Windows:

*This function is available only when EPSON Status Monitor 3 is enabled. To enable the status monitor, access the printer driver and click the **Maintenance** tab followed by the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.*

Follow the steps below to continue printing temporarily with black ink.

Replacing Ink Cartridges

- 1 When EPSON Status Monitor 3 tells you to cancel your print job, click **Cancel** or **Cancel Print** to cancel your print job.



Note:

If the error stating that a color ink cartridge is expended originates with another computer on the network, you may need to cancel the print job at the product.

- 2 Load plain paper or envelope.
- 3 Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 4 Click the Main tab, and make suitable settings.
- 5 Select **plain papers** or **Envelope** as the Paper Type setting.
- 6 Select the **Grayscale** as the Color setting.
- 7 Click **OK** to close the printer settings window.


Replacing Ink Cartridges

- 8 Print your file.
- 9 EPSON Status Monitor 3 is displayed on your computer screen again. Click **Print in Black** to print with black ink.

For Mac OS X

Follow the steps below to continue printing temporarily with black ink.

- 1 If printing can not be resumed, click the product icon in the Dock. If an error message is displayed prompting you to cancel the print job, click **Delete** and follow the steps below to reprint the document with black ink.




Note:

If the error stating that a color ink cartridge is expended originates with another computer on the network, you may need to cancel the print job at the product.

For Mac OS X 10.8:

Click the button, and if an error message appears, click **OK**. Follow the steps below to reprint the document with black ink.



Replacing Ink Cartridges

- 2 Open **System Preferences**, click **Print & Scan** (Mac OS X 10.8 or 10.7) or **Print & Fax** (Mac OS X 10.6 or 10.5), and select the product from the Printers list. Next, click **Options & Supplies** and then **Driver**.
- 3 Select **On** for Permit temporary black printing.
- 4 Load plain paper or envelope.
- 5 Access the Print dialog box.
➡ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 6 Click the **Show Details** button (for Mac OS X 10.7) or the ▼ button (for Mac OS X 10.6 or 10.5) to extend this dialog box.
- 7 Select the product you are using as the Printer setting, and then make suitable settings.
- 8 Select **Print Settings** from the pop-up menu.
- 9 Select **plain papers** or **Envelope** as the Media Type setting.
- 10 Select the **Grayscale** check box.
- 11 Click **Print** to close the Print dialog box.


Conserving Black Ink When the Cartridge Is Low (For Windows Only)

Note for Windows:

*This function is available only when EPSON Status Monitor 3 is enabled. To enable the status monitor, access the printer driver and click the **Maintenance** tab followed by the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.*

Replacing Ink Cartridges

The window below appears when black ink runs low and there is more color ink than black ink. It appears only when **plain papers** is selected as the paper type, and **Standard** is selected as the Quality.



The window gives you the option to either continue using black ink normally or conserve black ink by using a mixture of color inks to create black.


- ☐ Click the **Yes** button to use a mixture of color inks to create black. You will see the same window the next time you print a similar job.
- ☐ Click the **No** button to continue using the remaining black ink for the job you are printing. You will see the same window the next time you print a similar job, and again have the option to conserve black ink.
- ☐ Click **Disable this feature** to continue using the remaining black ink.

Replacing an ink cartridge

- 1** Open the scanner unit.

The ink cartridge holder moves to the ink cartridge replacement position. When you replace an ink cartridge before it is expended, select the menu as shown below.

Setup > Maintenance > Ink Cartridge(s) Replacement




Replacing Ink Cartridges

! Important:


- ❑ Do not move the ink cartridge holder by hand; otherwise, you may damage the product.
- ❑ Do not lift up the scanner unit when the document cover is open.



- 2** Open the ink cartridge cover.



- 3** Pinch and remove the ink cartridge.




Note:

- ❑ The illustration shows replacement of the black ink cartridge. Replace the cartridge appropriate to your situation.
- ❑ Removed ink cartridges may have ink around the ink supply port, so be careful not to get any ink on the surrounding area when removing the cartridges.


Replacing Ink Cartridges

- 4** Gently shake new replacement cartridges four or five times and remove the replacement ink cartridge from its package.




Note:

- ❑ Be careful not to break the hooks on the side of the ink cartridge when you remove it from the package.
- ❑ Do not touch the green chip or the small window on the side of the cartridge. Doing so may prevent normal operation and printing.



- 5** Remove only the yellow tape.




Replacing Ink Cartridges

**Important:**


- ☐ You must remove the yellow tape from the cartridge before installing it; otherwise, print quality may decline or you may not be able to print.
- ☐ If you have installed an ink cartridge without removing the yellow tape, take the cartridge out of the product, remove the yellow tape, and then reinstall it.
- ☐ Do not remove the transparent seal from the bottom of the cartridge; otherwise, the cartridge may become unusable.
- ☐ Do not remove or tear the label on the cartridge; otherwise, ink will leak.

6

Insert the cartridge and press it until it clicks.

**7**

Close the ink cartridge cover.



Press **Check** on the control panel of the product to check if the cartridges are installed correctly.

8

Close the scanner unit slowly. Ink charging starts.

Note:

- ☐ The power light continues to flash while the product is charging ink. Do not turn off the product during ink charging. If the ink charging is incomplete, you may not be able to print.
- ☐ If you had to replace an ink cartridge during copying, to ensure copy quality after ink charging is finished, cancel the job that is copying and start again from placing the originals.

Ink cartridge replacement is complete. The product will return to its previous status.

Maintaining Your Product and Software

Checking the Print Head Nozzles

If you find that the printout is unexpectedly faint or that dots are missing, you may be able to identify the problem by checking the print head nozzles.

You can check the print head nozzles from your computer by using the Nozzle Check utility or from the product by using the buttons.

Using the Nozzle Check utility for Windows

Follow the steps below to use the Nozzle Check utility.

- 1** Make sure that no warnings or errors are indicated in the control panel.
- 2** Make sure that A4-size paper is loaded in the paper cassette.
- 3** Right-click the product icon on the taskbar, then select **Nozzle Check**.
If the product icon does not appear, refer to the following section to add the icon.
➔ [“From the shortcut icon on the taskbar” on page 51](#)
- 4** Follow the on-screen instructions.

Using the Nozzle Check utility for Mac OS X

Follow the steps below to use the Nozzle Check utility.


- 1** Make sure that no warnings or errors are indicated in the control panel.
- 2** Make sure that A4-size paper is loaded in the paper cassette.
- 3** Access the Epson Printer Utility 4.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 4** Click the **Nozzle Check** icon.
- 5** Follow the on-screen instructions.

Using the control panel


Follow the steps below to check the print head nozzles using the product control panel.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the paper cassette.
- 3 Enter **Setup** mode from the Home menu.
- 4 Select **Maintenance**.
- 5 Select **Print Head Nozzle Check**, and then follow the instructions on the LCD screen to print a nozzle check pattern.
- 6 Below are two sample nozzle check patterns.

Compare the quality of the printed check page with the sample shown below. If there are no print quality problems, such as gaps or missing segments in the test lines, the print head is fine.



If any segment of the printed lines is missing, as shown below, this could mean a clogged ink nozzle or a misaligned print head.



- ➔ [“Cleaning the Print Head” on page 138](#)
- ➔ [“Aligning the Print Head” on page 140](#)

Cleaning the Print Head

If you find that the printout is unexpectedly faint or that dots are missing, you may be able to solve these problems by cleaning the print head, which ensures that the nozzles are delivering ink properly.

You can clean the print head from your computer using the Head Cleaning utility in the printer driver or from the product by using the buttons.

Maintaining Your Product and Software

**Important:**

Do not turn off the product during head cleaning. If the head cleaning is incomplete, you may not be able to print.

Note:

- ☐ Do not open the scanner unit during head cleaning.
- ☐ Perform the nozzle check first to identify any defective color(s); this will allow you to select the appropriate color(s) for the head cleaning function. Black ink may be used when printing color images.
 - ➔ [“Checking the Print Head Nozzles” on page 137](#)
- ☐ Because print head cleaning uses some ink from some cartridges, clean the print head only if quality declines; for example, if the printout is blurry or the color is incorrect or missing.
- ☐ When ink is low, you may not be able to clean the print head.
- ☐ If print quality does not improve, make sure you selected the appropriate color according to the nozzle check result.
- ☐ If print quality has not improved after repeating this procedure about four times, leave the product on and wait for at least six hours. Then run the nozzle check again and repeat the head cleaning if necessary. If print quality has still not improved, contact Epson support.
- ☐ To maintain print quality, we recommend printing a few pages on a regular basis.

Using the Head Cleaning utility for Windows

Follow the steps below to clean the print head using the Head Cleaning utility.

- 1** Make sure that no warnings or errors are indicated in the control panel.
- 2** Right-click the product icon on the taskbar, then select **Head Cleaning**.
If the product icon does not appear, refer to the following section to add the icon.
 - ➔ [“From the shortcut icon on the taskbar” on page 51](#)
- 3** Follow the on-screen instructions.

Using the Head Cleaning utility for Mac OS X

Follow the steps below to clean the print head using the Head Cleaning utility.

- 1** Make sure that no warnings or errors are indicated in the control panel.
- 2** Access the Epson Printer Utility 4.
 - ➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 3** Click the **Head Cleaning** icon.
- 4** Follow the on-screen instructions.

Using the control panel

Follow the steps below to clean the print head using the product control panel.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Enter **Setup** mode from the Home menu.
- 3 Select **Maintenance**.
- 4 Select **Print Head Cleaning**.
- 5 Follow the instructions on the LCD screen to continue.
- 6 Select the color you want to clean, and follow the instructions on the LCD screen to start cleaning.

Note:

Select the color that shows a defect in the nozzle check result.

Aligning the Print Head

If you notice a misalignment of vertical lines or horizontal banding, you may be able to solve this problem by using the Print Head Alignment utility in your printer driver or by using the product buttons.

Refer to the appropriate section below.

Note:

Do not cancel printing while printing a test pattern with the Print Head Alignment utility.

Using the Print Head Alignment utility for Windows

Follow the steps below to align the print head using the Print Head Alignment utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure A4-size paper is loaded in the paper cassette 1.
- 3 Right-click the product icon on the taskbar, then select **Print Head Alignment**.
If the product icon does not appear, refer to the following section to add the icon.
➔ [“From the shortcut icon on the taskbar” on page 51](#)

Maintaining Your Product and Software

- 4 Follow the on-screen instructions to align the print head.

Using the Print Head Alignment utility for Mac OS X

Follow the steps below to align the print head using the Print Head Alignment utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure A4-size paper is loaded in the paper cassette 1.
- 3 Access the Epson Printer Utility 4.
➔ [“Accessing the printer driver for Mac OS X” on page 51](#)
- 4 Click the **Print Head Alignment** icon.
- 5 Follow the on-screen instructions to align the print head.

Using the control panel

Follow the steps below to align the print head using the product control panel.


- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the paper cassette 1.
- 3 Enter **Setup** mode from the Home menu.
- 4 Select **Maintenance**.
- 5 Select **Print Head Alignment**.
- 6 Select **Vertical Alignment** or **Horizontal Alignment**, and then follow the on-screen instructions to print an alignment pattern.

Note:

If your printouts look blurry or vertical ruled lines appear misaligned, select Vertical Alignment. If you see horizontal banding at regular intervals, select Horizontal Alignment.

Maintaining Your Product and Software

- 7** When you selected Vertical Alignment, find the most solid pattern in each of #1 to #6 groups, then enter the pattern number.



When you selected Horizontal Alignment, find the least separated and overlapped pattern.



- 8** Finish aligning the print head.

Making Network Service Settings

Web Config

You can make network service settings such as Epson Connect, AirPrint, or Google Cloud Print using a Web browser on your computer, smartphone, tablet PC, or laptop that is connected to the same network as the product.

Enter the product's IP address in the address bar of the Web browser and search for the product.

<Example>

[IPv4] <http://192.168.11.46>

[IPv6] [http://\[fe80::226:abff:feff:37cd\]/](http://[fe80::226:abff:feff:37cd]/)

Note:

You can check your product's IP address on the product's control panel or by printing a network status sheet.

Setup > System Administration > Wi-Fi/Network Settings > Wi-Fi/Network Status

When the product is found successfully, the product's web page is displayed. Select the menu you want.

The web page also allows you to check the product's status and update the product's firmware.

Email Server Settings

To use email features, such as scan or fax forwarding features, you need to configure the email server. Check the following before configuring the email server.

- ☐ The product is connected to the network.
- ☐ The email server information, such as the documents from your service provider that you used to setup the email on your computer.

Note:

If you use a free email service, such as Internet email, search the Internet to get the email server information you need.

- 1** Enter **Setup** mode from the Home menu.
- 2** Select **System Administration > Wi-Fi/Network Settings > Advanced Setup**.
- 3** Select **Email Server > Server Settings**.
- 4** Select the authentication method of the email server you are using.



Important:

The following authentication methods are available. SSL and STARTTLS are not supported.

- ☐ None
- ☐ SMTP (SMTP AUTH)
- ☐ POP Before SMTP

Contact your internet service provider to confirm the authentication method of the email server. The product may not be able to communicate with an email server even if the authentication method is available since security may be enhanced (for example SSL communication is necessary). Visit the Epson support website for the latest information.

<http://www.epson.eu/Support> (Europe)

<http://support.epson.net/> (outside Europe)

- 5** Make the appropriate settings.
The necessary settings vary depending on the authentication method. Enter the information for the email server you are using.

Items	Explanations
Authentication Method	Displays the selected authentication method.
Authenticated Account	If you select SMTP-AUTH or POP before SMTP as the Authentication Method, enter the user name (email address) registered to the email server within 30 characters or less.
Authenticated Password	If you select SMTP-AUTH or POP before SMTP as the Authentication Method, enter the password of the authenticated account within 20 characters or less.

Maintaining Your Product and Software

Items	Explanations
Sender's Email Address	Specify the email address that the product uses to send emails. You can specify the existing email address. To make it clear that the email is being sent from the product, you can acquire an address specifically for the product and enter it here.
SMTP Server Address	Enter the server address of the server that sends the email (SMTP server).
SMTP Server Port Number	Enter the port number of the server that sends the email (SMTP server).
POP3 Server Address	If you select POP Before SMTP as the Authentication Method, enter the server address of the server that receives the email (POP3 server).
POP3 Server Port Number	If you select POP Before SMTP as the Authentication Method, enter the port number of the email server that receives the email (POP3 server).

6 Press **OK**.

7 Select **Connection Check** to check that the product is connected to the email server.

Note:

- ☐ If an error message is displayed, check if the email server settings are correct.
- ☐ When you cannot send an email even if the connection check succeeds, check the authentication method for the email server you are using.

Checking an email server connection

1 Enter **Setup** from the Home menu.

2 Select **System Administration > Wi-Fi/Network Settings > Advanced Setup**.

3 Select **Email Server > Connection Check** to check that the printer is connected to the email server.

Note:

- ☐ If an error message is displayed, check if the email server settings are correct.
- ☐ When you cannot send an email even if the connection check succeeds, check the authentication method for the email server you are using.

Sharing the Product for Printing

You can setup the printer so that other computers on the network can share it.

The computer connected directly to the printer acts as a server. Other computers on the network access the server and share the printer.

For more details, see the computer's help.

If you want to use the printer over a network, see the Network Guide.

Cleaning the Product

Cleaning the exterior of the product

To keep your product in optimum condition, clean it thoroughly several times a year by using the following instructions.


**Important:**

Never use alcohol or thinner to clean the product. These chemicals can damage the product.

Note:

Close the rear paper feed slot after you use the product to protect the product from dust.


- ☐ Use a soft, dry, clean cloth to clean the touchscreen. Do not use liquid or chemical cleaners.
- ☐ Use a soft, dry, clean cloth to clean the surface of the scanner glass.
If straight lines appear in the printout or the scanned data, clean the small scanner glass on the left carefully.



- ☐ If the glass surface is stained with grease or some other hard-to-remove material, use a small amount of glass cleaner and a soft cloth to remove it. Wipe off all remaining liquid.
- ☐ Do not press the surface of the scanner glass with any force.
- ☐ Be careful not to scratch or damage the surface of the scanner glass, and do not use a hard or abrasive brush to clean it. A damaged glass surface can decrease the scan quality.

Maintaining Your Product and Software

- ❑ Open the ADF cover and use a soft, dry, clean cloth to clean the roller and the interior of the ADF.



Cleaning the interior of the product

If your printouts are stained with ink, follow the steps below to clean the roller inside the product.

**Caution:**

Be careful not to touch the parts inside the product.

**Important:**

- ❑ Be careful to keep water away from the electronic components.
- ❑ Do not spray the inside of the product with lubricants.
- ❑ Unsuitable oils can damage the mechanism. Contact your dealer or a qualified service person if lubrication is needed.

1

Make sure that no warnings or errors are indicated in the control panel.

2

Load several sheets of A3-size plain paper (WF-7610 Series/WF-7620 Series) or A4-size plain paper (WF-3620 Series/WF-3640 Series) in the paper cassette 1.

➡ [“Loading Paper into the Paper Cassette” on page 33](#)

3

Enter **Setup** mode from the Home menu.

4

Select **Maintenance, Paper Guide Cleaning**, and then follow the instructions on the control panel.

Note for the product with paper cassette 2:

If the stain does not clear, load paper in paper cassette 2, then try step 3 to 4.

Replacing Maintenance Box

Checking the maintenance box status

The maintenance box status is shown in the same screen of the ink cartridge status. You can check the status from the printer software or the control panel.

➔ [“Checking the Ink Cartridge Status” on page 126](#)

Precautions on the maintenance box

Read all of the instructions in this section before replacing the maintenance box.

- ☐ Epson recommends the use of a genuine Epson maintenance box. The use of a non-genuine maintenance box may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic printer behavior. Epson cannot guarantee the quality or reliability of a non-genuine maintenance box.
- ☐ Do not dismantle the maintenance box.
- ☐ Do not touch the green chip on the side of the maintenance box.
- ☐ Keep out of reach of children, and do not drink the ink.
- ☐ Do not tilt the used maintenance box until it is placed in the plastic bag provided.
- ☐ Do not reuse a maintenance box which has been removed and left detached for a long period.
- ☐ Keep the maintenance box away from direct sunlight.
- ☐ In some print cycles a very small amount of surplus ink may be collected in the maintenance box. To prevent ink leakage from the maintenance box, the product is designed to stop printing when the absorbing capacity of the maintenance box has reached its limit. Whether and how often this is required will vary according to the number of pages you print, the type of material that you print and the number of cleaning cycles that the product performs. Replace the maintenance box when you are promoted to do so. The Epson Status Monitor, your LCD, or lights on the control panel will advise you when this part needs replacing. The need for replacement of the pad does not mean that your product has ceased to operate in accordance with its specifications. The Epson warranty does not cover the cost of this replacement. It is a user-serviceable part.

Replacing a maintenance box

To replace the maintenance box, follow the steps below.

- 1** Confirm that the product is not draining the ink.
- 2** Remove the replacement maintenance box from the package.


Note:

Do not touch the green chip on the side of the box. Doing so may prevent normal operation.


Maintaining Your Product and Software

3

For WF-7610 Series/WF-7620 Series: Open the rear cover 1.




For WF-3620 Series/WF-3640 Series: Pull out the rear cover.



4

Put your hand on the handle of the maintenance box, and then pull the box outward.




Note:

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water.

5

Put the used maintenance box in the plastic bag provided with the replacement box, and dispose of it properly.



Maintaining Your Product and Software

Note:


Do not tilt the used maintenance box until after it is sealed in the plastic bag.

6


Insert the maintenance box into place as far as it will go.

7

For WF-7610 Series/WF-7620 Series: Close the rear cover 1.



For WF-3620 Series/WF-3640 Series: Reattach the rear cover.



Maintenance box replacement is complete.

Transporting the Product

If you move the product some distance, you need to prepare it for transportation in its original box or one of a similar size.

**Important:**

- ☐ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.
- ☐ Leave the ink cartridges installed. Removing the cartridges can dry out the print head and may prevent the product from printing.

1


Make sure the product is off.

2


Open the scanner unit.

Maintaining Your Product and Software

- 3** Make sure the print head is in the home position on the right.



- 4** Secure the ink cartridge holder to the case with tape as shown.



- 5** Close the scanner unit slowly.

- 6** Unplug its power cord and disconnect all other cables from the product.

- 7** Remove all paper from the rear paper feed slot.

- 8** Close the rear paper feed slot and the output tray.

- 9** Remove all paper from the paper cassette and re-insert the cassette into the product.

- 10** Repack the product in its box, using the protective materials that came with it.

Note:

Keep the product level during transport.

Checking and Installing Your Software

Checking the software installed on your computer

To use the functions described in this User's Guide, you need to install the following software.

- ☐ Epson Driver and Utilities
- ☐ Epson Easy Photo Print
- ☐ Epson Event Manager
- ☐ Epson FAX Utility

Follow the steps below to check that the software is installed on your computer.

For Windows

- 1** **Windows 8 and Server 2012:** Select **Desktop**, **Settings** charm, and **Control Panel**.
Windows 7, Vista, and Server 2008: Click the start button and select **Control Panel**.
Windows XP and Server 2003: Click **Start** and select **Control Panel**.
- 2** **Windows 8, Windows 7, Vista, Server 2012 and Server 2008:** Select **Uninstall a program** from the Programs category.
Windows XP: Double-click the **Add or Remove Programs** icon.
Windows Server 2003: Click the **Add or Remove Programs** icon.
- 3** Check the list of currently installed programs.

For Mac OS X

- 1** Double-click **Macintosh HD**.
- 2** Double-click the **Epson Software** folder in the Applications folder and check the contents.

Note:

- ☐ The Applications folder contains software provided by third parties.
- ☐ To check that the printer driver is installed, click **System Preferences** on the Apple menu and then click **Print & Scan** (for Mac OS X 10.8 or 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5.8). Then locate your product in the Printers list box.

Installing the software

You can download the latest software applications from the following Epson website.

<http://support.epson.net/>

<http://www.epson.eu/Support> (Europe)

Uninstalling Your Software

You may need to uninstall and then reinstall your software to solve certain problems or if you upgrade your operating system.

See the following section for information on determining what applications are installed.

➔ [“Checking the software installed on your computer” on page 151](#)

For Windows

Note:

- ☐ For Windows 8, 7, Vista, Server 2012 and Server 2008, you need an administrator account and password if you log on as a standard user.
- ☐ For Windows XP and Server 2003, you must log on to a Computer Administrator account.

1 Turn off the product.

2 Disconnect the product's interface cable from your computer.

3 Do one of the following.

Windows 8 and server 2012: Select **Desktop, Settings** charm, and **Control Panel**.

Windows 7, Vista, and Server 2008: Click the start button and select **Control Panel**.

Windows XP and Server 2003: Click **Start** and select **Control Panel**.

4 Do one of the following.

Windows 8, Windows 7, Vista, Server 2012 and Server 2008: Select **Uninstall a program** from the Programs category.

Windows XP: Double-click the **Add or Remove Programs** icon.

Windows Server 2003: Click the **Add or Remove Programs** icon.

5 Select the software you want to uninstall such as your product's driver and the application from the list displayed.

Maintaining Your Product and Software

6

Do one of the following.

Windows 8, Windows 7, Server 2012 and Server 2008: Select **Uninstall/Change** or **Uninstall**.

Windows Vista: Click **Uninstall/Change** or **Uninstall**, and then click **Continue** in the User Account Control window.

Windows XP and Server 2003: Click **Change/Remove** or **Remove**.

Note:

*If you chose to uninstall your product's printer driver in step 5, select the icon for your product and then click **OK**.*

7

When the confirmation window appears, click **Yes** or **Next**.

8

Follow the on-screen instructions.

In some cases, a message may appear to prompt you to restart your computer. If so, make sure **I want to restart my computer now** is selected and click **Finish**.

For Mac OS X

Note:

- ☐ To uninstall your software you need to download the Uninstaller.
Access the site at:
<http://www.epson.com>
Next, select the support section of your local Epson Web site.
- ☐ To uninstall applications, you must log on to a Computer Administrator account.
You cannot uninstall programs if you log on as a limited account user.
- ☐ Depending on the application, the Installer may be separated from the Uninstaller.

1

Quit all running applications.

2

Double-click the **Uninstaller** icon in your Mac OS X hard drive.

3

Select the check boxes for the software you want to uninstall, such as the printer driver and the application, from the list displayed.

4

Click **Uninstall**.

5

Follow the on-screen instructions.

If you cannot find the software you want to uninstall in the Uninstaller window, double-click the **Applications** folder in your Mac OS X hard drive, select the application you want to uninstall, and then drag it to the **Trash** icon.

Maintaining Your Product and Software

Note:

*If you uninstall the printer driver and the name of your product remains in the Print & Scan (for Mac OS X 10.8 or 10.7) or Print & Fax (for Mac OS X 10.6 or 10.5.8) window, select the name of your product and click the - **remove** button.*

Transferring Data Using an External Storage Device

You can use the product's memory card slots or external USB port to copy files to a computer connected to the product. You can also use it to copy files on your computer to the storage device.

Precautions on Storage Devices

Keep the following in mind when copying files between your storage device and computer:

- ☐ Check the documentation that came with your storage device and any adapter you may be using for any handling guidelines.
- ☐ Do not copy files to a storage device while you are printing from your storage device.
- ☐ The product display does not update information about your storage device after you copy files to it or delete files from it. To update the information displayed, eject and reload the storage device.
- ☐ Do not eject your memory card or turn off the printer while the memory card light is flashing or you may lose data.

Copying Files Between a Storage Device and Your Computer

Note:

If Memory Device setting in the System Administration settings has been set to Disable, the product does not recognize the storage device if it is inserted.

Copying files to your computer

- 1** Make sure the product is turned on and a storage device is inserted or connected.
- 2**
 - Windows 8 and Server 2012:**
Right-click on the **Start** screen, or swipe from the bottom or top edge of the **Start** screen and select **All apps**, then select **Computer**.
 - Windows 7, Vista, and Server 2008:**
Click the start button and select **Computer**.
 - Windows XP and Server 2003:**
Click **Start** and select **My Computer**.

Transferring Data Using an External Storage Device

Mac OS X:

The removable disk icon () appears on your desktop automatically.

3

Double-click the removable disk icon, then select the folder in which your files are saved.

Note:

If you have set a volume label, it is displayed as the drive name. If you have not set the volume label, "removable disk" is displayed as the drive name on Windows XP and Server 2003.

4

Select the files you want to copy and drag them to a folder on your computer's hard drive.



Important:

For Mac OS X users

When you remove the storage device, always drag the removable disk icon on your desktop into the trash before you remove the storage device or you may lose data on the device.

Saving files to a storage device

Before inserting your memory device, make sure the write-protect switch is set to allow writing to the memory device.

Note:

- ☐ *After copying a file to a memory device from a Macintosh computer, an older digital camera may not be able to read the memory device.*
- ☐ *If USB is selected from the File Sharing menu, you cannot write to the memory device from a computer connected through a network. To give write access to the network computer, change the setting to Wi-Fi/Network.*

1

Make sure the product is turned on and a storage device is inserted or connected.

2

Windows 8 and Server 2012:

Right-click on the **Start** screen, or swipe from the bottom or top edge of the **Start** screen and select **All apps**, then select **Computer**.

Windows 7, Vista, and Server 2008:

Click the start button and select **Computer**.

Windows XP and Server 2003:

Click **Start** and select **My Computer**.

Mac OS X:

The removable disk icon () appears on your desktop automatically.

3

Double-click the removable disk icon, then select the folder in which you want to save your files.

Note:

If you have set a volume label, it is displayed as the drive name. If you have not set the volume label, "removable disk" is displayed as the drive name on Windows XP and Server 2003.

Transferring Data Using an External Storage Device

4

Select the folder on your computer's hard drive that contains the files you want to copy. Then select the files and drag them to the folder on your storage device.



Important:

For Mac OS X users

When you remove the storage device, always drag the removable disk icon on your desktop into the trash before you remove the storage device or you may lose data on it.

Error Indicators

Error Messages on the Control Panel

This section explains the meaning of messages displayed on the LCD screen. You can also check errors on the Status Menu by pressing **i**.

➔ [“Status Menu” on page 25](#)

Messages	Solutions
Paper Jam	➔ “Paper Jams” on page 165
Printer error. Turn the power off and on again. For details, see your documentation.	Turn the product off and then back on. Make sure that no paper is still in the product. If the error still appears, contact Epson Support.
Maintenance box is at the end of its service life. You need to replace it.	Replace the maintenance box. ➔ “Replacing Maintenance Box” on page 147
A printer's ink pad is nearing the end of its service life. Please contact Epson Support.	Press ⏏ button to resume printing. The message will be displayed until the ink pad* is replaced. Contact Epson or an authorized Epson service provider to replace the ink pad before the end of its service life. It is not a user-serviceable part.
A printer's ink pad is at the end of its service life. Please contact Epson Support.	Contact Epson or an authorized Epson service provider to replace the ink pad*. It is not a user-serviceable part.
The phone line is connected to a different jack.	➔ “Connecting to a Phone Line” on page 81
Connect the phone line to the "LINE" jack.	
The phone line is not connected.	
No dial tone detected.	➔ ““No dial tone detected.” error occurs” on page 196
Failed to receive faxes because the fax data capacity is full. Press [i] for details.	Received faxes may accumulate without being processed due to the following reasons. <ul style="list-style-type: none"> ❑ Cannot print because a printer error has occurred. Clear the printer error. To check the details and solutions to the error, press i and then select Printer Information. ❑ Cannot save in the computer or the memory device. To check whether or not received faxes have been saved, press i and then select Job Monitor > Communication Job. To save received faxes, turn on the computer or connect a memory device to the printer.
Combination of the IP address and the subnet mask is invalid. See your documentation.	Refer the online Network Guide.
Communication error Authentication error DNS error	See the solution in the following section. ➔ “Error Code on the Status Menu” on page 159

Error Indicators

Messages	Solutions
Recovery Mode	<p>The firmware update has failed. You will need to re-attempt the firmware update. Ready a USB cable and visit your local Epson website for further instructions.</p> <p>➔ "Where To Get Help" on page 209</p>

* In some print cycles a very small amount of surplus ink may be collected in the ink pad. To prevent ink leakage from the pad, the product is designed to stop printing when the pad has reached its limit. Whether and how often this is required will vary according to the number of pages you print using the borderless print option. The need for replacement of the pad does not mean that your product has ceased to operate in accordance with its specifications. The product will advise you when the pad requires replacing and this can only be performed by an authorized Epson Service provider. The Epson warranty does not cover the cost of this replacement.

Error Code on the Status Menu

If a job does not complete successfully, check the error code displayed on the history of the each job. You can check the error code by pressing **i**, and then select **Job History**. Refer to the following table to find the problem and its solution.

Code	Problem	Solution
001	The product was turned off by a power failure.	-
109	The received fax was already deleted.	-
110	The job was printed on one side only because the paper loaded does not support double sided printing.	-
201	The memory is full.	<p>Send multiple pages separately.</p> <p>Sending a monochrome fax to one recipient is available using Direct Send.</p> <p>➔ "Using handy fax features" on page 90</p> <p>Print unprinted received fax data from Job Monitor in the Status Menu.</p>
202	The line was disconnected by the recipient machine.	Wait for a moment, and then try again.
203	The product cannot detect the dial tone.	<p>Check the phone line is connected correctly.</p> <p>➔ "Connecting to a Phone Line" on page 81</p> <p>Find more solutions in the following section.</p> <p>➔ ""No dial tone detected." error occurs" on page 196</p>
204	The recipient machine is busy.	Wait for a moment, and then try again.
205	The recipient machine does not answer.	
206	The phone cable is incorrectly connected to the LINE and EXT port of the product.	<p>Connect the product to the phone line correctly.</p> <p>➔ "Connecting to a Phone Line" on page 81</p>
207	The product is not connected to the phone line.	

Error Indicators

Code	Problem	Solution
208	The fax could not be sent to some of the specified recipients.	<p>Print a Fax Log from Fax Report to check which recipients failed to receive the fax.</p> <p>➔ "Printing a fax report" on page 104</p> <p>When Save Failure Data is set to On, you can resend a fax from Job Monitor in Status Menu.</p>
301 401	There is not enough storage space available to save the data in the external memory device.	<p>Increase the storage space.</p> <p>When scanning, reduce the number of documents or change the following settings to reduce the size of the scanned data.</p> <ul style="list-style-type: none"> - Select a lower resolution. - Select a higher Compression Ratio. <p>➔ "Scan Mode" on page 111</p>
302 402	The external memory device is write-protected.	Disable write protection on the external memory device.
303	No folder has been created to save the scanned data.	Insert another external memory device.
304 404	The external memory device has been removed.	Reinsert the external device.
305	An error occurred while saving the data to the external memory device.	If the external device is accessed from a computer, wait for a while and then try again.
405	An error occurred while saving the data to the external memory device.	<p>Reinsert the external memory device.</p> <p>Use a different external memory device on which you have created a folder using the Create Folder to Save function.</p>
311 321 411 421	A DNS error has occurred.	<p>Check the product's DNS settings from the control panel. Select the menu as shown below.</p> <p>Setup > System Administration > Wi-Fi/Network Settings > Advanced Setup > DNS Server</p> <p>Check the DNS settings for the server, the computer, or the access point.</p>
312 412	An authentication error has occurred.	<p>Check the product's Email Server settings. Select the menu shown as below to run the connection check.</p> <p>Setup > System Administration > Wi-Fi/Network Settings > Advanced Setup > Email Server > Connection Check</p>
313 413	A communication error has occurred.	<p>Check the product's Email Server settings. Select the menu shown as below to run the connection check.</p> <p>Setup > System Administration > Wi-Fi/Network Settings > Advanced Setup > Email Server > Connection Check</p> <p>➔ "Email Server Settings" on page 143</p> <p>The authentication method of the settings and the email server may not match. When you select Off as the authentication method, make sure the authentication method of the email server is set to None.</p> <p>Make sure the product is connected to the network correctly. For details, see the Network Guide.</p>

Error Indicators

Code	Problem	Solution
314	The data size exceeds the maximum size for attached files.	When scanning, increase the Attached File Max Size setting or change the following settings to reduce the size of the scanned data. - Select a lower resolution. - Select a higher Compression Ratio.
306 315	The memory is full.	Wait until other ongoing jobs are finished.
322 422	An authentication error has occurred.	Check that the entered folder path, the user name, and the password are correct.
323 423	A communication error has occurred.	Make sure the product is connected to the network correctly. For details, see the Network Guide. Check the Location settings. A file with the same name may exist in the specified file. Make sure the file is not opened and the file is not a read-only file.
324	A file with the same name already exists in the specified folder.	Delete the file with the same name or change the File Name Prefix in File Settings.
325 425	There is not enough storage space available to save the data in the specified folder.	Increase the storage space. When scanning to a folder, reduce the number of documents or change the following settings to reduce the size of the scanned data. - Select a lower resolution. - Select a higher Compression Ratio.
327	The memory is full.	Wait until other ongoing jobs are finished.
328 428	The destination was wrong or the destination did not exist.	Check the entered folder path, the user name, and the password is correct.
331	A communication error occurred while acquiring the destination list.	Make sure the product is connected to the network correctly. For details, see the Network Guide.
332	There is not enough storage space available to save the scanned data in the destination storage.	Reduce the number of documents.
333	The destination could not be found because the destination information has been changed before sending the scanned data.	Select the destination again.
334	An error occurred while sending the scanned data.	-
341	A communication error has occurred.	Make sure the product is connected to the computer or network correctly. For details, see the Network Guide. When you are using Scan to Computer, make sure you have installed Epson Event Manager. ➔ "Installing the software" on page 152

Troubleshooting for Printing/Copying

Diagnosing the Problem

Troubleshooting product problems is best handled in two steps: first diagnose the problem, then apply likely solutions until the problem is fixed.

The information that you need to diagnose and solve most common problems is provided by online problem solving, the control panel, or the status monitor. Refer to the appropriate section below.

If you have a specific problem relating to print quality, a printing problem not related to print quality, or a paper feeding problem, or if the product does not print at all, refer to the appropriate section.

To solve a problem, you may need to cancel printing.

➡ [“Canceling printing” on page 55](#)

Troubleshooting for Printing/Copying

Checking product status

If a problem occurs while printing, an error message will appear in the status monitor window.

When you need to replace an ink cartridge or a maintenance box, click the **How To** button on the window, and the status monitor will lead you step-by-step through the cartridge or the maintenance box replacement procedure.

For Windows

There are two ways to access EPSON Status Monitor 3:

- ☐ Double-click the product shortcut icon on your Windows taskbar. To add a shortcut icon to the taskbar, see the following section:
➔ [“From the shortcut icon on the taskbar” on page 51](#)
- ☐ Open the printer driver, click the **Maintenance** tab, then click the **EPSON Status Monitor 3** button.

When you access EPSON Status Monitor 3, the following window appears:



Note:

- ☐ If EPSON Status Monitor 3 does not appear, access the printer driver and click the **Maintenance** tab and then the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.
- ☐ Depending on current settings, the simplified status monitor may be displayed. Click the **Details** button to display the window above.

EPSON Status Monitor 3 provides the following information:

Troubleshooting for Printing/Copying

❑ **Current Status:**

If the ink is low/expended or the maintenance box is nearly full/full, the **How to** button appears in the EPSON Status Monitor 3 window. Clicking **How to** displays ink cartridge or maintenance box replacement instructions.

❑ **Ink Levels:**

EPSON Status Monitor 3 provides a graphic display of the ink cartridge status.

❑ **Information:**

You can view information about the installed ink cartridges by clicking **Information**.

❑ **Maintenance Box Service Life:**

EPSON Status Monitor 3 provides a graphic display of the maintenance box status.

❑ **Technical Support:**

Click **Technical Support** to access the Epson technical support website.

❑ **Print Queue:**

You can view Windows Spooler by clicking **Print Queue**.

For Mac OS X

Follow these steps to access EPSON Status Monitor.

1

Access the Epson Printer Utility 4.

➔ [“Accessing the printer driver for Mac OS X” on page 51](#)

2


Click the **EPSON Status Monitor** icon. The EPSON Status Monitor appears.



Troubleshooting for Printing/Copying

You can also use this utility to check the ink cartridge status before printing. EPSON Status Monitor displays the ink cartridge status at the time it was opened. To update the ink cartridge status, click **Update**.

When ink is low/expended or the maintenance box is nearly full/full, a **How to** button appears. Click **How to**, and EPSON Status Monitor will lead you step by step through the ink cartridge or maintenance box replacement procedure.



Paper Jams



Caution:

Never touch the buttons on the control panel while your hand is inside the product.

Note:

- ☐ Cancel the print job if prompted by a message from the LCD screen or the printer driver.
- ☐ After you have removed the jammed paper, press the button indicated in the LCD screen.


Removing jammed paper from the rear cover

WF-7610 Series/WF-7620 Series


- 1 Turn the product around.

Note:

If you need to change the position of the product, two people are required to lift the product.




- 2 Open the rear cover 1.




Troubleshooting for Printing/Copying


- 3** Remove the jammed paper.



- 4** Pull out the rear cover 2.




- 5** Carefully remove the jammed paper.




Troubleshooting for Printing/Copying

- 6** Carefully remove the jammed paper.




- 7** Open the rear cover 2.




Troubleshooting for Printing/Copying


- 8** Carefully remove the jammed paper.



- 9** Reattach the rear cover 2.




- 10** Close the rear cover 1.




WF-3620 Series/WF-3640 Series

- 1** Pull out the rear cover.




Troubleshooting for Printing/Copying


- 2** Carefully remove the jammed paper.



- 3** Carefully remove the jammed paper.




- 4** Open the rear cover.




Troubleshooting for Printing/Copying

- 5** Carefully remove the jammed paper.




- 6** Reattach the rear cover.




Removing jammed paper from inside the product

- 1** Carefully remove the jammed paper.



- 2** Open the scanner unit.





Troubleshooting for Printing/Copying

**Important:**

Do not lift up the scanner unit when the document cover is open.

**3**

Remove all of the paper inside, including any torn pieces.

**Important:**

Do not touch the flat white cable connected to the cartridge holder.

4

Close the scanner unit slowly.


Note for WF-7610 Series/WF-7620 Series:

If there are still some torn pieces of paper inside the product even after clearing the paper jam, follow the steps below to remove them.


Setup > Maintenance > Remove Paper

Removing jammed paper from the paper cassette

- 1 Pull the paper cassette all the way out.




- 2 For WF-7610 Series/WF-7620 Series: Remove the cover.




- 3 Remove the jammed paper from the cassette.

- 4 Carefully remove any paper jammed inside the product.




Troubleshooting for Printing/Copying


- 5** Align the edges of the paper.



- 6** For WF-7610 Series/7620 Series: Put the paper cassette cover back on.




- 7** Keep the cassette flat and slowly and carefully reinsert it all the way into the product.




Removing jammed paper from the Automatic Document Feeder (ADF)

- 1 Remove the stack of paper from the ADF input tray.
- 2 For WF-7610 Series/WF-7620 Series: Raise the ADF lever and open the ADF cover.




For WF-3620 Series/WF-3640 Series: Open the ADF cover.

**Important:**


Make sure you open the ADF cover before removing jammed paper. If you do not open the cover, the product may be damaged.

- 3 Carefully remove the jammed paper.




Troubleshooting for Printing/Copying

- 4** Open the document cover.




- 5** Carefully remove the jammed paper.



- 6** Close the document cover and ADF cover.

- 7** Raise the ADF input tray.



Troubleshooting for Printing/Copying

- 8** Carefully remove the jammed paper.



- 9** Return the ADF input tray to its original position.

Preventing paper jams

If your paper jams frequently, check the following.

- ☐ The paper is smooth, not curled or wrinkled.
- ☐ You are using high-quality paper.
- ☐ The printable side of the paper is face down in the paper cassette.
- ☐ The printable side of the paper is face up in the rear paper feed slot.
- ☐ The paper stack was fanned before loading.
- ☐ For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide.
For Epson special media, make sure the number of sheets is less than the limit specified for the media.
➔ [“Selecting Paper” on page 27](#)
- ☐ The edge guides are snug against the edges of the paper.
- ☐ The product is on a flat, stable surface that extends beyond the base in all directions. The product will not operate properly if it is tilted.

Reprinting after a paper jam (for Windows only)

After you cancel the print job because of a paper jam, you can reprint it without reprinting pages that have already been printed.

- 1** Solve the paper jam.
➔ [“Paper Jams” on page 165](#)
- 2** Access the printer settings.
➔ [“Accessing the printer driver for Windows” on page 50](#)
- 3** Select the **Print Preview** check box in the Main window of your printer driver.

Troubleshooting for Printing/Copying


- 4
- Make the settings that you want to use to print.
- 5
- Click **OK** to close the printer settings window, and then print your file. Print Preview window opens.
- 6
- Select a page that has already been printed in the page list box on the left side, and then select **Remove Page** from the Print Options menu. Repeat this step for all the pages that have already been printed.
- 7
- Click **Print** on the Print Preview window.

Print Quality Help

If you are having print quality problems, then compare it with the illustrations below. Click the caption under the illustration that best resembles your prints.

<div>enthalten alle Aufdruck. W 5008 "Regel</div> <div>Good sample</div>	<div></div> <div>Good sample</div>
<div>enthalten alle Aufdruck. W 5008 "Regel</div> <div>➔ "Horizontal banding" on page 179</div>	<div>enthalten alle Aufdruck. W 5008 "Regel</div> <div>➔ "Vertical banding or misalignment" on page 179</div>
<div></div> <div>➔ "Horizontal banding" on page 179</div>	<div></div> <div>➔ "Vertical banding or misalignment" on page 179</div>

Troubleshooting for Printing/Copying



Horizontal banding

- ❑ Make sure the printable side (the whiter or glossier side) of the paper is face up in the rear paper feed slot.
- ❑ Make sure the printable side (the whiter or glossier side) of the paper is face down in the paper cassette.
- ❑ Run the Nozzle Check utility and then clean any print heads which produced a defective nozzle check result.
 - ➔ ["Checking the Print Head Nozzles" on page 137](#)
- If the problem does not improve, run the Print Head Alignment utility.
 - ➔ ["Aligning the Print Head" on page 140](#)
- ❑ For best results, use up ink cartridge within six months of opening the package.
- ❑ Try to use genuine Epson ink cartridges.
- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.
 - ➔ ["Selecting Paper" on page 27](#)
- ❑ If a moire (cross-hatch) pattern appears on your copy, change the Zoom setting in the LCD menu or shift the position of your original.
- ❑ If there is problem with copy quality, clean the surface of the scanner glass.
 - ➔ ["Cleaning the exterior of the product" on page 145](#)

Vertical banding or misalignment

- ❑ Make sure the printable side (the whiter or glossier side) of the paper is face up in the rear paper feed slot.
- ❑ Make sure the printable side (the whiter or glossier side) of the paper is face down in the paper cassette.
- ❑ Run the Nozzle Check utility and then clean any print heads which produced a defective nozzle check result.
 - ➔ ["Checking the Print Head Nozzles" on page 137](#)
- ❑ Run the Print Head Alignment utility.
 - ➔ ["Aligning the Print Head" on page 140](#)

Troubleshooting for Printing/Copying

- ❑ For Windows, clear the **High Speed** check box from the More Options window in your printer driver. See the online help for details.
For Mac OS X, select **Off** from the High Speed Printing. To display the High Speed Printing, click through the following menus: **System Preferences, Print & Scan** (for Mac OS X 10.8 or 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5.8), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.
- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.
➔ [“Selecting Paper” on page 27](#)
- ❑ For Windows, if you have selected Standard-Vivid as Quality in your printer driver's Main tab, change it to Standard.
For Mac OS X, if you have selected Normal-Vivid as Print Quality in your printer driver's Print Settings from the pop-up menu, change it to Normal.
- ❑ If there is problem with copy quality, clean the surface of the scanner glass.
➔ [“Cleaning the exterior of the product” on page 145](#)

Incorrect or missing colors

- ❑ For Windows, clear the **Grayscale** setting in the Main window in your printer driver.
For Mac OS X, clear the **Grayscale** setting in Print Settings in the Print dialog box in your printer driver.
- ❑ Adjust the color settings in your application or in your printer driver settings.
For Windows, check the More Options window.
For Mac OS X, check the Color Options dialog box from the Print dialog box.
- ❑ Run the Nozzle Check utility and then clean any print heads which produced a defective nozzle check result.
➔ [“Checking the Print Head Nozzles” on page 137](#)
- ❑ If you have just replaced an ink cartridge, make sure the date on the box. If you have not used the product for a long time, Epson recommends replacing the ink cartridges.
➔ [“Replacing an ink cartridge” on page 133](#)
- ❑ Try to use genuine Epson ink cartridges and paper recommended by Epson.

Blurry or smeared print

- ❑ Try to use genuine Epson ink cartridges and paper recommended by Epson.
- ❑ Make sure the product is on a flat, stable surface that extends beyond the base in all directions. The product will not operate properly if it is tilted.
- ❑ Make sure your paper is not damaged, dirty, or too old.
- ❑ Make sure your paper is dry and the printable side (the whiter or glossier side) is face up in the rear paper feed slot.
- ❑ Make sure your paper is dry and the printable side (the whiter or glossier side) is face down in the paper cassette.
- ❑ If the paper is curled toward the printable side, flatten it or curl it slightly in the opposite direction.

Troubleshooting for Printing/Copying

- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.
➡ [“Selecting Paper” on page 27](#)
- ❑ Remove each sheet from the output tray as it is printed.
- ❑ Do not touch or allow anything to come into contact with the printed side of paper with a shiny finish. To handle your prints, follow the instructions of the paper.
- ❑ Run the Nozzle Check utility and then clean any print heads which produced a defective nozzle check result.
➡ [“Checking the Print Head Nozzles” on page 137](#)
- ❑ Run the Print Head Alignment utility.
➡ [“Aligning the Print Head” on page 140](#)
- ❑ From the product's control panel, select the menu as shown below.
Setup > Maintenance > Thick Paper > On

For Windows, select **Thick paper and envelopes** from Extended Settings in your printer driver's Maintenance tab.

For Mac OS X 10.5.8, select **On** from the Thick paper and envelopes. To display the Thick Paper and Envelopes, click through the following menus: **System Preferences, Print & Scan** (for Mac OS X 10.8 or 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5.8), your product (in the Printers list box, **Options & Supplies**, and then **Driver**.

- ❑ For Windows, if your printouts are still smeared when using Thick Paper and Envelopes, follow the instructions below.

Select **Short Grain Paper** from Extended Settings in your printer driver's Maintenance tab. This setting is not available when Borderless or Anti-Copy Pattern are selected.

This function is only available for WF-7610 Series/WF-7620 Series.

- ❑ If you are printing high-density data on plain paper using automatic 2-sided printing, lower the Print Density and choose a longer Increase Ink Drying Time in the Print Density Adjustment window (for Windows) or in the Two-sided Printing Settings (for Mac OS X) of your printer driver. The longer the Increase Ink Drying Time is, the longer it takes to print.
- ❑ If the paper is smeared with ink after printing, clean the interior of the product.
➡ [“Cleaning the interior of the product” on page 146](#)
- ❑ If there is problem with copy quality, clean the surface of the scanner glass.
➡ [“Cleaning the exterior of the product” on page 145](#)

Miscellaneous Printout Problems

Incorrect or garbled characters

- ❑ Clear any stalled print jobs.
➡ [“Canceling printing” on page 55](#)
- ❑ Turn off the product and computer. Make sure the product's interface cable is securely plugged in.

Troubleshooting for Printing/Copying

- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)
- ❑ If you put your computer into Hibernate or Sleep mode manually while the computer is sending a print job, pages of garbled text may be printed the next time you start your computer.

Incorrect margins

- ❑ Make sure that the paper is loaded into the rear paper feed slot or the paper cassette correctly.
 - ➔ [“Loading Paper into the Paper Cassette” on page 33](#)
 - ➔ [“Loading Envelopes into the Paper Cassette” on page 36](#)
 - ➔ [“Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39](#)
- ❑ Check the margin settings in your application. Make sure that the margins are within the printable area of the page.
 - ➔ [“Printable area” on page 200](#)
- ❑ Make sure the printer driver settings are appropriate for the paper size you are using.
 - For Windows, check the Main window.
 - For Mac OS X, check the Page Setup dialog box or Print dialog box.
- ❑ If margins still appear even when printing using the borderless setting, try one of the following.
 - For Windows, click **Extended Settings** button on the printer driver's Maintenance window, and then select **Remove white borders**.
 - For Mac OS X, select **On** from the Remove white borders. To display the Remove white borders, click through the following menus: **System Preferences**, **Print & Scan** (for Mac OS X 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5), your printer (in the Printers list box), **Options & Supplies**, and then **Driver**.
- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

Printout has a slight slant

- ❑ Make sure that the paper is loaded into the rear paper feed slot or the paper cassette correctly.
 - ➔ [“Loading Paper into the Paper Cassette” on page 33](#)
 - ➔ [“Loading Envelopes into the Paper Cassette” on page 36](#)
 - ➔ [“Loading Paper and Envelopes into the Rear Paper Feed Slot” on page 39](#)
- ❑ If Draft is selected in Quality in the Main window in your printer driver (for Windows), or in Print Quality in Print Settings (for Mac OS X), select another setting.

Size or position of copied image is incorrect

- ❑ Make sure the paper size, layout, document orientation, document size, and zoom setting selected in the control panel matches the paper used.
- ❑ When you are using the scanner glass, make sure you have not placed the product in direct sunlight or near a light source. The scanner glass may not detect the document correctly near a strong light.
- ❑ If the edges of the copy are cropped off, move the original slightly away from the corner.

Troubleshooting for Printing/Copying

- ❑ Clean the scanner glass.
 - ➔ [“Cleaning the exterior of the product” on page 145](#)

Inverted image

- ❑ For Windows, clear the **Mirror Image** check box from the More Options window of your printer driver, or turn off the Mirror Image setting in your application.
For Mac OS X, clear the **Mirror Image** check box in **Print Settings** in the Print dialog box of your printer driver, or turn off the Mirror Image setting in your application.
- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

Blank pages print

- ❑ Make sure the printer driver settings are appropriate for the paper size you are using.
For Windows, check the Main window.
For Mac OS X, check the Page Setup dialog box or Print dialog box.
- ❑ For Windows, check the **Skip Blank Page** setting by clicking the **Extended Settings** button on the Maintenance window of the printer driver.
For Mac OS X, select **On** from the Skip Blank Page. To display the Skip Blank Page, click through the following menus: **System Preferences**, **Print & Scan** (for Mac OS X 10.8 or 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5.8), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.
- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

Printed side is smeared or scuffed

- ❑ If the paper is curled toward the printable side, flatten it or curl it slightly in the opposite direction.
- ❑ Clean the interior of the product by using the Paper Guide Cleaning function.
 - ➔ [“Cleaning the interior of the product” on page 146](#)
- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

Printing is too slow

- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.
 - ➔ [“Selecting Paper” on page 27](#)
- ❑ Choose a lower print quality in the printer driver's Main window (Windows), or in the Print Settings dialog box from the printer driver's Print dialog box (Mac OS X).
 - ➔ [“Accessing the printer driver for Windows” on page 50](#)
 - ➔ [“Accessing the printer driver for Mac OS X” on page 51](#)

Troubleshooting for Printing/Copying

- ❑ When Increase Ink Drying Time settings is changed, the print speed may decline. Choose a shorter time for Increase Ink Drying Time in the Print Density Adjustment window (for Windows) or in the Two-sided Printing Settings (for Mac OS X) of your printer driver.
- ❑ Close any unnecessary applications.
- ❑ If you print continuously for an extended period, the printing may be extremely slow. This is to slow down the printing speed and prevent the product mechanism from overheating and being damaged. If this happens, you can continue to print, but we recommend stopping and leaving the product idle for at least 30 minutes with the power on. (The product does not recover with the power off.) After you restart, the product will print at normal speed.
- ❑ Uninstall the printer driver, then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

If you try all of the methods above and cannot solve the problem, see the following.

Paper Does Not Feed Correctly

Paper does not feed

Remove the stack of paper and make sure of the following:

- ❑ You have inserted the paper cassette all the way into the product.
- ❑ The paper is not curled or creased.
- ❑ The paper is not too old. See the instructions that came with the paper for more information.
- ❑ For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide. For Epson special media, make sure the number of sheets is less than the limit specified for the media.
 - ➔ [“Selecting Paper” on page 27](#)
- ❑ Paper is not jammed inside the product. If it is, remove the jammed paper.
 - ➔ [“Paper Jams” on page 165](#)
- ❑ The ink cartridges are not expended. If a cartridge is expended, replace it.
 - ➔ [“Replacing an ink cartridge” on page 133](#)
- ❑ You have followed any special loading instructions that came with your paper.

Multiple pages feed

- ❑ For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide. For Epson special media, make sure the number of sheets is less than the limit specified for the media.
 - ➔ [“Selecting Paper” on page 27](#)
- ❑ Make sure the edge guides are snug against the edges of the paper.
- ❑ Make sure the paper is not curled or folded. If so, flatten it or curl it slightly toward the opposite side before loading.

Troubleshooting for Printing/Copying

- ☐ Remove the stack of paper and make sure that the paper is not too thin.
 - ➔ [“Paper” on page 199](#)
- ☐ Fan the edges of the stack to separate the sheets, then reload the paper.

Paper is improperly loaded

If you have loaded the paper too far into the product, the product cannot feed the paper correctly. Turn the product off and gently remove the paper. Then turn the product on and reload the paper correctly.

Paper is not ejected fully or is wrinkled


- ☐ If the paper does not eject fully, press the button indicated on the control panel to eject the paper. If the paper is jammed inside the product, remove it by referring to the following section.
 - ➔ [“Paper Jams” on page 165](#)
- ☐ If the paper is wrinkled when it comes out, it may be damp or too thin. Load a new stack of paper.

Note:

Store any unused paper in its original packaging in a dry area.

The Product Does Not Print

All lights are off

- ☐ Press the  button to make sure the product is on.
- ☐ Make sure that the power cord is securely plugged in.
- ☐ Make sure that your outlet works and is not controlled by a wall switch or timer.

Lights came on and then went out

The product's voltage may not match the outlet rating. Turn off the product and unplug it immediately. Then check the label on the back of the product.



Caution:

If the voltage does not match, DO NOT PLUG YOUR PRODUCT BACK IN. Contact your dealer.

The control panel or lights are on


- ☐ Turn off the product and computer. Make sure the product's interface cable is securely plugged in.
- ☐ If you are using the USB interface, make sure your cable meets the USB or Hi-Speed USB standards.

Troubleshooting for Printing/Copying

- ❑ If you are connecting the product to your computer via a USB hub, connect the product to the first-tier hub from your computer. If the printer driver is still not recognized on your computer, try to directly connect the product to your computer without the USB hub.
- ❑ If you are connecting the product to your computer via a USB hub, make sure the USB hub device is recognized by your computer.
- ❑ If you are trying to print a large image, your computer may not have enough memory. Try reducing the resolution of your image or printing the image at a smaller size. You may need to install more memory in your computer.
- ❑ Users of Windows can clear any stalled print jobs from the Windows Spooler.
➔ [“Canceling printing” on page 55](#)
- ❑ Uninstall the printer driver, then reinstall it.
➔ [“Uninstalling Your Software” on page 152](#)

An ink error is indicated after you replace the cartridge

- 1 Open the scanner unit.



Important:

Do not lift up the scanner unit when the document cover is open.



- 2 Make sure the ink cartridge holder is at the ink cartridge replacement position.


Note:

If the ink cartridge holder is at the far right position, select the menu as shown below.


Setup > Maintenance > Ink Cartridge(s) Replacement

Troubleshooting for Printing/Copying

- 3** Open the ink cartridge cover. Remove and reinsert the ink cartridge and then continue with the ink cartridge installation.



- 4** Close the ink cartridge cover firmly.



- 5** Close the scanner unit slowly.

Other Problem

Printing plain papers quietly

When plain paper is selected for the paper type in the printer driver, try choosing Quiet Mode for quieter operations. This will reduce the print speed.

For Windows, select **On** as Quiet Mode in the Main tab of your printer driver.

For Mac OS X, select **On** from the Quiet Mode. To display the Quiet Mode, click through the following menus: **System Preferences**, **Print & Scan** (for Mac OS X 10.8 or 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.


The external memory device is not recognized

The external memory device may not be recognized depending on the Memory Device Interface settings. Select the menu as shown below.

Setup > System Administration > Memory Device Interface > Memory Device > Enable

Rear paper feed slot is removed (Only for WF-7610 Series/WF-7620 Series)

When the rear paper feed slot is removed, reattach it by holding vertically shown as below.



Power Turns Off Automatically

- ☐ Select **Power Off Settings** in System Administration, and then disable the **Power Off If Inactive** and **Power Off If Disconnected** settings.
- ☐ Disable the **Power Off Timer** setting in System Administration.

Note:

Available features vary depending on the production date and the location of purchase.

Troubleshooting for Scanning

Problems Indicated by Messages on the LCD Screen or Status Light

- ❑ Make sure the product is connected to your computer properly.
- ❑ Turn off the product and turn it on again. If the problem is not solved, the product may be malfunctioning, or the light source in the scanner unit may need to be replaced. Contact your dealer.
- ❑ Make sure the scanning software is fully installed.
For more details about reinstalling, visit your local Epson Web site.
➔ [“Where To Get Help” on page 209](#)

Problems When Starting a Scan

- ❑ Check the status light and make sure the product is ready to scan.
- ❑ Make sure your cables are securely connected to the product and a working electrical outlet.
If necessary, test your product's AC adapter by plugging in another electrical device and turning it on.
- ❑ Turn off the product and computer, and then check the interface cable connection between them to make sure it is secure.
- ❑ Make sure you select the correct product if a scanner list appears when starting to scan.
- ❑ Connect the product directly to the computer's external USB port or through one USB hub only. The product may not work properly when connected to the computer through more than one USB hub. If the problem persists, try connecting the product directly to the computer.
- ❑ If more than one product is connected to your computer, it may not work. Connect only the product you want to use, and then try scanning again.
- ❑ If the scanning software does not work properly, uninstall the software first and then reinstall it.
➔ [“Uninstalling Your Software” on page 152](#)

For more details about reinstall, visit your local Epson Web site for further instructions.
➔ [“Where To Get Help” on page 209](#)
- ❑ If you have clicked the **Keep Blocking** button in the Windows Security Alert window during or after installation of the Epson Software, unblock Epson Event Manager.
➔ [“How to unblock Epson Event Manager” on page 189](#)

How to unblock Epson Event Manager

- 1 Click **Start** or the start button, and then point to **Control Panel**.
For **Windows 8**: Select **Desktop**, **Settings** charm, and **Control Panel**.

Troubleshooting for Scanning

2

Do one of the following.

- ☐ Windows 8 and 7:
Select **System and Security**.
- ☐ Windows Vista:
Select **Security**.
- ☐ Windows XP:
Select **Security Center**.

3

Do one of the following.

- ☐ Windows 8, 7 and Vista:
Select **Allow a program through Windows Firewall**.
- ☐ Windows XP:
Select **Windows Firewall**.

4

Do one of the following.

- ☐ Windows 8 and 7:
Confirm that the check box for **EEventManager Application** is selected in the **Allowed programs and features** list.
- ☐ Windows Vista:
Click the **Exceptions** tab, and then confirm that the check box for **EEventManager Application** is selected in the Program or port list.
- ☐ Windows XP:
Click the **Exceptions** tab, and then confirm that the check box for **EEventManager Application** is selected in the Programs and Services list.

5

Click OK.

Using the Automatic Document Feeder (ADF)

- ☐ If the document cover or ADF cover is open, close it and try scanning again.
- ☐ Make sure your cables are securely connected to the product and a working electrical outlet.

Using scanning software other than Epson Scan driver

- ☐ If you are using any TWAIN-compliant programs, make sure that the correct product is selected as the Scanner or Source setting.
- ☐ If you cannot scan using any TWAIN-compliant scanning programs, uninstall the TWAIN-compliant scanning program and then reinstall it.
 - ➔ [“Uninstalling Your Software” on page 152](#)

Problems When Feeding Paper

The paper gets dirty

You may need to clean the product.

➔ [“Cleaning the Product” on page 145](#)

Multiple sheets of paper are fed

- ☐ If you load unsupported paper, the product may feed more than one sheet of paper at a time.
 - ➔ [“Automatic Document Feeder \(ADF\) specifications” on page 201](#)
 - ☐ You may need to clean the product.
 - ➔ [“Cleaning the Product” on page 145](#)
-

The paper jams in the Automatic Document Feeder (ADF)

Remove the jammed paper inside the ADF.

➔ [“Removing jammed paper from the Automatic Document Feeder \(ADF\)” on page 175](#)

Problems With Scanning Time

- ☐ Scanning at a high resolution takes a long time.
- ☐ When Quiet Mode is selected, scanning may take longer.
 - Select Quiet Mode from the pull-down list on the Epson Scan Configuration Setting screen.

Problems With Scanned Images

Scan quality is unsatisfactory

Scan quality can be improved by changing the current settings or adjusting the scanned image.

➔ [“Image Adjustment Features” on page 74](#)

An image on the back of your original appears in your scanned image

If your original is printed on thin paper, images on the back may be visible to the product and appear in your scanned image. Try scanning the original with a piece of black paper placed on the back of it. Also make sure that you select Text Enhancement in Office Mode.

Characters are blurred

- ☐ In Office Mode, select the **Text Enhancement** check box.

Troubleshooting for Scanning

- ❑ Adjust the Threshold setting.

Office Mode:

Select **Black&White** as the Image Type setting, and then try adjusting the Threshold setting.

Professional Mode:

Select **Black&White** from the Image type. Make the appropriate Image Option setting and then try adjusting the Threshold setting.


- ❑ Increase the resolution setting.

Characters are not recognized correctly when converted into editable text (OCR)

Place the document so that it is straight on the scanner glass. If the document is skewed, it may not be recognized correctly.

Ripple patterns appear in your scanned image

A ripple or cross-hatch pattern (known as moiré) may appear in a scanned image of a printed document.



- ❑ When you are using the scanner glass, displace your original document.
- ❑ Select the **Descreening** as the image quality setting.
- ❑ Try changing the **Resolution** setting.

Uneven color, smears, dots, or straight lines appear in your image

You may need to clean the interior of the product.


➔ [“Cleaning the Product” on page 145](#)

The scanning area or direction is unsatisfactory

The edges of your original are not scanned


- ❑ If you are scanning using the button or using normal preview in Professional Mode, move the document or photo 6mm(0.2inch) away from the horizontal and vertical edges of the scanner glass to avoid.
- ❑ If you are scanning using the button or using normal preview, move the document or photo about 3 mm (0.12 inch) away from the horizontal and vertical edges of the scanner glass to avoid cropping.

Troubleshooting for Scanning



Multiple documents are scanned into a single file

Position documents at least 20 mm (0.8 inch) apart from each other on the scanner glass.



Cannot scan the area you want

- ☐ Depending on the documents, you may not be able to scan the area you want. Use normal preview and create marquees on the area you want to scan.
- ☐ When you are using the scanner glass, make sure you have not placed the product in direct sunlight or near a light source. The scanner glass may not detect the document correctly near a strong light.
- ☐ When you are scanning from the control panel, check the Scan Area settings.
- ☐ When you are setting resolution is large, scanning area may be restricted. Lower the resolution or adjust the scanning area on the preview window.

Cannot scan in the direction you want

Click **Configuration**, select the **Preview** tab, and then clear the **Auto Photo Orientation** check box. Then, place your documents correctly.

Other Problems

Scanning quietly

You can select Quiet Mode to reduce the noise while scanning; however, scanning may take longer. Select **Quiet Mode** from the pull-down list on the Configuration EPSON Scan setting screen.

Cannot send the scanned image by email

Make sure you have configured the email server settings.

➔ [“Email Server Settings” on page 143](#)

Problems Remain After Trying All Solutions

If you have tried all the solutions and have not solved the problem, initialize the Epson Scan settings.

Click **Configuration**, select the **Other** tab, and then click **Reset All**.

Troubleshooting for Faxing

Cannot send and receive fax

- ❑ Make sure the phone cable is connected correctly.
 - ➔ [“Connecting to a Phone Line” on page 81](#)
- ❑ Run the **Check Fax Connection** to identify the cause of the problem.
 - ➔ Setup > System Administration > Fax Settings > Check Fax Connection
- ❑ Check the error code displayed for the failed fax job, and then see the following section for the solution.
 - ➔ [“Error Code on the Status Menu” on page 159](#)
- ❑ If the product is not connected to a phone and you want to receive faxes automatically, make sure you set **Receive Mode** to **Auto**.
 - ➔ [“Setting up the receive mode” on page 94](#)
- ❑ If you connected the product to a DSL phone line, you must install a DSL filter on the line otherwise you cannot fax. Contact your DSL provider for the necessary filter.
- ❑ Transmission speed may be the cause of the problem. Lower the **Fax Speed** setting.
 - ➔ [“System Administration Settings” on page 115](#)

If sending a fax to a specific recipient in the Contacts list often fails, set a lower fax speed for that recipient.

 - ➔ [“Creating a Contact” on page 106](#)
- ❑ Make sure that **ECM** is turned on. Color faxes cannot be sent and received when ECM is off.
 - ➔ [“System Administration Settings” on page 115](#)
- ❑ Under the following conditions, the printer runs out of memory and cannot receive faxes.
 - ❑ 100 received documents have been saved in the inbox.
 - ❑ The printer's memory is full (100%).
 - ➔ [“Memory full error occurs” on page 196](#)
- ❑ If a fax failed to send because the recipient machine did not respond, ask the recipient if the fax machine is operating.

If you still cannot send the fax, the cause may be the time taken for the recipient machine to pick up the call. After dialing, the product waits for 50 seconds for the recipient machine to respond, and if the machine does not respond, it cancels the transmission. To solve this problem, add pauses after the fax number by entering a hyphen (-). One hyphen causes the product to pause for three seconds.

“No dial tone detected.” error occurs

If you are connecting the product to a PBX (Private Branch Exchange) phone line or a Terminal Adapter, change the Line Type setting to PBX.

➔ [“Setting the line type” on page 85](#)

If you still cannot send a fax, change the **Dial Tone Detection** setting to **Off**. However, doing so may drop the first digit of a fax number and send the fax to the wrong number.

➔ Setup > System Administration > Fax Settings > Basic Settings > Dial Tone Detection

Memory full error occurs

- ☐ If your product is set to save received faxes in the Inbox, delete received faxes you have already seen or print the fax.
- ☐ If your product is set to save received faxes on a computer or an external storage device, turn on the computer or connect the device to save the faxes to the computer or device.
- ☐ If an error occurs because of a paper jam or expended ink cartridges when receiving a fax, clear the error and ask the sender to send the fax again.
- ☐ Even if the memory is full, you can send a monochrome fax to a single recipient by enabling the Direct Send option.
- ☐ Send your documents in several batches.

Quality problems

In sent faxes

- ☐ Clean the scanner glass and Automatic Document Feeder (ADF).
➔ [“Cleaning the exterior of the product” on page 145](#)
- ☐ If the fax you sent was faint or not clear, change the **Resolution** or **Density** in the fax settings menu.
➔ [“Fax Mode” on page 111](#)
- ☐ If you are not sure about the capabilities of the recipient fax machine, enable the **Direct Send** feature or select **Fine** as the Resolution setting before sending the fax. If you select **Super Fine** or **Ultra Fine** as the Resolution setting for a monochrome fax, and send the fax without using the Direct Send function, the product may automatically lower the resolution.

In received faxes

- ☐ Make sure that ECM is turned on.
➔ [“System Administration Settings” on page 115](#)
- ☐ You can print the fax again from the Status Menu.
➔ [“Checking sent/received fax jobs” on page 103](#)

Other problems

Answering machine cannot answer voice calls

When the Receive Mode is set to Auto, and an answering machine is connected to the same phone line as this product, set the number of rings to answer for receiving faxes to a higher number than the number of rings for the answering machine.

➔ [“Setting the number of rings to answer” on page 86](#)

The time and date of sent or received fax jobs is incorrect

If the time stamps on fax jobs are incorrect, or a scheduled fax is not sent at the specified time, the product's clock may be running fast/slow, it may have been reset by a power failure, or the product may have been turned off for an extended period of time. Set the correct time.

➔ Setup > System Administration > Common Settings > Date/Time Settings

Cannot store received faxes in an external storage device

The external storage device may be running out of memory, be write protected, or may not have the folder to save. To create a folder to save received faxes in the device, see the following section.

➔ [“Saving and Forwarding Received Faxes” on page 95](#)

You cannot save received faxes when **Memory Device Interface** has been disabled.

➔ Setup > System Administration > Printer Settings > Memory Device Interface

Faxes are sent at the wrong size

- ☐ When you are using the scanner glass, make sure you have not placed the product in direct sunlight or near a light source. The scanner glass may not detect the document correctly near a strong light.
- ☐ When scanning your document on the scanner glass for faxing, you need to select the document size.
 - ➔ [“Fax Mode” on page 111](#)

Cannot forward received faxes by email

Make sure you have configured the email server settings.

➔ [“Email Server Settings” on page 143](#)

Product Information

System Requirements

For Windows

System	PC Interface
Windows 8 (32-bit, 64-bit), Windows 7 (32-bit, 64-bit), Vista (32-bit, 64-bit), XP SP1 or higher(32-bit), or XP Professional x64 Edition, Server 2012, Server 2008 R2, Server 2008, and Server 2003	Hi-Speed USB

For Mac OS X

System	PC Interface
Mac OS X 10.5.8, 10.6.x, 10.7.x, 10.8.x	Hi-Speed USB

Note:

The UNIX File System (UFS) for Mac OS X is not supported.

Technical Specifications

Note:

Specifications are subject to change without notice.

Printer specifications

Paper path	Paper cassette 1 and 2 *, front entry Rear paper feed slot, top entry
Capacity	27.5 mm for paper cassette 1 and 2 * 0.3 mm for rear paper feed slot

* Paper cassette 2 is only supported for WF-7620 Series/WF-3640 Series.

Product Information

Paper

Note:

- ❑ Since the quality of any particular brand or type of paper may be changed by the manufacturer at any time, Epson cannot attest to the quality of any non-Epson brand or type of paper. Always test samples of paper stock before purchasing large quantities or printing large jobs.
- ❑ Poor quality paper may reduce print quality and cause paper jams or other problems. If you encounter problems, switch to a higher grade of paper.

Single sheets:

Size	A3+ 329 × 483 mm* A3 297 × 420 mm* B4 257 × 364 mm* A4 210 × 297 mm B5 182 × 257 mm A5 148 × 210 mm A6 105 × 148 mm 10 × 15 cm (4 × 6 in.) 13 × 18 cm (5 × 7 in.) 9 × 13 cm (3.5 × 5 in.) 13 × 20 cm (5 × 8 in.) 20 × 25 cm (8 × 10 in.) 16:9 wide size (102 × 181 mm) 100 × 148 mm Letter 8 1/2 × 11 in. Legal 8 1/2 × 14 in.
Paper types	Plain paper or special paper distributed by Epson
Thickness (for plain paper)	0.08 to 0.11 mm (0.003 to 0.004 in.)
Weight (for plain paper)	64 g/m ² (17 lb) to 90 g/m ² (24 lb)

* Available only for WF-7610 Series/WF-7620 Series.

Envelopes:


Size	Envelope #10 4 1/8 × 9 1/2 in. Envelope DL 110 × 220 mm Envelope C4 229 × 324 mm Envelope C6 114 × 162 mm
Paper types	Plain paper
Weight	75 g/m ² (20 lb) to 90 g/m ² (24 lb) for Envelope #10, DL, and C6 80 g/m ² (21 lb) to 100 g/m ² (26 lb) for Envelope C4

Product Information


Printable area

Highlighted portions show printable area.

Single sheets:



Envelopes:



	Minimum margin		
Media type	Single sheets	Envelopes (#10/DL/C6)	Envelop (C4)
A	3.0 mm (0.12 in.)	3.0 mm (0.12 in.)* ¹	3.0 mm (0.12 in.)* ¹
B	3.0 mm (0.12 in.)	5.0 mm (0.20 in.)	5.0 mm (0.20 in.)* ³ 10.0 mm (0.40 in.)* ⁴
C	3.0 mm (0.12 in.)	3.0 mm (0.12 in.)* ²	3.0 mm (0.12 in.)* ²

*1 The recommended margin is 21 mm.

*2 The recommended margin is 50 mm.

*3 For WF-7610 Series/WF-7620 Series

*4 For WF-3620 Series/WF-3640 Series

Product Information

Note:

Depending on the type of paper, print quality may decline in the top and bottom areas of the print, or the area may be smeared.

Scanner specifications

Scanner type	Flatbed color
Photoelectric device	CIS
Effective pixels	WF-7610 Series/WF-7620 Series: 14040 × 40800 pixels at 1200 dpi WF-3620 Series/WF-3640 Series: 10200 × 28080 pixels at 1200 dpi Scanning area may be restricted if resolution setting is large.
Document size (WF-7610 Series/WF-7620 Series)	297 × 431.8mm (11.7 × 17inches) A3 or US B (11 × 17inches)
Document size (WF-3620 Series/WF-3640 Series)	216 × 297 mm (8.5 × 11.7 inches) A4 or Letter
Scanning resolution	1200 dpi (main scan) 2400 dpi (sub scan)
Output resolution	50 to 4800, 7200, and 9600 dpi (50 to 4800 dpi in 1 dpi increments)
Image data	16 bits per pixel per color internal 8 bits per pixel per color external (maximum)
Light source	LED

Automatic Document Feeder (ADF) specifications

Paper input	Face-up loading
Paper output	Face-down ejection
Paper size ^{*1}	B5, A5, A4, Letter, Legal, B4 ^{*2} , A3 ^{*2}
Paper types	Plain paper
Paper weight	64 to 95 g/m ²
Paper capacity	Total thickness of 3.5 mm, up to about 35 sheets ^{*3*4}

^{*1} For the WF-3620 Series/WF-3640 Series, you cannot automatically scan both sides of A5 and Legal size paper.

^{*2} A3 and B4 documents are only available for the WF-7610 Series/WF-7620 Series.

^{*3} For WF-3620 Series/WF-3640 Series, the loading capacity of Legal size is 10 sheets.

^{*4} Paper with a weight of 75g/m².

Product Information

Fax specifications

Fax type	Walk-up black and white and color fax capability (ITU-T Super Group 3)
Supported lines	Standard analogue telephone lines, PBX (Private Branch Exchange) telephone systems
Speed	Up to 33.6 kbps
Resolution	Monochrome Standard: 203 × 98 dpi Fine: 203 × 196 dpi Photo: 203 × 196 dpi Super Fine: 203 × 392 dpi Ultra Fine: 406 × 392 dpi Color Fine: 200 × 200 dpi Photo: 200 × 200 dpi
Speed dial numbers	WF-7610 Series/WF-7620 Series: 200 WF-3620 Series/WF-3640 Series: 100
Page memory	WF-7610 Series/WF-7620 Series: up to 550 pages WF-3620 Series/WF-3640 Series: up to 180 pages (Based on ITU-T No.1 chart)
Redial*	2 times (with 1 minute interval)
Interface	RJ-11 Phone Line RJ-11 Telephone set connection

* The specifications may differ by country or region.

Network interface specification

Wi-Fi	Standard:	IEEE 802.11b/g/n ^{*1}
	Security:	WEP (64/128bit) WPA-PSK (AES) ^{*2}
	Frequency Band:	2.4 GHz
	Maximum Radio-Frequency Power Transmitted:	17.5 dBm (EIRP)
	Communication Mode:	Infrastructure Ad hoc Wi-Fi Direct ^{*3}
Ethernet	Standard:	IEEE802.3i/u, IEEE802.3az ^{*4}
	Communication Mode:	Ethernet 100BASE-TX/10BASE-T ^{*5}

Product Information

Security Protocol	SSL / TLS	HTTPS Server/Client
		IPPS

*1 Complies with either IEEE 802.11b/g/n or IEEE 802.11b/g depending on location of purchase.

*2 Complies with WPA2 with support for WPA/WPA2 Personal.

*3 You can use the product in a Wi-Fi Direct and Simple AP mode even if you connect it to an Ethernet network.

*4 The connected device should comply with IEEE802.3az.

*5 Use a category 5e or higher STP (Shielded twisted pair) cable to prevent risk of radio interference.

Memory card

Compatible memory cards	Memory Stick Duo Memory Stick PRO Duo Memory Stick PRO-HG Duo Memory Stick Micro* MagicGate Memory Stick Duo SDXC SDHC SD miniSDHC* miniSD* microSDXC* microSDHC* microSD*
Media format DCF	DCF (Design rule for Camera File system) version 1.0 or 2.0 compliant. All card types standard version compliant.
Voltage Requirements	3.3 v

* Adapter required.

Photo data specifications

File format	JPEG with the Exif Version 2.3 standard The following TIFF 6.0 compliant images: - RGB full color images (not compressed) - Binary images (not compressed or CCITT encoded)
Image size	80 × 80 pixels to 10200 × 10200 pixels
File size	Up to 2 GB
Number of files	JPEG: Up to 9990 TIFF: Up to 999

Product Information

Mechanical

WF-7610 Series

Dimensions	Storage Width: 567 mm (22.3 inches) Depth: 486 mm (19.1 inches) Height: 340 mm (13.4 inches)
	Printing* Width: 567 mm (22.3 inches) Depth: 817 mm (32.2 inches) Height: 340 mm (13.4 inches)
Weight	Approx. 18.5 kg (40.8 lb) without the ink cartridges and the power cord.

* With the output tray extension extended.

WF-7620 Series

Dimensions	Storage Width: 567 mm (22.3 inches) Depth: 486 mm (19.1 inches) Height: 418 mm (16.5 inches)
	Printing* Width: 567 mm (22.3 inches) Depth: 817 mm (32.2 inches) Height: 418 mm (16.5 inches)
Weight	Approx. 21.7 kg (47.8 lb) without the ink cartridges and the power cord.

* With the output tray extension extended.

WF-3620 Series

Dimensions	Storage Width: 449 mm (17.7 inches) Depth: 417 mm (16.4 inches) Height: 243 mm (9.6 inches)
	Printing* Width: 449 mm (17.7 inches) Depth: 560 mm (22.0 inches) Height: 243 mm (9.6 inches)
Weight	Approx. 9.7 kg (21.4 lb) without the ink cartridges and the power cord.

* With the output tray extension extended.

WF-3640 Series

Product Information

Dimensions	Storage Width: 449 mm (17.7 inches) Depth: 427 mm (16.8 inches) Height: 308 mm (12.1 inches)
	Printing* Width: 449 mm (17.7 inches) Depth: 563 mm (22.2 inches) Height: 308 mm (12.1 inches)
Weight	Approx. 11.5 kg (25.4 lb) without the ink cartridges and the power cord.

* With the output tray extension extended.

Electrical

WF-7610 Series

		100-240 V Model	220-240 V Model
Input voltage range		90 to 264 V	198 to 264 V
Rated frequency range		50 to 60 Hz	50 to 60 Hz
Input frequency range		49.5 to 60.5 Hz	49.5 to 60.5 Hz
Rated current		1.0 to 0.6 A	0.6 A
Power consumption (with USB connection)	Standalone copying*	Approx. 19 W (ISO/ IEC24712)	Approx. 23 W (ISO/ IEC24712)
	Ready mode	Approx. 8.5 W	Approx. 8.7 W
	Sleep mode	Approx. 1.7W	Approx. 1.9 W
	Power off	Approx. 0.3 W	Approx. 0.4 W

* For users in Belgium, power consumption when copying may vary. Check <http://www.epson.be> for the latest specifications.

WF-7620 Series

		100-240 V Model	220-240 V Model
Input voltage range		90 to 264 V	198 to 264 V
Rated frequency range		50 to 60 Hz	50 to 60 Hz
Input frequency range		49.5 to 60.5 Hz	49.5 to 60.5 Hz
Rated current		1.0 to 0.6 A	0.6 A

Product Information

Power consumption (with USB connection)	Standalone copying	Approx. 19 W (ISO/ IEC24712)	Approx. 23 W (ISO/ IEC24712)
	Ready mode	Approx. 8.5W	Approx. 8.7W
	Sleep mode	Approx. 1.7 W	Approx. 1.9 W
	Power off	Approx. 0.3 W	Approx. 0.4 W

WF-3620 Series

		100-240 V Model	220-240 V Model
Input voltage range		90 to 264 V	198 to 264 V
Rated frequency range		50 to 60 Hz	50 to 60 Hz
Input frequency range		49.5 to 60.5 Hz	49.5 to 60.5 Hz
Rated current		0.8 to 0.4 A	0.4 A
Power consumption (with USB connection)	Standalone copying	Approx. 17 W (ISO/ IEC24712)	Approx. 17 W (ISO/ IEC24712)
	Ready mode	Approx. 7.3 W	Approx. 7.5 W
	Sleep mode	Approx. 1.6 W	Approx. 1.8 W
	Power off	Approx. 0.4 W	Approx. 0.4 W

WF-3640 Series

		100-240 V Model	220-240 V Model
Input voltage range		90 to 264 V	198 to 264 V
Rated frequency range		50 to 60 Hz	50 to 60 Hz
Input frequency range		49.5 to 60.5 Hz	49.5 to 60.5 Hz
Rated current		0.8 to 0.4 A	0.4 A
Power consumption (with USB connection)	Standalone copying	Approx. 18 W (ISO/ IEC24712)	Approx. 18 W (ISO/ IEC24712)
	Ready mode	Approx. 7.8 W	Approx. 8.0 W
	Sleep mode	Approx. 1.6 W	Approx. 1.8 W
	Power off	Approx. 0.4 W	Approx. 0.4 W

Note:

- ❑ Check the label on the back of the product for its voltage.
- ❑ For European users, see the following Website for details on power consumption.
<http://www.epson.eu/energy-consumption>

Product Information

Environmental

Temperature	Operation: 10 to 35 °C (50 to 95 °F) Storage: -20 to 40 °C (-4 to 104 °F) 1 month at 40 °C (104 °F)
Humidity	Operation:* 20 to 80% RH Storage:* 5 to 85% RH

* Without condensation

Standards and approvals

U.S. model:

Safety	UL60950-1 CAN/CSA-C22.2 No.60950-1
EMC	FCC Part 15 Subpart B Class B CAN/CSA-CEI/IEC CISPR 22 Class B

This equipment contains the following wireless module.

Manufacture: Askey Computer Corporation

Type: WLU6117-D69 (RoHS)

This product conforms to Part 15 of the FCC Rules and RSS-210 of the IC Rules. Epson cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

European model:

Low voltage directive 2006/95/EC	EN60950-1
EMC directive 2004/108/EC	EN55022 Class B EN61000-3-2 EN61000-3-3 EN55024
R&TTE directive 1999/5/EC	EN300 328 EN301 489-1 EN301 489-17 TBR21 EN60950-1

Product Information

For European users:

We, Seiko Epson Corporation, hereby declare that the equipment Models, C441C, C481D, and C481E are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

For use only in Ireland, UK, Austria, Germany, Liechtenstein, Switzerland, France, Belgium, Luxemburg, Netherlands, Italy, Portugal, Spain, Denmark, Finland, Norway, Sweden, Iceland, Croatia, Cyprus, Greece, Slovenia, Malta, Bulgaria, Czech, Estonia, Hungary, Latvia, Lithuania, Poland, Romania, and Slovakia.

Epson can not accept responsibility for any failure to satisfy the protection requirements resulting a non-recommended modification of the products.



Australian model:

EMC	AS/NZS CISPR22 Class B
------------	------------------------

Epson hereby declares that the equipment Models, C441C, C481D, and C481E, are in compliance with the essential requirements and other relevant provisions of AS/NZS4268. Epson cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product.

Interface

Hi-Speed USB (Device Class for computers)
Hi-Speed USB (for Mass storage class for external storage)*

* Epson cannot guarantee the operation of externally connected devices.

External USB device

Devices	The maximum capacities
MO drive*	1.3 GB
Hard disk drive* USB Flash drive	2 TB Formatted in FAT, FAT32, or exFAT.

* External storage devices that are powered via USB are not recommended. Use only external storage devices with independent AC power sources.

Photo data file format	<p>DCF (Design rule for Camera File system) version 1.0 or 2.0* compliant.</p> <p>* Photo data stored in digital cameras with built-in memory are not supported.</p> <p>JPEG with the Exif Version 2.3 standard.</p> <p>TIFF 6.0 compliant images as below</p> <ul style="list-style-type: none"> - RGB full color image (non-compression) - Binary image (non-compression or CCITT encoding)
-------------------------------	---

Where To Get Help

Technical Support Web Site

If you need further help, visit the Epson support website shown below. Select your country or region and go to the support section of your local Epson website. The latest drivers, FAQs, manuals, or other downloadables are also available from the site.

<http://support.epson.net/>

<http://www.epson.eu/Support> (Europe)

If your Epson product is not operating properly and you cannot solve the problem, contact Epson support services for assistance.

Contacting Epson Support

Before Contacting Epson

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact Epson support services for assistance. If Epson support for your area is not listed below, contact the dealer where you purchased your product.

Epson support will be able to help you much more quickly if you give them the following information:

- ☐ Product serial number
(The serial number label is usually on the back of the product.)
- ☐ Product model
- ☐ Product software version
(Click **About**, **Version Info**, or similar button in the product software.)
- ☐ Brand and model of your computer
- ☐ Your computer operating system name and version
- ☐ Names and versions of the software applications you normally use with your product

Note:

Depending on the product, the dial list data for fax and/or network settings may be stored in the product's memory. Due to breakdown or repair of a product, data and/or settings may be lost. Epson shall not be responsible for the loss of any data, for backing up or recovering data and/or settings even during a warranty period. We recommend that you make your own backup data or take notes.

Help for Users in Europe

Check your **Pan-European Warranty Document** for information on how to contact Epson support.

Help for Users in Taiwan

Contacts for information, support, and services are:

World Wide Web

<http://www.epson.com.tw>

Information on product specifications, drivers for download, and products enquiry are available.

Epson HelpDesk

Phone: +886-2-80242008

Our HelpDesk team can help you with the following over the phone:

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

Repair service center:

<http://www.tekcare.com.tw/branchMap.page>

TekCare corporation is an authorized service center for Epson Taiwan Technology & Trading Ltd.

Help for Users in Australia

Epson Australia wishes to provide you with a high level of customer service. In addition to your product manuals, we provide the following sources for obtaining information:

Internet URL

<http://www.epson.com.au>

Access the Epson Australia World Wide Web pages. Worth taking your modem here for the occasional surf! The site provides a download area for drivers, Epson contact points, new product information and technical support (e-mail).

Epson Helpdesk

Phone: 1300-361-054

Epson Helpdesk is provided as a final backup to make sure our clients have access to advice. Operators on the Helpdesk can aid you in installing, configuring and operating your Epson product. Our Pre-sales Helpdesk staff can provide literature on new Epson products and advise where the nearest dealer or service agent is located. Many types of queries are answered here.

Where To Get Help

We encourage you to have all the relevant information on hand when you ring. The more information you prepare, the faster we can help solve the problem. This information includes your Epson product manuals, type of computer, operating system, application programs, and any information you feel is required.

Transportation of Product

Epson recommends retaining product packaging for future transportation.

Help for Users in Singapore

Sources of information, support, and services available from Epson Singapore are:

World Wide Web

<http://www.epson.com.sg>

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), Sales Enquiries, and Technical Support via e-mail are available.

Epson Helpdesk

Toll Free: 800-120-5564

Our HelpDesk team can help you with the following over the phone:

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problem troubleshooting
- ☐ Enquiries on repair service and warranty

Help for Users in Thailand

Contacts for information, support, and services are:

World Wide Web

<http://www.epson.co.th>

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and e-mail are available.

Epson Hotline

Phone: 66-2685-9899

Email: support@eth.epson.co.th

Our Hotline team can help you with the following over the phone:

- ☐ Sales enquiries and product information

Where To Get Help

- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

Help for Users in Vietnam

Contacts for information, support, and services are:

Epson Hotline

Phone (Ho Chi Minh City): 84-8-823-9239

Phone (Hanoi City): 84-4-3978-4785, 84-4-3978-4775

Epson Service Center

65 Truong Dinh Street, District 1, Hochiminh City, Vietnam

29 Tue Tinh, Quan Hai Ba Trung, Hanoi City, Vietnam

Help for Users in Indonesia

Contacts for information, support, and services are:

World Wide Web

<http://www.epson.co.id>

- ☐ Information on product specifications, drivers for download
- ☐ Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

Epson Hotline

Phone: +62 1500-766

Fax: +62-21 808 66-799

Our Hotline team can help you with the following over the phone or fax:

- ☐ Sales enquiries and product information
- ☐ Technical support

Where To Get Help

Epson Service Center

Province	Company Name	Address	Phone E-mail
DKI JAKARTA	ESS Jakarta MG. DUA	RUKO MANGGA DUA MALL NO. 48 JL. ARTERI MANGGA DUA - JAKARTA UTARA- DKI	(+6221)62301104 jkt-technical1@epson-indonesia.co.id
NORTH SUMATERA	ESC Medan	Kompleks Graha Niaga, Jl. Bambu II No. A-4, Medan- 20114	(+6261)42066090/42066091 mdn-technical@epson-indonesia.co.id
WEST JAWA	ESC Bandung	JL. CIHAMPELAS NO. 48A-BANDUNG JABAR 40116	(+6222)4207033 bdg-technical@epson-indonesia.co.id
DI YOGYAKARTA	ESC Yogyakarta	YAP Square, Blok A No.6 Jl. C Simanjutak YOGYAKARTA - DIY	(+62274)581065 ygy-technical@epson-indonesia.co.id
EAST JAWA	ESC Surabaya	HITECH MALL LT.2 BLOK A NO. 24 JL. KUSUMA BANGSA NO. 116 -118 - SURABAYA JATIM	(+6231)5355035 sby-technical@epson-indonesia.co.id
SOUTH SULAWESI	ESC Makassar	JL. GUNUNG BAWAKARAENG NO.68E - MAKASSAR SULSEL	(+62411)328212 mksr-technical@epson-indonesia.co.id
WEST KALIMANTAN	ESC Pontianak	JL. NUSA INDAH I NO. 40A PONTIANAK KALBAR 78117	(+62561)735507 pontianak-technical@epson-indonesia.co.id
PEKANBARU	ESC PEKANBARU	JL. TUANKU TAMBUSAI NO. 353 - PEKANBARU RIAU	(+62761)21420 pkb-technical@epson-indonesia.co.id
DKI JAKARTA	ESS JAKARTA KEIAI	WISMA KEIAI LT. 1 JL. JEND. SUDIRMAN KAV. 3 JAKPUS DKI JAKARTA	(+6221)5724335 ess.support@epson-indonesia.co.id
EAST JAWA	ESS SURABAYA	JL. JAWA NO. 2-4 KAV. 29, RUKO SURYA INTI, SURABAYA - JATIM	(+6231)5014949 esssby.support@epson-indonesia.co.id
BANTEN	ESS SERPONG	Ruko mall WTC MATAHARI no. 953 SERPONG - Banten	(+6221)53167051 esstag.support@epson-indonesia.co.id
CENTRAL JAWA	ESS SEMARANG	Komplek Ruko Metro Plaza Blok C20 , Jl. MT Haryono No 970 Semarang - Jawa tengah	(+6224)8313807 esssmg.support@epson-indonesia.co.id
EAST KALIMANTAN	ESC SAMARINDA	Jl. KH. Wahid Hasyim (M. Yamin) Kel. Sempaja Selatan Kec. Samarinda Utara Samarinda- Kalimantan Timur (samping kantor pos)	(+62541)7272904 escsmd.support@epson-indonesia.co.id

Where To Get Help

Province	Company Name	Address	Phone E-mail
SOUTH SUMATERA	ESC PALEMBANG	Jl. H.M. Rasyid Nawawi no.249, kelurahan 9 ilir Palembang - Sumsel	(+62711)311330 escplg.support@epson-indonesia.co.id
EAST JAVA	ESC JEMBER	Jl. Panglima Besar Sudirman No.1 D JEMBER - JAWA TIMUR (Depan Balai Penelitian dan Pengolahan Kakao)	(+62331) 486468,488373 jmr-admin@epson-indonesia.co.id jmr-technical@epson-indonesia.co.id
NORTH SULAWESI	ESC MANADO	Tekno @Megamall, Megamall LG TK-21 Jl. Piere Tendean Kawasan Megamas Boulevard Manado 95111	(+62431)7210033 MND-ADMIN@EPSON-INDONESIA.CO.ID

For other cities not listed here, call the Hot Line: 08071137766.

Help for Users in Hong Kong

To obtain technical support as well as other after-sales services, users are welcome to contact Epson Hong Kong Limited.

Internet Home Page

<http://www.epson.com.hk>

Epson Hong Kong has established a local home page in both Chinese and English on the Internet to provide users with the following information:

- ☐ Product information
- ☐ Answers to Frequently Asked Questions (FAQs)
- ☐ Latest versions of Epson product drivers

Technical Support Hotline

You can also contact our technical staff at the following telephone and fax numbers:

Phone: 852-2827-8911

Fax: 852-2827-4383

Help for Users in Malaysia

Contacts for information, support, and services are:

Where To Get Help

World Wide Web

<http://www.epson.com.my>

- ☐ Information on product specifications, drivers for download
- ☐ Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

Epson Call Centre

Phone: +60 1800-8-17349

- ☐ Sales enquiries and product information
- ☐ Product usage questions or problems
- ☐ Enquiries on repair services & warranty

Head Office

Phone: 603-56288288

Fax: 603-5628 8388/603-5621 2088

Help for Users in the Philippines

To obtain technical support as well as other after sales services, users are welcome to contact the Epson Philippines Corporation at the telephone and fax numbers and e-mail address below:

World Wide Web

<https://www.epson.com.ph/>

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and E-mail Enquiries are available.

Epson Philippines Customer Care

Toll Free (PLDT): 1800-1069-37766

Toll Free (Digital): 1800-3-0037766

Metro Manila: (+632)441-9030

Web Site: <https://www.epson.com.ph/contact>

E-mail: customercare@epc.epson.som.ph

Our Customer Care team can help you with the following over the phone:

- ☐ Sales enquiries and product information

Where To Get Help

- ☐ Product usage questions or problems
- ☐ Enquiries on repair service and warranty

Epson Philippines Corporation

Trunk Line: +632-706-2609

Fax: +632-706-2665

Index

2

2-Sided.....	109, 113
2-Sided (Copy).....	120
2-sided printing.....	58
2-up.....	109
2-up Copy.....	43

4

4-up.....	109
-----------	-----

A

A4/Letter Auto Switching.....	115
ADF 2-Sided.....	111
Admin Password.....	114
Admin Settings.....	114
Administrator settings.....	65
Advanced Setup.....	117
Aligning print head.....	140
Anti-Copy Pattern printing.....	62
Attach Image to Report.....	118
Attached File Max Size.....	113
Auto Error Solver.....	115
Auto Reduction.....	118
Auto Rotation.....	117, 118
Auto Select Settings.....	115
Automatic Document Feeder (ADF).....	42
paper jams in.....	191
problems.....	191

B

Backup Data Auto Clear.....	119
Banding.....	179
Basic Settings.....	112, 113, 119
Batch Send.....	90, 117
Bidirectional.....	110
Blank pages.....	183
Blurry prints.....	180
Borderless.....	109, 110
Buttons	
control panel.....	21

C

Canceling printing.....	55
Mac OS X.....	56
Windows.....	56
Check Fax Connection.....	119
Check Paper Width.....	120
Cleaning	
print head.....	138
Clear Backup Data.....	119

Collate Copy.....	109
Collation Stack.....	118
Color problems.....	180
Common Settings.....	116
Communication Mode.....	112
Compression Ratio.....	113
Configuration Status Sheet.....	114
Configure.....	120
Confirm Address List.....	119
Connection Check.....	117
Connection Mode.....	112
Contacting Epson.....	209
Continuous Scan from ADF.....	111
Control panel.....	21
Copy Settings.....	117
Copying	
basic.....	47
Copyright.....	2
Country/Region.....	116

D

Date.....	110
Date/Time.....	116
Date/Time Settings.....	116
Daylight Saving Time.....	116
Density.....	109, 111, 113
Dial Mode.....	119
Dial Tone Detection.....	119
Direct Dialing Restrictions.....	119
Direct Send.....	90, 111
Disable Wi-Fi.....	117
Document Orientation.....	109, 113
Document Size.....	109
Document Size (Glass).....	111
Document Type.....	113
Documents	
printing.....	51
DRD.....	118
Driver.....	79
accessing for Mac OS X.....	51
accessing for Windows.....	50
uninstalling.....	152
Dry Time.....	110, 120

E

Easy Photo Print.....	57
ECM.....	119
Eco Mode.....	120
Email Server Status.....	114
Email Settings.....	113
Enlarging pages.....	60
Envelopes	
loading.....	36, 39
printable area.....	200
Epson	
Easy Photo Print.....	57

Index

paper.....	27
Epson Connect.....	10
Epson Connect Services.....	117
Epson Connect Status.....	114
Epson Event Manager.....	79
Error Code.....	159
Error messages.....	158
Error Notice.....	115
Errors	
fax.....	195
print.....	162
scan.....	189
Expansion.....	109, 110
External USB device.....	208

F

Fax Log Auto Print.....	104, 118
Fax Output.....	118
Fax Report.....	104, 111
Fax Send Settings.....	111
Fax Setting Wizard.....	84, 119
Fax Settings.....	117
Fax Speed.....	119
File Settings.....	112
File Sharing.....	115
Filename Prefix.....	113
Fit Frame.....	110
Fit to page printing.....	60
Fix Photo.....	110
Fix Red-Eye.....	110
Format.....	112, 113
Forwarding Report.....	118

G

Google Cloud Print Services.....	117
Google Cloud Print Status.....	114

H

Head cleaning	
control panel.....	140
Mac OS X.....	139
Windows.....	139
Header.....	119
Header/Footer printing.....	64
Help	
Epson.....	209
Epson Event Manager.....	79
Epson Scan.....	79
Horizontal Alignment.....	114
Horizontal banding.....	179

I

Icons for each mode.....	24
ID Card.....	109
Image Adjustment.....	74
Image Adjustments.....	110

Inbox Password Settings.....	119
Incorrect characters.....	181
Initialize.....	194
Ink	
BK printing.....	129
BK printing in Mac.....	131
BK printing in Windows.....	129
checking ink cartridge status in Mac OS X.....	127
checking ink cartridge status in Windows.....	126
precaution.....	124
saving black ink in Windows.....	132
temporarily printing with black ink.....	129
Ink Cartridge(s) Replacement.....	114
Ink cartridges	
replacing when expended.....	133
Ink Levels.....	114
Interface cables.....	208

J

JPEG.....	110
-----------	-----

L

Language.....	116
Layout.....	109, 110
LCD Brightness.....	116, 120
Left Offset.....	120
Left Offset in Back.....	120
Light	
status lights.....	189
Lights	
control panel.....	21
flashing.....	186
Line Type.....	85, 119
Loading	
envelopes.....	36
paper.....	27, 33, 39
Location.....	112
Lock Setting.....	114

M

Mac OS X	
accessing printer settings.....	51
checking product status.....	164
Maintenance.....	114
Maintenance box.....	147
Managing print jobs	
Windows.....	163
Manual feed.....	39
Margins	
problems.....	182
Marquee.....	77, 78
Memory cards	
data specifications.....	203
inserting.....	44
supported types.....	203
Memory Device.....	115
Memory Device Interface.....	115

Index

Menu.....	112, 113
Mirror image.....	183
Misalignment.....	179
Multiple pages per sheet.....	61

N

Network Status.....	114
Nozzle check.....	137
control panel.....	138
Mac OS X.....	137
Windows.....	137

O

Off.....	120
On.....	120
Operation Time Out.....	116
Options.....	110
Output Settings.....	118

P

Pages per sheet printing.....	61
Paper	
Epson special paper.....	27
feeding problems.....	184
jams.....	165
loading.....	33, 39
loading capacity.....	27
printable area.....	200
specifications.....	199
wrinkling.....	185
Paper Guide Cleaning.....	114
Paper jam.....	191
Paper Setup.....	114
Paper Size Notice.....	115
Paper Source.....	109, 110
Paper Source Settings.....	115
Paper Type Notice.....	115
Password.....	112
PBX.....	85
PC Connection via USB.....	115
PDF Settings.....	113
Photo	
software.....	57
PIN Code Setup (WPS).....	117
Polling Receive.....	100, 111
Polling Send.....	92, 111
Port Number.....	112
Power Off Timer.....	116
Presto! PageManager.....	80
Previewing.....	77
Print head	
aligning.....	140
checking.....	137
cleaning.....	138
Print Head Alignment.....	114
Print Head Cleaning.....	114
Print Head Nozzle Check.....	114

Print Order.....	110
Print quality	
improving.....	178
Print speed	
increasing.....	183
Print Status Sheet.....	114
Print Suspend Time.....	118
Printable area specifications.....	200
Printer Settings.....	115
Printing	
2-sided.....	58
canceling.....	55
fit to page.....	60
multiple pages per sheet.....	61
preset.....	58
shortcut.....	58
text.....	51
Printing from memory card.....	48
Printing Photos.....	48
Priority Send.....	90, 111
Problems	
banding.....	179
blank pages.....	183
blurry prints.....	180
contacting Epson.....	209
diagnosing.....	162
fax.....	195
incorrect characters.....	181
incorrect colors.....	180
margins.....	182
mirror image.....	183
paper feeding.....	184
paper jams.....	165
print.....	162
print speed.....	183
product does not print.....	185
scan.....	189
smeared prints.....	180, 183
solving.....	209
Product	
checking status.....	163
cleaning.....	145
parts.....	16
transporting.....	149
Product settings	
accessing for Mac OS X.....	51
accessing for Windows.....	50
Push Button Setup (WPS).....	117

Q

Quality.....	109, 110
--------------	----------

R

Receive Mode.....	94, 118
Receive Settings.....	118
Reducing page size.....	60
Remote Receive.....	101, 118
Remove Paper.....	114
Remove Punch Holes.....	109

Index

Remove Shadow.....	109
Replacing ink cartridges.....	133
Report Format.....	118
Resizing pages.....	60
Resolution.....	111, 113
Restore Default Settings.....	120
Restrictions on copying.....	14
Rings to Answer.....	86, 118

S

Safety information.....	11
Save Failure Data.....	117
Scan	
Skip Blank Page.....	71
Scan Area.....	113
Scan quality problems.....	191
Scan Report.....	112, 113
Scan Settings.....	117
Scan to a folder.....	68
Scan to an email.....	68
Scanner glass.....	44
Scanning software	
bundle software.....	79
Security Settings.....	119
Select Group.....	110
Select Images.....	110
Send Fax Later.....	111
Send Settings.....	117
Service.....	209
Settings.....	110, 112
Short Grain Paper.....	181
Skip Blank Page.....	120
Sleep Timer.....	116, 120
Smeared prints.....	180, 183
Software	
uninstalling.....	152
Sound.....	116
Specifications	
automatic document feeder.....	201
fax.....	202
mechanical.....	204
memory card.....	203
paper.....	199
printer.....	198
scanner.....	201
standards and approvals.....	207
Speed	
increasing.....	183
Split Pages.....	109
Status icons.....	23
Status lights.....	189
Status Menu.....	25
Status Monitor	
Mac OS X.....	164
Store Fax Data.....	92, 111
Subject.....	113
Supply Status Sheet.....	114
System Administration.....	114
System Administration Settings.....	115
System requirements.....	198

T

Technical support.....	209
Text	
printing documents.....	51
Thick Paper.....	114
TIFF.....	110
Time Difference.....	116
Top Offset.....	120
Top Offset in Back.....	120
Trademarks.....	2
Transmission Report.....	111
Transporting product.....	149

U

Universal Print Settings.....	120
Usage History Sheet.....	114
USB	
connector.....	208
User Default Settings.....	117
User Name.....	112

V

Vertical Alignment.....	114
-------------------------	-----

W

Watermark printing.....	63
Web service.....	10
Wi-Fi Auto Connect.....	117
Wi-Fi Direct Setup.....	117
Wi-Fi Direct Status.....	114
Wi-Fi Setup.....	117
Wi-Fi Setup Wizard.....	117
Wi-Fi/Network Settings.....	117
Wi-Fi/Network Status.....	114, 117
Windows	
accessing printer settings.....	50
checking product status.....	163
managing print jobs.....	163
With Border.....	109

Z

Zoom.....	109
-----------	-----