

ML-18000

For Customers Using Firmware Versions Other Than BP13P5

If you are using a firmware version other than BP13P5, the number of adjustment pattern blocks for manual (details) Print Head Alignment will be changed as follows:

Before the change: 1 to 144 blocks

After the change: 1 to 153 blocks

You can check the firmware version by touching [Printer Status] - [Firmware Version] on the menu screen of the operation panel.

When performing manual Print Head Alignment as described in the “User’s Manual” under Print Adjustments, please be aware of the difference in the number of blocks.

BP13P5 以外のファームウェアバージョンをご使用のお客様へ

BP13P5 以外のファームウェアバージョンをご使用の場合、プリントヘッドの位置調整の手動（詳細）の調整パターンブロック数が以下の通り変更されます。

変更前：1～144 ブロック

変更後：1～153 ブロック

ファームウェアバージョンは、操作パネルのメニュー画面の [情報確認] - [ファームウェアバージョン] をタッチしてご確認ください。
『ユーザーズマニュアル』の印刷調整 - プリントヘッドの位置調整（手動）を実施するときは、ブロック数の違いにご注意ください。