
OI-S05 (Compact Flash[®] Adapter)

410588001

Copyright© Seiko Epson Corporation 2006

Printed in China 2006.02

CompactFlash[®] is a trademark of SanDisk Corporation, registered in the United States and other countries.

EMC and Safety Standards Applied

Product name: OI-S05

Model name: M227A

The following standards are applied only to this equipment that are so labeled.

North America:EMI: FCC/ICES-003 Class A

Europe:CE marking

Japan:EMI: VCCI Class A

Oceania: EMC: AS/NZS CISPR22 Class A

WARNING

You are cautioned that changes or modifications not expressly approved by SEIKO EPSON Corporation could void your authority to operate the equipment.

CE Marking

This equipment conforms to the following Directives and Norms:

Directive 89/336/EEC

EN 55022 Class A

EN 55024

IEC 61000-4-2

IEC 61000-4-3

IEC 61000-4-4

IEC 61000-4-5

IEC 61000-4-6

IEC 61000-4-11

FCC Compliance Statement For American Users

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

For Canadian Users

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme la norme NMB-003 du Canada.

Important Safety Information

This user's manual and the product itself use a variety of icons to ensure that the product is safely used and to prevent personal injury or damage to your property or the property of others. Read the following carefully before handling the product.

WARNING

Indicates information that, if ignored, could cause death or severe injury to the user.

CAUTION

Indicates information that, if ignored, could cause severe injury to the user or that could cause damage to the user's property only.

Safety Precautions

WARNING

- Never disassemble or modify this product.
Tampering with this product may result in injury, fire, or electric shock.*
- Do not allow foreign objects to fall into this product.
Penetration by foreign objects may lead to fire or shock.*
- If water or other liquid spills into this product, immediately turn off the power switch and contact your dealer or an Epson service center for advice.
Continued use may lead to fire or shock.*

CAUTION

- Do not drop or subject this product to strong physical shocks.
Rough treatment may damage the product.*
- Do not use the unit in locations subject to high humidity or dust levels. Make particularly sure to avoid using in areas with excessive heat and humidity, and never subject to condensation.
Using the product in such an environment could cause damage or product deterioration.*
- Turn the power switch off before inserting or removing compact flash memory.*