

# TM-C3400 Series CW-C4000 Series TM-C3500 Series



ファンフォールド紙をセットする場合  
When Installing Fanfold Paper

Dans le cas de papier en accordéon

Beim Einlegen von Endlospapier

Bij het plaatsen van kettingpapier

Quando si inserisce carta continua

Cuando Coloque Papel Continuo

Ao Instalar o Papel Contínuo

При установке фальцованной бумаги

安裝折疊式記錄紙時


安裝折疊式記錄紙時

①




OFF

②



③



\*412539401\*