




*	USB-A	USB-B	USB-C	USB-PD	Ethernet	Wi-Fi	Bluetooth	microSD
001, 002, 101, 102	✓	✓	✓	✓	✓	-	-	-
021, 022, 141, 142, 621, 622	✓	✓	✓	✓	✓	✓	✓	-
011, 012	✓	✓	-	✓	✓	-	-	✓
051, 052	✓	✓	-	✓	✓	✓	✓	✓