



\*412452600\*

**EPSON®**  
EXCEED YOUR VISION

# UB-P500 User's Manual

Copyright © Seiko Epson Corporation 2012  
Printed in China

## **Introduction**

The UB-P500 is a dedicated interface board for Epson EU-T482 series. This manual provides instructions, including a simple setup for operators to use the interface board safely and correctly.

## **Important Safety Information**

### **Key to Symbols**

The symbols in this manual are identified by their level of importance, as defined below. Read the following carefully before handling the product.



#### **CAUTION:**

*Cautions must be observed to avoid minor injury to yourself, damage to your equipment, or loss of data.*



#### **Note:**

*Notes have important information and useful tips on the operation of your equipment.*

### **Safety Precautions**



#### **CAUTION:**

*Do not install the UB-P500 into other printers than the Epson EU-T482 series.*

*The printers may not work properly.*

*Be sure to make the printer setting appropriately for each interface.*

*Disconnect the power supply from the printer before you remove the interface board. The electrical current is flowing in some parts of the printer circuit even when the power switch is turned off. The interface board and printer may become damaged if you install the interface board with the power supply connected to the printer.*

*Wear a grounded wrist strap when handling the interface board to prevent damage from static electricity.*

*To avoid contamination, do not touch the board connector.*

## **Unpacking**

The following items are included. If any item is damaged, contact your dealer.

- UB-P500
- User's Manual (this manual)

---

## Installing the UB-P500 in the Printer


1. Remove the two screws that securing the interface board; then pull the board and remove it. You will use the screws when installing the UB-P500.



### **CAUTION:**

*Put the removed interface board into an anti-static bag for storage to prevent damage from static electricity.*

2. Hold the UB-P500 as shown in the illustration below. Push the UB-P500 in gently until you feel the connector fits into place.



3. Secure the UB-P500 with the two screws.
4. Change the printer settings to match the printer to the new interface. See the printer documentation for the settings.



### **Note:**

*Be sure to make the printer settings, or the printer may not work correctly.*

---

## Standards and Approvals

The following standards are applied only to the interface boards that are so labeled. (EMC is tested using the EPSON power supplies and EU-T482 series.)

Europe: CE marking

North America: FCC/ICES-003 Class A

Oceania: AS/NZS CISPR22 Class A

### **WARNING**

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

The printers in which this board is installed becomes class A devices.

The connection of a non-shielded printer interface cable to this board will invalidate the EMC standards of this device.

You are cautioned that changes or modifications not expressly approved by Seiko Epson Corporation could void your authority to operate the equipment.

## **CE Marking**

The printer conforms to the following Directives and Norms:

Directive 2004/108/EC

EN 55022 Class A

EN 55024

IEC 61000-4-2

IEC 61000-4-3

IEC 61000-4-4

IEC 61000-4-5

IEC 61000-4-6

## **FCC Compliance Statement For American Users**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

## **For Canadian Users**

This Class A digital apparatus complies with Canadian ICES-003.

## **À l'intention des utilisateurs canadiens**

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, Seiko Epson Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by Seiko Epson Corporation.

EPSON is a registered trademark of Seiko Epson Corporation in Japan and other countries/regions.

Windows is a registered trademark of Microsoft Corporation, USA.

General Notice: Other product and company names used herein are for identification purposes only and may be trademarks of their respective companies.

**Notice:** The contents of this manual are subject to change without notice. Please contact us for the latest information.

